

[Manuals.plus](#) /

› [YOTON](#) /

› YOTON 17.5" Portable DVD Player Instruction Manual

YOTON 735940743037

YOTON 17.5" Portable DVD Player

Model: 735940743037

Brand: YOTON

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your YOTON 17.5" Portable DVD Player. Please read this manual thoroughly before using the device and retain it for future reference. This portable DVD player is designed for versatile entertainment, offering a high-definition viewing experience with its swivel screen and multi-format support.

2. WHAT'S IN THE BOX

- 1 x Portable DVD Player YD155
- 1 x Remote Control (battery not included)
- 1 x AC Charger
- 1 x 3-in1 AV Cable (male)
- 1 x Car Charger



Image: Contents of the YOTON Portable DVD Player package, including the player, remote control, AC charger, AV cable, and car charger.

3. PRODUCT OVERVIEW & FEATURES

3.1. High-Definition Swivel Screen

Enjoy crystal-clear viewing on the 1280*800 resolution swivel screen that rotates 270° and flips 180° for perfect angles. The anti-glare display reduces eye strain during extended use, ideal for movies, shows, and educational content.



Image: The YOTON Portable DVD Player displaying its 15.6-inch screen.




Image: Illustration highlighting the wide viewing angle capabilities of the YOTON Portable DVD Player's screen.

3.2. Long-Lasting Battery

The 5000mAh rechargeable battery delivers 6+ hours of continuous playback. It includes a certified AC adapter and a 70" car charger for home, car, or travel use, ensuring you never worry about sudden power loss during trips.

Region Free & Multiple Formats



Disc Format:

VCD VCD1.1, VCD2.0, VCD3.0, SVCD, DVCD, CVD

DVD MINI DVD, DVD-5, DVD-9, DVD-10, DVD-18, DVD+R, DVD-R, DVD-RW, DVD+RW

Image: The YOTON Portable DVD Player with an overlay indicating its 5000mAh high-capacity battery.



Image: Graphic illustrating the 6-hour battery life and the included car charger and AC power adapter.

3.3. Multi-Format Support & Region-Free Playback

The player supports direct playback of various disc formats including CD, DVD, DVD±R, CD-R(RW), SVCD-R(RW), DVD±RW, and VCD. **Note: It does not support Blu-ray and Dolby discs.** It also supports multi-media files via USB and SD Card (up to 32G), such as VOB, AVI, MPEG, MP3, WMA, and JPEG. Its region-free design allows easy playback of discs from all regions.



Image: The YOTON Portable DVD Player with a visual representation of supported disc formats like VCD and DVD.

High-capacity Battery

Rechargeable lithium battery supports playback time of 2 movies and comes with 2 types of chargers.

(Included in the package)



5000 mAh
Battery



Car
Charger



AC Power
Adapter



Image: Graphic illustrating the region-free capability and various supported media formats (VCD, DVD, USB, SD card).

3.4. Dual Stereo Speakers

Equipped with dual stereo speakers, the player provides sufficient sound experience for an immersive viewing experience.

Last Memory Function

The break-point memory function will pick up from where you left last time



Image: The YOTON Portable DVD Player with a graphic overlay showing sound waves emanating from its dual stereo speakers.



Region Free & Multiple Formats

Note:Doesn't Support Blu-ray Discs.

Disc Format:

VCD VCD1.1, VCD2.0, VCD3.0, SVCD, DVCD, CVD

DVD MINI DVD, DVD-5, DVD-9, DVD-10, DVD-18, DVD+R, DVD-R, DVD-RW, DVD+RW

Image: Illustration emphasizing the dual speaker setup for superior audio performance.

3.5. Last Memory Function

The break-point memory function allows the player to pick up from where you left off last time, ensuring a seamless viewing experience.



Image: The YOTON Portable DVD Player illustrating its last memory function, resuming playback from where it was stopped.





Image: Graphic demonstrating the break-point memory function, showing the player resuming from its last position.

3.6. USB & SD Card Support

The device supports multi-media files via USB and SD Card (up to 32G). This allows for flexible playback of various digital content.



Image: The YOTON Portable DVD Player highlighting its USB and SD card input slots.




Last Memory Function

The break-point memory function will pick up from where you left last time.

Image: Detailed view of the YOTON Portable DVD Player's side ports, including USB, SD card, headphone jack, AV in/out, DC, and Game USB.

3.7. External Connectivity (Sync Screen to TV)

Easily create a private theater for your family by syncing the screen to a television, projector, or another similar player using the AV output.



Support USB and SD Cards

Supports multi-media files via USB and SD Card (up to 32G)

Image: The YOTON Portable DVD Player connected to a television, demonstrating its screen sync capability.



Image: Graphic showing the YOTON Portable DVD Player's ability to sync its screen to a television, projector, or another player.

3.8. Vibration Absorption Technology

Built-in vibration absorption technology prevents skips and freezes when moving, ensuring smooth viewing in cars, planes, or while walking. This makes it perfect for travel entertainment.

3.9. Child & Senior-Friendly Design

Simple one-touch controls and loud stereo speakers make it easy for kids and elderly users to enjoy movies and music. The device also includes a parental control function for safe viewing.

3.10. Official Product Video

Your browser does not support the video tag.

Video: An official product video from YOTON showcasing the features and usage of the YOTON Portable DVD Player.

4. SETUP

1. **Charging the Battery:** Before first use, fully charge the internal 5000mAh battery using the provided AC charger. The indicator light will show charging status. For car use, connect the provided car charger to the vehicle's 12V power outlet.
2. **Power On/Off:** Locate the power switch (ON/OFF) on the side of the device. Slide it to the 'ON' position to power on.
3. **Inserting a Disc:** Gently slide the disc tray release to open the disc compartment. Place your DVD or CD disc onto the spindle, ensuring it is seated correctly. Close the disc compartment.
4. **Connecting External Devices:**
 - **USB/SD Card:** Insert a USB flash drive or SD card (up to 32GB) into the respective slots to play media files.
 - **Headphones:** Plug 3.5mm headphones into the headphone jack for private listening.
 - **AV In/Out:** Use the 3-in-1 AV cable to connect to an external display (TV, projector) via AV OUT, or to display content from another device on the DVD player's screen via AV IN.
 - **Gamepad:** Connect a compatible gamepad to the dedicated Game USB port for gaming (if supported by media).

5. OPERATING INSTRUCTIONS

5.1. Basic Playback

- After inserting a disc or connecting a USB/SD device, the player will typically begin loading automatically.
- Use the controls on the player or the remote control to navigate menus, play, pause, stop, fast forward, rewind, and adjust volume.

Supports USB and SD cards (Max 32GB)

Video Encoding MPEG-1, MPEG-2, MP4V, DIVIX, XVID

Video AVI, MPG, MPEG, DAT, VOB, ASF

Audio MP3, WMA, OGG, ACC

Image JPEG



Image: Close-up of the YOTON Portable DVD Player's control panel, showing buttons for playback, volume, and menu navigation.

5.2. Screen Adjustment

- The screen can swivel 270° and flip 180° to achieve optimal viewing angles.
- Adjust the screen position carefully to avoid putting strain on the hinge.

5.3. Media Playback Notes

- Only supports 720*480 resolution video files and 2650*1440 resolution image files.
- Does not support 1080P, 4K, or Blu-ray discs.

6. MAINTENANCE

- Keep the device clean by wiping it with a soft, dry cloth.
- Avoid exposing the player to extreme temperatures, direct sunlight, or high humidity.
- Handle discs carefully to prevent scratches and ensure smooth playback.
- When not in use for extended periods, fully charge the battery and store the device in a cool, dry place.

7. TROUBLESHOOTING

Q: Video Player doesn't work?

1. Please make sure the power switch is set to the ON position and check the battery. Connect the DVD Player to the power adapter and then check the status of the indicator light.
2. If the power switch is ON and the power adapter is connected, but no indicator light is shown, it indicates a problem with the motherboard or power adapter.
3. If the power adapter is connected and the indicator light is on, it indicates a problem with the motherboard.
4. Please contact us for support: support.vp@yoton.co

Q: Video Player doesn't read the disc?

1. Please clean the laser and try other VCD, CD and assumed game CD for testing purposes.
2. If all discs cannot be read, this would indicate a problem with the laser or motherboard.
3. Partial discs cannot be read. The laser is aging or the disc is not compatible.
4. The Video Player does not support HD/Blu-ray CD and Dolby discs.
5. There is a yellow card inside the Video Player. Please remove it before you insert a disc.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	15.35 x 10.24 x 1.97 inches
Item Weight	3.96 pounds
ASIN	B09WN25ZB1
Item model number	735940743037
Batteries	1 Lithium Ion batteries required. (included)
Date First Available	March 28, 2022
Manufacturer	YOTON
Brand	YOTON
Media Type	SD, VCD, DVD, AVI, MPG, MPEG, DAT, VOB, OGG, ASF, CD, MP3, WMA, JPEG
Color	Black
Screen Size	15.6 Inches
Display Type	LCD

9. WARRANTY & SUPPORT

All products purchased from YOTON are covered by a 1-year warranty. For any concerns about using the product or anything in need, please feel free to reach out at any time. Our professional team will offer you 100% technology support in 24 hours.

9.1. Accessories & Parts

YOTON customers enjoy after-sales service. You can contact our after-sales team directly for free new parts for any broken or missing components.

9.2. Protection Plans

Additional protection plans are available for purchase:

- **2-Year Protection Plan:** \$6.99 (one-time)

- **3-Year Protection Plan:** \$8.99 (one-time)
- **Complete Protect:** One plan covers all eligible past and future purchases for \$16.99/month.



Image: Graphic detailing YOTON's customer support, including prompt replies and lifetime professional support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question