

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Naxa](#) /
- › [Naxa NSH-3001 Wi-Fi Smart Camera User Manual](#)

Naxa NSH-3001

Naxa NSH-3001 Wi-Fi Smart Camera User Manual

Model: NSH-3001

INTRODUCTION

The Naxa NSH-3001 Wi-Fi Smart Camera provides reliable home security monitoring with 24/7 HD recording capabilities. This camera allows you to check in on your home remotely from anywhere using your smartphone. It features motion detection, two-way audio communication, night vision, and customizable activity alerts.

This manual provides detailed instructions for setting up, operating, and maintaining your Naxa NSH-3001 Wi-Fi Smart Camera to ensure optimal performance and security.



Image: Front view of the Naxa NSH-3001 Wi-Fi Smart Camera, showing the lens and Naxa logo.

WHAT'S IN THE BOX

Upon unpacking your Naxa NSH-3001 Wi-Fi Smart Camera, please ensure all the following components are present:

- Wi-Fi Smart Camera
- AC Power Adapter
- USB Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Naxa NSH-3001 Wi-Fi Smart Camera.

naxa®
NSH-3001

Wi-Fi™

Smart Life

Download on the App Store

ANDROID APP ON Google play

Controlled with the Smart Life App right on your phone

Protect Your Home Even When You're Away

Image: The Naxa NSH-3001 Wi-Fi Smart Camera displayed alongside icons representing its key features: HD Resolution, Encrypted ID, 2-Way Audio, Cloud Service, Motion Detection, IR Night Vision, Time Scheduling, and Hotspot capability.

- **Camera Lens:** Captures video footage.
- **Infrared (IR) LEDs:** Provide night vision capabilities.

- **Microphone:** For audio input and two-way communication.
- **Speaker:** For audio output and two-way communication.
- **Micro USB Port:** For power connection.
- **Reset Button:** Used to reset the camera to factory settings.
- **Micro SD Card Slot:** For local storage of recorded footage (Micro SD card not included).

SETUP GUIDE

1. Powering On the Camera

1. Connect the provided USB cable to the camera's Micro USB port.
2. Connect the other end of the USB cable to the AC power adapter.
3. Plug the AC power adapter into a standard electrical outlet.
4. The camera will power on, and an indicator light will show its status (refer to the camera's LED indicator guide for specific light patterns).

2. Downloading the Smart Life App

The Naxa NSH-3001 camera is controlled via the Smart Life app. Download it to your smartphone:

- For iOS devices, search for "Smart Life" in the Apple App Store.
- For Android devices, search for "Smart Life" in the Google Play Store.
- Install the app and create an account if you don't already have one.



Image: The Naxa NSH-3001 Wi-Fi Smart Camera shown with the Smart Life app logo and icons for the Apple App Store and Google Play, indicating app compatibility.

3. Connecting to Wi-Fi

Ensure your smartphone is connected to a 2.4 GHz Wi-Fi network. The NSH-3001 camera only supports 2.4 GHz Wi-Fi.

1. Open the Smart Life app and tap "Add Device" or the "+" icon.
2. Select "Security & Video Surveillance" and then "Smart Camera".
3. Follow the on-screen instructions in the app to connect your camera to your Wi-Fi network. This typically involves scanning a QR code generated by the app with the camera's lens.
4. Once connected, the camera's indicator light will change (refer to the LED indicator guide), and you will see the camera added to your app.

4. Mounting the Camera

The NSH-3001 camera is designed for wall mount installation, but can also be placed on a flat surface. Choose a location that provides the desired viewing angle (105 degrees) and is within range of your Wi-Fi signal.



Image: The Naxa NSH-3001 Wi-Fi Smart Camera positioned on a nightstand in a bedroom, demonstrating a typical indoor placement.

- For wall mounting, use appropriate screws and anchors (not included) to secure the camera's base to the wall.
- Adjust the camera's angle to cover the desired area.

OPERATING INSTRUCTIONS

Live View and Remote Access

Once connected, you can access your camera's live feed from anywhere using the Smart Life app on your smartphone.

- Open the Smart Life app and select your NSH-3001 camera from the device list.
- The live video stream will appear.

Two-Way Audio Communication

The camera supports two-way audio, allowing you to hear and speak through the camera.

- In the live view interface of the app, tap the microphone icon to speak.
- Tap the speaker icon to listen to audio from the camera's location.

Motion Detection and Alerts

The camera can detect motion and send real-time push notifications to your phone.

- Navigate to the camera settings within the Smart Life app.
- Enable "Motion Detection" and adjust sensitivity levels as needed.
- Configure alert schedules and notification preferences.

Night Vision

The NSH-3001 features an IR-cut filter for clear night vision, automatically switching between day and night modes based on ambient light.

- Night mode activates automatically in low-light conditions.
- The IR-cut filter ensures optimal clarity in both day and night recordings.

Video Recording and Storage

The camera supports 24/7 HD recording. Footage can be stored locally or via cloud service (subscription may be required).

- **Micro SD Card Storage:** Insert a compatible Micro SD card (up to 128GB, not included) into the camera's SD card slot for continuous or event-based recording.
- **Cloud Storage:** Check the Smart Life app for available cloud storage options and subscription details.
- Review recorded footage directly through the Smart Life app.

Video Tuning

Adjust video parameters directly from your smartphone for optimal image quality.

- Within the Smart Life app, access video settings to adjust contrast, brightness, saturation, and sharpness.

Time Scheduling

Set schedules for camera operation, recording, or alerts.

- Use the Smart Life app's scheduling feature to define specific times for motion detection, recording, or other functions.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Naxa NSH-3001 Wi-Fi Smart Camera.

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Software Updates:** Regularly check the Smart Life app for firmware updates for your camera. Keeping the firmware updated ensures you have the latest features and security enhancements.
- **Placement:** Ensure the camera is placed in a stable location and protected from extreme temperatures, direct sunlight, and moisture.

TROUBLESHOOTING

If you encounter issues with your Naxa NSH-3001 Wi-Fi Smart Camera, refer to the following common solutions:

Problem	Possible Solution
Camera not connecting to Wi-Fi	<ul style="list-style-type: none">• Ensure your Wi-Fi network is 2.4 GHz.• Check Wi-Fi signal strength at the camera's location.• Restart your router and the camera.• Perform a factory reset on the camera and try pairing again.
No video feed in the app	<ul style="list-style-type: none">• Verify the camera is powered on and connected to Wi-Fi.• Check your internet connection on your smartphone.• Close and reopen the Smart Life app.
Motion alerts not received	<ul style="list-style-type: none">• Ensure motion detection is enabled in the app settings.• Check your phone's notification settings for the Smart Life app.• Adjust motion detection sensitivity.
Two-way audio not working	<ul style="list-style-type: none">• Check microphone and speaker permissions for the Smart Life app on your phone.• Ensure volume levels are adjusted correctly in the app and on your phone.

If problems persist, please contact Naxa customer support.

SPECIFICATIONS

Feature	Detail
Model Name	NSH-3001
Brand	Naxa
Connectivity Technology	Wi-Fi (2.4 GHz)
Video Capture Resolution	720p
Viewing Angle	105 Degrees

Feature	Detail
Special Feature	Motion Sensor, Night Vision, Two-Way Audio
Indoor/Outdoor Usage	Indoor, Outdoor (Note: IP54 rating suggests splash resistance, not full outdoor weatherproofing)
Power Source	Corded Electric
Compatible Devices	Smartphone (via Smart Life App)
Mounting Type	Wall Mount
Storage	Micro SD Card (up to 128GB, not included), Cloud Storage (optional)
Dimensions (L x W x H)	3.2 x 3.2 x 4.3 inches
Item Weight	3.2 ounces
Material	Plastic
International Protection Rating	IP54

WARRANTY AND SUPPORT

Naxa Electronics, Inc. manufactures the NSH-3001 Wi-Fi Smart Camera. For specific warranty information, please refer to the warranty card included with your product or visit the official Naxa website.

For technical support, troubleshooting assistance beyond this manual, or inquiries about your product, please contact Naxa customer service. Contact details can typically be found on the Naxa website or on the product packaging.

Naxa Official Website: www.naxa.com