

Midea MDG80C

Midea 8 kg Clothes Dryer MDG80C User Manual

Model: MDG80C

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Midea 8 kg Condensation Clothes Dryer, model MDG80C. Please read these instructions carefully before using the appliance and retain them for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the dryer is properly grounded.
- Do not dry articles that have been soiled with flammable substances.
- Keep the area around the exhaust opening and adjacent surrounding areas free from the accumulation of lint, dust, and dirt.
- Do not allow children to play on or in the appliance.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not install or store the appliance where it will be exposed to the weather.

3. PRODUCT OVERVIEW

The Midea MDG80C is an 8 kg capacity condensation clothes dryer designed for efficient and gentle drying of your laundry. It features multiple programs to suit various fabric types and drying needs.



Image Description: This image displays the Midea MDG80C clothes dryer. The front panel features a central control knob, a digital display, and buttons for program selection and settings. Below the control panel is the large circular door for the drum. At the bottom, there are two rectangular access panels, one for the condenser filter and the other for the lint filter.

4. INSTALLATION AND SETUP

Proper installation is crucial for the safe and optimal performance of your dryer.

4.1 Unpacking

- Remove all packaging materials and transport bolts.
- Inspect the dryer for any damage. If damaged, do not install or operate.

4.2 Positioning

- Place the dryer on a firm, level floor.
- Ensure adequate ventilation around the appliance.
- Do not block the air intake or exhaust vents.

4.3 Electrical Connection

- The dryer operates on **220 Volts**. Ensure your electrical supply matches this requirement.
- Connect the power cord to a properly grounded electrical outlet.

4.4 Condensate Drain

As a condensation dryer, it collects water in a reservoir. You can either manually empty the reservoir after each cycle or connect a drain hose for continuous drainage (if applicable to your model).

4.5 Professional Installation Support

For professional installation assistance, please contact the following numbers:

- Riyadh: +966 -11- 4094006 Ext – 113
- Jeddah: +966- 12- 6577714
- Dammam: +966-13- 8343691
- Qassim: +966 581044198
- Abha: +966 593322785

5. OPERATING INSTRUCTIONS

Follow these general steps to operate your Midea clothes dryer:

1. **Load Laundry:** Open the dryer door and load clothes, ensuring not to overload the drum. For best results, separate items by fabric type and weight.
2. **Close Door:** Firmly close the dryer door.
3. **Select Program:** Turn the program selection knob to choose the desired drying program. Refer to the control panel for specific program names and descriptions.
4. **Adjust Settings (Optional):** Depending on the selected program, you may be able to adjust settings such as drying level, anti-crease, or delay start.
5. **Start Cycle:** Press the Start/Pause button to begin the drying cycle.
6. **End of Cycle:** The dryer will signal when the cycle is complete. Remove laundry promptly to minimize wrinkling.
7. **Empty Water Tank/Clean Filter:** After each cycle, empty the condensate water tank (if not using direct drain) and clean the lint filter.

6. DRYING PROGRAMS

Your Midea MDG80C dryer offers 16 programs to cater to various fabric types and drying needs. While specific program names are detailed on the appliance's control panel, common programs typically include:

- Cotton (Extra Dry, Standard Dry, Iron Dry)
- Synthetics (Cupboard Dry, Iron Dry)
- Delicates
- Mix
- Refresh
- Timed Drying
- Sportswear
- Baby Care
- Jeans
- Quick Dry

Always consult the control panel or the full printed manual for the exact list and descriptions of the 16 available programs.

7. MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your dryer.

7.1 Cleaning the Lint Filter

The lint filter should be cleaned after every drying cycle. A clogged lint filter reduces drying efficiency and increases energy consumption.

1. Open the dryer door.
2. Pull out the lint filter, usually located inside the door opening.
3. Remove accumulated lint by hand or with a soft brush.
4. Reinsert the filter firmly.

7.2 Emptying the Condensate Water Tank

If you are not using the direct drain option, the water tank must be emptied after each cycle.

1. Pull out the water tank, typically located at the top left of the control panel.
2. Pour out the collected water.
3. Push the tank back into its position until it clicks.

7.3 Cleaning the Condenser Filter

The condenser filter, located behind a lower access panel, should be cleaned periodically (e.g., monthly or every 20-30 cycles) to maintain drying performance.

1. Open the lower access panel.
2. Unlock and remove the condenser filter.
3. Rinse the filter under running water to remove lint and debris.
4. Allow the filter to dry completely before reinserting.
5. Close the access panel.

7.4 Exterior Cleaning

Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.

8. TROUBLESHOOTING

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Dryer does not start	Power cord unplugged; Door not closed; Program not selected; Start button not pressed.	Check power connection; Ensure door is latched; Select a program; Press Start.
Clothes not drying properly	Lint filter clogged; Condenser filter clogged; Overloaded drum; Incorrect program selected.	Clean lint filter; Clean condenser filter; Reduce load size; Select appropriate program.
Water tank full indicator on	Condensate water tank is full.	Empty the water tank.
Unusual noise during operation	Foreign objects in drum; Dryer not level.	Check drum for objects; Adjust leveling feet.

9. SPECIFICATIONS

Detailed technical specifications for the Midea MDG80C Clothes Dryer:


- Brand:** Midea
- Model:** MDG80C
- Capacity:** 8 Kilograms
- Type:** Condensation Dryer
- Color:** White
- Form Factor:** Front Load
- Access Location:** Front Load
- Voltage:** 220 Volts
- Material:** Plastic, Stainless Steel
- Product Dimensions (D x W x H):** 59.5 cm x 61.5 cm x 84.5 cm
- Item Weight:** 43 Kilograms
- Number of Programs:** 16

10. WARRANTY AND SUPPORT

Your Midea MDG80C Clothes Dryer comes with a **2-year warranty**. For any warranty claims, technical support, or service requests, please contact Midea customer service or the authorized service centers.

For installation support, please refer to the contact numbers provided in Section 4.5 of this manual.

Related Documents - MDG80C

	<p><u>Midea Gas and Electric Clothes Dryer Owner's Manual</u></p> <p>Comprehensive owner's manual for Midea Gas and Electric Clothes Dryers, covering installation, operation, maintenance, and troubleshooting. Includes safety precautions and warranty information.</p>
	<p><u>Midea Dryer User Manual and Installation Instructions</u></p> <p>Comprehensive user manual and installation guide for the Midea MLE52N4AWW dryer, covering safety, operation, installation, care, and troubleshooting.</p>
	<p><u>Midea MDG09EH80 Tumble Dryer User Manual</u></p> <p>Comprehensive user manual for the Midea MDG09EH80 Tumble Dryer. This guide provides detailed instructions on safety precautions, installation, operation, maintenance, and troubleshooting for your Midea tumble dryer.</p>
	<p><u>Midea Dryer MLE27N5AWWC User Manual and Installation Guide</u></p> <p>Official user manual and installation instructions for the Midea MLE27N5AWWC dryer. Covers safety, setup, operation, care, and troubleshooting for Midea home appliances.</p>
	<p><u>Midea Dryer User Manual & Installation Instructions</u></p> <p>Comprehensive user manual and installation guide for the Midea MLE47R5BWW clothes dryer, detailing safety precautions, operational procedures, installation requirements, maintenance tips, and troubleshooting solutions.</p>
	<p><u>Midea MD200H80WB/W-UK Tumble Dryer User Manual</u></p> <p>Comprehensive user manual for the Midea MD200H80WB/W-UK tumble dryer, detailing safety precautions, installation steps, operation guides, maintenance procedures, troubleshooting, technical specifications, and product fiches.</p>

