Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Gigaset /
- > Gigaset A695 Duo DECT Cordless Phone User Manual

Gigaset L36852-H2814-N153

Gigaset A695 Duo DECT Cordless Phone User Manual

Model: A695 Duo

1. Introduction

This manual provides comprehensive instructions for the Gigaset A695 Duo DECT Cordless Phone. It covers essential information regarding setup, daily operation, maintenance, and troubleshooting to ensure you get the most out of your device. Please read this manual carefully before using your phone.



Figure 1.1: Gigaset A695 Duo Cordless Phone System

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1x Gigaset A695 Base Station
- 2x Gigaset A695 Handsets
- 2x Power Supply Units
- 1x Telephone Connection Cable
- 4x AAA NiMH Rechargeable Batteries
- 2x Battery Covers
- 1x User Guide (this document)




Figure 2.1: Included Components

3. SETUP INSTRUCTIONS

Follow these steps to set up your Gigaset A695 Duo phone system:

- 1. **Install Batteries:** Open the battery compartment on each handset and insert the provided AAA NiMH rechargeable batteries, observing the correct polarity. Close the battery compartment.
- 2. Connect Base Station:
 - Connect the power supply unit to the base station and plug it into a wall outlet.
 - Connect the telephone connection cable to the base station and then to your wall telephone socket or router.
- 3. **Charge Handsets:** Place both handsets on their respective base stations or charging cradles. The handsets will begin charging automatically. Allow them to charge for at least 6 hours before first use to ensure optimal battery performance.




Figure 3.1: Base Station Connection Options

Note: The Gigaset A695 is designed for use in France. Available functions may vary depending on your router or the base station to which the product is connected.

4. OPERATING INSTRUCTIONS

4.1 Basic Functions

- Making Calls: Enter the phone number and press the green call button.
- Answering Calls: Press the green call button when the phone rings.
- Ending Calls: Press the red end call button.
- Hands-Free Function: During a call, press the hands-free button (speaker icon) to activate speakerphone
 mode.

Optimisé pour la France* : Les fonctions varient selon le routeur et la station de base



Plus d'informations sur le site de Gigaset.

Figure 4.1: Hands-Free Calling

4.2 Key Features

- **High-Contrast Display:** The large, high-contrast display ensures optimal readability, especially with extralarge digits in dialing mode.
- Volume Adjustment: Adjust the call volume to one of 5 available levels using the navigation keys during a call.
- **Phonebook:** Store up to 100 contacts in the phonebook. Access it via the 'Menu' button and navigate to 'Phonebook'.
- Call Protection: Block up to 32 unwanted numbers. This feature helps prevent nuisance calls. Refer to the menu for 'Call Blocking' or 'Blacklist' options.

Technologie ECO DECT -Pour une consommation d'énergie réduite







Figure 4.2: Key Features Overview

5. MAINTENANCE

To ensure the longevity and optimal performance of your Gigaset A695 Duo, follow these maintenance guidelines:

- Cleaning: Clean the handsets and base station with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** Use only the recommended NiMH rechargeable batteries. If the phone will not be used for an extended period, remove the batteries.
- **ECO DECT Technology:** Your Gigaset A695 features ECO DECT technology, which reduces energy consumption and transmitting power. This contributes to a more environmentally friendly operation.

Contenu de la livraison -Qu'est-ce qui est inclus dans ton colis ?




Figure 5.1: ECO DECT for Reduced Energy Consumption

6. TROUBLESHOOTING

If you encounter issues with your Gigaset A695 Duo, try the following solutions:

Problem	Possible Solution	
No dial tone	Check if the telephone cable is securely connected to both the base station and the wall socket/router. Ensure the power supply is connected.	
Handset not charging	Ensure the handset is correctly placed on the base station/charging cradle. Check that the power supply is connected to the base station and the outlet. Clean the charging contacts on both the handset and base.	
Poor sound quality	Move closer to the base station. Check for interference from other electronic devices. Ensure batteries are sufficiently charged.	

Problem	Possible Solution
Display always on (even on base)	This is a characteristic of some Gigaset models. If you wish to turn off the display, remove the handset from the base. For night use in a bedroom, consider placing the handset off the base or deactivating it temporarily (consult advanced settings in the menu).
Cannot make/receive calls	Check if the handset is registered to the base station. Restart the base station by unplugging and replugging the power. Verify your phone line is active.

If the problem persists after trying these solutions, please contact Gigaset customer support.

7. SPECIFICATIONS


Feature	Detail
Model Number	L36852-H2814-N153
Connectivity Technology	DECT
Special Features	Cordless, Hands-free function, Call blocking
Handset Dimensions (L x W x H)	4.9 x 2.8 x 15.5 cm
Handset Weight	119 g
Batteries	4x AAA NiMH (included)
Standby Time	Up to 200 hours
Talk Time	Up to 18 hours
Phonebook Capacity	100 contacts
Call Blocking Capacity	Up to 32 numbers
Display	High-contrast, backlit graphic display
Color	Grey
Material	Acrylonitrile Butadiene Styrene (ABS)
Origin	Germany

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or visit the official Gigaset website. For technical support, product registration, or to download the latest version of this manual, please visit the Gigaset support page or contact their customer service directly.

Gigaset Official Website: www.gigaset.com

Related Documents - L36852-H2814-N153





Gigaset R700H PRO Cordless Phone: Safety, Specifications, and Warranty Information

Comprehensive guide to the Gigaset R700H PRO cordless phone, covering safety precautions, technical specifications, warranty details, and manufacturer's advice. Learn about installation, usage, and care.