

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Anne Klein](#) /

› [Anne Klein Women's Bracelet Watch Gold \(Model 086702705429\) Instruction Manual](#)

Anne Klein 086702705429

Anne Klein Women's Bracelet Watch Gold Instruction Manual

Model: 086702705429

INTRODUCTION

This manual provides comprehensive instructions for the Anne Klein Women's Bracelet Watch Gold, Model 086702705429. Please read this guide carefully to ensure proper use and care of your timepiece. This watch features a gold-tone finish, an octagonal case, and a light champagne dial with gold-tone hands and markers.




Image: Front view of the Anne Klein Women's Bracelet Watch Gold, showcasing its octagonal case and bracelet.

SETUP

1. Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any visible damage.



Image: The Anne Klein watch presented within its branded box, ready for unboxing.

2. Adjusting the Bracelet

The watch bracelet is designed with an extender link that can be removed to adjust the fit. This can typically be done without specialized tools. For precise adjustments or if you encounter difficulty, consult a professional jeweler.



Image: An illustration showing the Anne Klein watch worn on a wrist, demonstrating its fit.

3. Setting the Time

1. Pull the crown (the small knob on the side of the watch) gently outwards until you feel a click.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.



Image: Side view of the watch, highlighting the crown used for time adjustment.

OPERATING

Your Anne Klein watch is a quartz movement timepiece designed for accurate timekeeping. Once the time is set, the watch will operate continuously until the battery requires replacement.

MAINTENANCE

1. Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, which can damage the finish.

2. Water Resistance

This watch is water resistant to 100 feet (30 meters). This means it can withstand splashes or brief immersion in water, but it is not suitable for swimming, bathing, or diving. Avoid operating the crown while the watch is wet.





WATER RESISTANT CHART	
 NOT WATER RESISTANT	NOT WATER RESISTANT
 ACCIDENTAL SPLASHES	WATER RESISTANT TO 30M (100FT): In general, withstands splashes or brief immersion in water, but not suitable for swimming or bathing
 SWIMMING	WATER RESISTANT TO 50M (165FT): In general, suitable for short periods of recreational swimming, but not diving or snorkeling
 SNORKELING	WATER RESISTANT TO 100 M (330 FT): In general, suitable for swimming and snorkeling, but not scuba diving

Image: A chart illustrating different levels of watch water resistance, indicating that 30M (100FT) is suitable for accidental splashes but not swimming.

3. Battery Replacement

When the watch stops running, the battery may need to be replaced. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is maintained.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Time Inaccurate:** Ensure the crown is fully pushed in after setting the time. If the issue persists, the watch may require servicing.

SPECIFICATIONS

Feature	Detail
Model Number	086702705429
Case Diameter	24mm (1 inch)
Band Width	14mm
Band Length	7 inches (with removable extender link)
Dial Color	Light champagne
Hands and Markers	Gold-tone
Bracelet Material	Gold-tone mixed metals
Case Back Material	Stainless steel
Water Resistance	100 feet (30M)
Nickel Free	Yes
Manufacturer	Anne Klein



Image: Back view of the watch, showing the stainless steel case back and manufacturer markings.

WARRANTY AND SUPPORT

For information regarding warranty coverage or to seek support for your Anne Klein watch, please refer to the warranty card included with your purchase or visit the official Anne Klein website. The manufacturer is Anne Klein.

