

JMEXSUSS EXS-S-0100

JMEXSUSS 33ft 100 LED Color Changing String Lights

MODEL: EXS-S-0100

[Introduction](#)

[Safety Information](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Specifications](#)

[Support](#)

1. Introduction

Thank you for choosing JMEXSUSS 33ft 100 LED Color Changing String Lights. This product offers versatile lighting options with both warm white and multicolor settings, suitable for various indoor and outdoor decorative purposes. The upgraded LED beads provide higher brightness and a softer glow. This manual provides essential information for safe and effective use.

What's in the Box:

- 1x 100 LED Color Changing Christmas String Lights
- 1x UL Plug
- 1x Remote Control
- 1x Instructions Manual

2. Safety Information

- Ensure the product is in good condition before use.
- Keep away from fire or corrosive materials.
- The string lights are Waterproof (IPX rated) for outdoor use, but the UL Plug should be protected from direct water exposure. Plug into a safe and dry spot.
- Do not mix or connect this product with lights from other brands.
- This product has passed UL588 safety certification.

3. Setup Instructions

1. **Unpack the Lights:** Carefully unroll the string lights from the spool. Ensure the wires are not tangled.
2. **Connect to Power:** Plug the UL certified adapter into a standard electrical outlet.
3. **Placement:** Arrange the lights as desired for your indoor or outdoor decoration. The clear wire design helps them blend seamlessly.
4. **Connecting Multiple Strings:** These string lights are connectable. You can expand up to a maximum of 10 light chains (from 100 LED to 1000 LED) by connecting them end-to-end. Ensure all connections are secure and protected from moisture if used outdoors.




Image: Multiple JMEXSUSS string lights connected for extended coverage, illustrating the connectable feature.

4. Operating Instructions

The JMEXSUSS string lights can be operated using the included remote control or the button on the UL plug.

Remote Control Functions:

- **ON/OFF:** Power the lights on or off.
- **Timer Settings:**
 - **6H:** Lights on for 6 hours, then off for 18 hours.
 - **8H:** Lights on for 8 hours, then off for 16 hours.
 - **6639H:** Lights on for 6 hours, off for 6 hours, on for 3 hours, then off for 9 hours.

- **Brightness Adjustment (DIM+/-):** Adjust brightness to 100%, 75%, 50%, or 25%.
- **Lighting Modes (1-11):** Select from 11 impressive lighting modes: Comb, C1 Steady ON, C2 Steady ON, C1 Mixture, C2 Mixture, Slo-Glo, Breathing, C1 Slo Glo, C2 Slo Glo, Flash, In Wave.

Manual Button Operation:

Press the button on the UL plug to cycle through the available lighting modes. This button does not control dimming or timer functions.



LIGHTING MODES & COLOR CHANGING

<input type="radio"/> Comb	<input type="radio"/> C2 Mixture	<input type="radio"/> C2 Slo-Glo
<input type="radio"/> C1 Steady ON	<input type="radio"/> Slo-Glo	<input type="radio"/> Slow Fade
<input type="radio"/> C2 Steady ON	<input type="radio"/> Breathing	<input type="radio"/> In Wave
<input type="radio"/> C1 Mixture	<input type="radio"/> C1 Slo-Glo	



Image: Two Christmas trees illuminated by JMEXSUSS string lights, demonstrating the warm white and multicolor changing modes and a list of 11 lighting options.

100%-75%-50%-25% BRIGHTNESS DIMMABLE



Image: A child's teepee tent decorated with JMEXSUSS string lights, illustrating the 100%, 75%, 50%, and 25% dimmable brightness levels.

Video: Official product video from JMEXSUSS showcasing various lighting modes and colors of the string lights, suitable for Christmas decorations.

5. Maintenance

- **Cleaning:** Disconnect from power before cleaning. Wipe the lights gently with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully wrap the string lights around the provided spool or a similar organizer to prevent tangling. Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the lights and wiring for any damage. Do not use if any part is damaged.



Image: A hand demonstrating how to wind the JMEXSUSS string lights onto a spool for neat storage, highlighting the ease of organization.

Video: A seller-provided video demonstrating the various light modes and options for the JMEXSUSS LED Christmas String Lights, including dimming and twinkling effects.

6. Troubleshooting

- **Lights Not Turning On:**

- Ensure the UL plug is securely connected to a working power outlet.
- Check if the remote control battery needs replacement.
- Verify that the ON button on the remote or the manual button on the plug has been pressed.

- **Remote Control Not Responding:**

- Ensure the remote is pointed directly at the transformer/plug.
- Replace the remote control battery if necessary (CR2025 type).

- **Inconsistent Lighting:**

- If connecting multiple strings, ensure all connections are firm.
- Avoid over-stretching the lights, which can damage internal wiring.

7. Specifications

Feature	Detail
Brand	JMEXSUSS
Model Number	EXS-S-0100
Light Color	Warm White to Multicolor
Number of LEDs	100
Item Length	33 Feet
Power Source	Corded Electric
Special Feature	Color Changing, Dimmable, Timer, Remote Control, Connectable
Indoor/Outdoor Usage	Indoor/Outdoor
Water Resistance Level	Waterproof (IPX)
Material Type	Plastic
Certifications	UL588

Video: A seller-provided video detailing the measurements of the JMEXSUSS LED Christmas String Lights, including the length of the cord and spacing between bulbs.

8. Warranty & Support

If you encounter any problems with your JMEXSUSS 33ft 100 LED Color Changing String Lights, please do not hesitate to contact us. Our customer support team is ready to assist you.

Contact Information:

- **Email:** service@jmexsuss.com
- **Facebook:** [JMEXSUSS](#)