

- Manuals.plus /
- › Klarstein /
 - › Klarstein Beersafe XXL 80L Mini Refrigerator Instruction Manual

Klarstein Beersafe XXL

Klarstein Beersafe XXL 80L Mini Refrigerator

Model: Beersafe XXL | Brand: Klarstein

			Introduction	Safety			
Information	Setup	Operation	Maintenance	Troubleshooting	Specifications	Warranty	Support

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Klarstein Beersafe XXL 80L Mini Refrigerator. Please read these instructions carefully before installation and operation, and retain them for future reference.

The Klarstein Beersafe XXL is a compact beverage cooler designed for various indoor and outdoor settings, offering an 80-liter capacity, adjustable shelves, and quiet operation. It features a glass door and a temperature range of 3-10°C.



Figure 1: Klarstein Beersafe XXL 80L Mini Refrigerator. This image shows the compact design and glass door of the refrigerator.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstructions.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit. The appliance uses R600a refrigerant, which is environmentally friendly but flammable.

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended for household use and similar applications.
- Supervise children to ensure they do not play with the appliance.
- Unplug the appliance before cleaning or performing maintenance.


3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove the refrigerator from its packaging. Inspect the appliance for any damage during transit. Keep packaging materials out of reach of children.

3.2 Placement

Place the refrigerator on a firm, level surface. Use the height-adjustable feet to ensure stability and proper leveling. Allow adequate space around the appliance for proper ventilation (at least 10 cm on sides and back). Avoid direct sunlight or heat sources (e.g., ovens, radiators) as this can affect cooling performance and energy consumption. This appliance is designed for indoor use, but its robust construction allows for use in covered outdoor areas like patios, provided it is protected from direct weather exposure.



A SPACE-SAVING MIRACLE

With 80 litres of volume



Figure 2: The Klarstein Beersafe XXL is a space-saving appliance suitable for various environments such as bedrooms, kitchens, and offices.

3.3 Handle Installation

The door handle may require assembly. Align the handle with the pre-drilled holes on the door and secure it with the provided screws. Ensure the screws are tightened firmly but do not overtighten.

3.4 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and a mild detergent. Rinse with clean water and dry thoroughly.

3.5 Power Connection

After placement and cleaning, wait at least 2-4 hours before plugging the appliance into a power outlet. This allows the refrigerant to settle. Connect the power plug (Type C) to a grounded 220-240V~ | 50/60 Hz electrical outlet.

4. OPERATION

4.1 Temperature Control

The refrigerator features an adjustable temperature control knob, typically located inside the unit. The temperature range is between 3°C and 10°C. Turn the knob to your desired setting. A lower number indicates a warmer temperature, while a higher number indicates a colder temperature. For initial use, it is recommended to set it to a medium setting (e.g., '3' or '4') and adjust as needed.



HIGHLIGHT
LED interior lighting



CRYSTAL CLEAR
Elegant drinks refrigerator
with double-insulated
panorama glass door



Figure 3: Interior view showing the temperature control dial and LED lighting. Adjust the dial to set the desired cooling level.

4.2 Loading the Refrigerator

The Beersafe XXL comes with 3 removable glass shelves, allowing for flexible storage of various bottle and can sizes. Arrange items to allow for proper air circulation. Avoid overloading the shelves.



EYE-CATCHER

Snow-white interior



HIGH QUALITY

Stainless steel front
and handle



Figure 4: The interior of the refrigerator with beverages arranged on the adjustable shelves. The snow-white interior enhances visibility.

4.3 LED Interior Lighting

The refrigerator is equipped with LED interior lighting to illuminate the contents. This light can typically be controlled via a switch, allowing you to turn it on or off as desired. The LED light is designed to be energy-efficient.



Figure 5: The refrigerator with its LED interior lighting activated, highlighting the stored beverages through the glass door.

5. MAINTENANCE

5.1 Cleaning

- Always unplug the refrigerator before cleaning.
- Clean the interior regularly with a soft cloth and a mild, non-abrasive detergent.
- The removable shelves can be washed with warm soapy water. Ensure they are completely dry before placing them back in the unit.
- Wipe the exterior with a soft, damp cloth. For stainless steel surfaces, use a specialized stainless steel cleaner if necessary.
- Clean the door gasket regularly to ensure a proper seal.
- Do not use harsh chemicals, abrasive cleaners, or sharp objects for cleaning, as these can damage the surfaces.

5.2 Defrosting

This refrigerator features a frost-free defrost system, meaning manual defrosting is generally not required. However, if ice buildup occurs due to frequent door opening or high humidity, unplug the unit and allow the ice to melt naturally. Wipe away any melted water.

5.3 Power Outage

In case of a power outage, keep the refrigerator door closed to maintain the internal temperature for as long as possible. Avoid opening the door unnecessarily.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power supply. Power cord not properly plugged in. Circuit breaker tripped.	Check if the appliance is plugged in. Check the power outlet. Reset the circuit breaker.
Refrigerator is not cold enough.	Temperature setting is too high (warm). Door is opened too frequently or not sealed properly. Excessive amount of warm items placed inside. Poor ventilation around the unit.	Adjust the temperature control to a colder setting. Ensure the door is closed tightly and the gasket is clean. Allow warm items to cool before placing them in the refrigerator. Ensure adequate space for air circulation.
Unusual noises.	Appliance is not level. Items inside are rattling. Normal compressor operation.	Adjust the leveling feet. Rearrange items to prevent rattling. A slight humming or gurgling sound from the compressor and refrigerant is normal.
LED light is dim or not working.	Light switch is off. Light is obstructed by contents.	Check the LED light switch. Rearrange contents to allow light to spread.

7. PRODUCT SPECIFICATIONS

Brand	Klarstein
-------	-----------

Model Name	Beersafe XXL
Model Number	HEA-BeersafeXXL-Crys
Capacity	80 Liters
Configuration	Compact without freezer
Color	Silver, White
Installation Type	Freestanding
Number of Doors	1
Defrost System Type	Frost-free
Voltage	220-240 Volts
Shelf Type	Glass
Cooling Method	Compressor
Number of Shelves	3
Adjustable Temperature Control	Yes
Power Plug Type	Type C
Door Opening Direction	Left to Right
Refrigerant	R-600A
Finish Type	Stainless Steel
Door Material Type	Glass, Stainless Steel
Item Dimensions (D x W x H)	5 cm x 48 cm x 83 cm
Item Weight	30 Kilograms
Annual Energy Consumption	70 Kilowatt-hours per year
Max Depth with Door Open	48 Centimeters

8. WARRANTY INFORMATION

Klarstein products are covered by a manufacturer's warranty. The specific terms and duration of your warranty may vary depending on your region and the point of purchase. Please retain your proof of purchase for any warranty claims. For detailed warranty information, please refer to the warranty card included with your product or visit the official Klarstein website.

9. CUSTOMER SUPPORT

Should you encounter any issues or have questions regarding your Klarstein Beersafe XXL Mini Refrigerator, please contact our customer support team.

- **Online Support:** Visit the official Klarstein website for FAQs, troubleshooting guides, and contact forms.
- **Email:** Refer to your product documentation for the appropriate email address.
- **Phone:** Contact numbers for your region can be found on the Klarstein website or in your product's warranty

information.

When contacting support, please have your model number (Beersafe XXL) and purchase details readily available.

© 2023 Klarstein. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09WRQR2V2>

More documents and user manuals: <https://manuals.plus/>