

[manuals.plus](#) /› [ATTOP](#) /› [ATTOP W10 Camera Drone Battery Instruction Manual](#)

## ATTOP W10

# ATTOP W10 Camera Drone Battery Instruction Manual

## 1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your ATTOP W10 Camera Drone Battery. Please read this manual thoroughly before using the battery to ensure proper operation, extend battery life, and prevent damage or injury. Keep this manual for future reference.

## 2. SAFETY INFORMATION

Always prioritize safety when handling and using batteries. Failure to follow these guidelines may result in fire, personal injury, or property damage.

- **Charging:** Use only the original or manufacturer-approved charger designed for the ATTOP W10 drone battery. Do not charge unattended.
- **Storage:** Store the battery in a cool, dry place away from direct sunlight, heat sources, and flammable materials. Keep out of reach of children and pets.
- **Handling:** Do not puncture, impact, or disassemble the battery. Avoid exposing the battery to water or extreme temperatures.
- **Disposal:** Dispose of used batteries responsibly according to local regulations. Do not dispose of batteries in household waste.
- **Damage:** If the battery appears damaged, swollen, or leaks, discontinue use immediately and dispose of it safely.

## 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x ATTOP W10 Camera Drone Battery

## 4. PRODUCT OVERVIEW

The ATTOP W10 Camera Drone Battery is a rechargeable power source specifically designed for the ATTOP W10 camera drone. It provides the necessary power for drone flight and camera operation. This battery is compact and lightweight, ensuring optimal performance for your drone.



Image showing the ATTOP W10 Camera Drone Battery, a rectangular black battery with a connector.

## 5. SETUP

### 5.1 Charging the Battery

1. Connect the battery to the designated charging cable provided with your ATTOP W10 drone.
2. Plug the charging cable into a suitable USB power adapter (e.g., 5V/1A) or a USB port on a computer.
3. Observe the charging indicator on the charger or drone (refer to your drone's manual for specific indicator behavior).
4. Once fully charged, disconnect the battery from the charger. Avoid overcharging.

### 5.2 Installing the Battery

1. Ensure the ATTOP W10 drone is powered off before installation.
2. Locate the battery compartment on your ATTOP W10 drone (refer to your drone's manual for exact location).
3. Carefully insert the battery into the compartment, ensuring the connectors align correctly.
4. Secure the battery in place and close the battery compartment cover.

## 6. OPERATING INSTRUCTIONS

Once the battery is charged and installed, you can power on your ATTOP W10 drone according to its specific operating instructions. The battery provides power for flight and camera functions. Monitor the drone's battery indicator during operation to avoid sudden power loss during flight.

## 7. MAINTENANCE

### 7.1 Battery Care

- Regular Charging:** Charge the battery fully before each use.
- Long-Term Storage:** If storing the battery for an extended period, charge it to approximately 50-60% capacity. Recharge every 3 months to prevent deep discharge.
- Cleaning:** Keep the battery contacts clean and free from dust or debris. Use a dry, soft cloth for cleaning.
- Temperature:** Avoid operating or storing the battery in extreme hot or cold conditions, as this can degrade performance and lifespan.

## 8. TROUBLESHOOTING

If you encounter issues with your ATTOP W10 Camera Drone Battery, consider the following:

- Battery Not Charging:** Ensure the charging cable and adapter are functioning correctly. Check for proper connection between the battery and charger.
- Short Flight Time:** This could indicate an aging battery or improper charging. Ensure the battery is fully charged before use. If the issue persists, the battery may need replacement.
- Drone Not Powering On:** Verify the battery is correctly installed and fully charged. Check the drone's power button and connections.

For further assistance, refer to your ATTOP W10 drone's main instruction manual or contact ATTOP customer support.

## 9. SPECIFICATIONS

Feature	Specification
Model Number	W10 (for drone compatibility)
Product Dimensions	2.2 x 2 x 1 inches
Item Weight	0.8 ounces
Reusability	Rechargeable
Unit Count	1.0 Count
Recommended Uses	Camera, Drone

## 10. WARRANTY AND SUPPORT

For warranty information and customer support regarding your ATTOP W10 Camera Drone Battery, please refer to the documentation included with your ATTOP W10 drone or visit the official ATTOP website. Keep

your purchase receipt as proof of purchase for any warranty claims.

**ATTOP Official Website:** [Visit the ATTOP Store on Amazon](#)

© 2024 ATTOP. All rights reserved. Information subject to change without notice.