

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Roca](#) /
- › [Roca Debba ROUND Rimless Toilet Bowl A34299P000 Instruction Manual](#)

Roca A34299P000

Roca Debba ROUND Rimless Toilet Bowl

Model: A34299P000

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Roca Debba ROUND Rimless Toilet Bowl, model A34299P000. This product is a floor-standing toilet bowl designed for use with a low-level cistern (cistern and seat are not included). The Rimless design ensures enhanced hygiene and easier cleaning.



Image 1: Front view of the Roca Debba ROUND Rimless Toilet Bowl. This image shows the white ceramic bowl with its round shape, designed for a modern bathroom.

SETUP AND INSTALLATION

The Roca Debba ROUND toilet bowl is designed for floor-standing installation. A fixing set is included with the product to secure it to the floor. Please ensure you have all necessary plumbing connections and a compatible low-level cistern and toilet seat, as these are not supplied with the toilet bowl.

Key Installation Considerations:

- **Type of Installation:** Floor-standing.
- **Output Type:** Dual (Vario) for flexible waste pipe connection.
- **Fixing Set:** Included for secure mounting.
- **Required Components (Not Included):** Low-level cistern and toilet seat.




Image 2: Technical drawing illustrating the dimensions and connection points of the Roca Debba ROUND toilet bowl. This diagram provides critical measurements for plumbing and installation planning, including width, depth, and height, as well as waste outlet positions.

Installation Steps (General Guidance):

1. Ensure the floor surface is level and clean where the toilet bowl will be installed.
2. Position the toilet bowl and mark the fixing points on the floor.
3. Drill holes according to the fixing set instructions.
4. Connect the waste pipe to the dual (vario) outlet of the toilet bowl.
5. Secure the toilet bowl to the floor using the provided fixing set.
6. Install the low-level cistern and connect it to the toilet bowl's water inlet.
7. Install the toilet seat according to its manufacturer's instructions.
8. Test for leaks and proper flushing operation.

OPERATING INSTRUCTIONS

The Roca Debba ROUND toilet bowl features a Rimless design and a drag flush system, ensuring efficient and hygienic operation.

Rimless Technology:

The Rimless design eliminates the traditional rim around the inside of the toilet bowl, where dirt and germs can accumulate. Water is flushed directly from the back of the bowl, ensuring a powerful and thorough rinse of the entire inner surface. This design significantly improves hygiene and simplifies cleaning.

Flushing:

To flush the toilet, activate the flush mechanism on your installed low-level cistern. The drag flush system will efficiently clear the bowl. Ensure the cistern is properly filled for optimal flush performance.

MAINTENANCE AND CLEANING

Regular cleaning and proper maintenance will ensure the longevity and hygienic performance of your Roca Debba ROUND toilet bowl.

Cleaning the Bowl:

- Use mild, non-abrasive cleaning agents and a soft cloth or sponge.
- Avoid harsh chemicals, abrasive cleaners, scouring pads, or wire brushes, as these can damage the surface finish.
- Due to the Rimless design, cleaning the inside of the bowl is easier. Simply wipe down the entire inner surface.
- Rinse thoroughly with clean water after cleaning.

General Maintenance:

- Periodically check all connections for leaks. Tighten if necessary, but do not overtighten.
- Inspect the fixing points to ensure the toilet bowl remains stable.
- For issues related to flushing, refer to the instruction manual of your cistern.

TROUBLESHOOTING

This section addresses common issues you might encounter. For problems related to the cistern or seat, please consult their respective manuals.

Weak Flush:

- **Check water supply:** Ensure the water supply valve to the cistern is fully open.
- **Cistern water level:** Verify that the cistern is filling to the correct level. Adjust the float mechanism if needed (refer to cistern manual).
- **Blockage:** A partial blockage in the waste pipe can reduce flush effectiveness. Consider using a plunger or contacting a plumber.

Leaks Around the Base:

- **Loose fixings:** Check if the toilet bowl is securely fastened to the floor. Tighten the fixing bolts if loose.
- **Seal integrity:** The wax ring or rubber seal between the toilet bowl and the waste pipe might be compromised. This usually requires removing the toilet and replacing the seal. It is recommended to contact a professional plumber for this.
- **Cracked bowl:** Inspect the ceramic for any visible cracks. If a crack is found, the bowl will need to be replaced.

Persistent Stains:

- For hard water stains, use a descaling toilet cleaner specifically designed for ceramic surfaces. Follow product instructions carefully.
- Ensure regular cleaning to prevent stain buildup.

SPECIFICATIONS

Feature	Specification
Model Number	A34299P000

Brand	Roca
Product Type	Rimless Toilet Bowl
Installation Type	Floor-standing
Shape	Round
Color	White
Material	Plastic (Note: Typically toilet bowls are ceramic. This specification is as provided in source data.)
Overall Dimensions (W x D x H)	350 mm x 655 mm x 760 mm (approximate, including space for cistern)
Bowl Dimensions (W x D x H)	355 mm x 655 mm x 400 mm (to rim)
Product Weight	22 kg
Flush System	Drag Flush
Output Type	Dual (Vario)
Components Included	Toilet bowl, Fixing set
Components Not Included	Cistern, Toilet Seat

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact Roca customer service directly. Keep your proof of purchase for any warranty claims.

For technical support or further assistance, please visit the official Roca website or contact your retailer.

You can also visit the Roca brand store for more products and information:[Roca Brand Store](#)