

[Manuals.plus](#) /

› [Phinistec](#) /

› Phinistec Z6 MP3 Player User Manual

Phinistec Z6

Phinistec Z6 MP3 Player User Manual

Model: Z6

INTRODUCTION

Welcome to the user manual for your Phinistec Z6 MP3 Player. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your device. Please read this manual carefully to ensure optimal performance and longevity of your MP3 player.

The Phinistec Z6 is a versatile digital audio player featuring Bluetooth 5.0 connectivity, a loud built-in speaker, a 2.4-inch IPS display, and ample storage capacity. It supports various audio and video formats, FM radio, and voice recording.

1. SETUP

1.1 Unboxing and Initial Inspection

Upon receiving your Phinistec Z6 MP3 Player, carefully open the packaging and inspect all included components. Ensure the following items are present:

- 1x Phinistec Z6 MP3 Player
- 1x 64GB SD Card (pre-installed or separate, depending on package)
- 1x Type-C Charging Cable
- 1x USB C Converter
- 2x Screen Protectors
- 1x User Manual (this document)



Image: The Phinistec Z6 MP3 Player, showcasing its sleek design and the various ports and buttons. The device is black with a glass front and back, and a metal body. It has a 2.4-inch IPS display.

1.2 Charging the Device

Before first use, fully charge the MP3 player. Connect the provided Type-C charging cable to the device's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status. A full charge can provide up to 90 hours of continuous music playback.

Bluetooth 5.0



Image: A close-up view of the Phinistec Z6 MP3 Player's side, highlighting the Type-C charging port and the physical volume buttons. The screen displays the battery icon with a charging symbol.

1.3 Inserting/Expanding Memory

The Phinistec Z6 comes with 32GB of internal storage and a 64GB SD card, totaling 96GB. The device supports expandable memory up to 256GB via the microSD card slot. To insert an SD card, locate the card slot on the side of the player and gently push the card in until it clicks into place. Ensure the card is formatted to FAT32 for optimal compatibility.

Built-in 32GB+64GB Memory Card



90 Hours Playing



256GB TF Card Support



Up to 8000 Songs



1500mAh



Image: The Phinistec Z6 MP3 Player with various microSD cards (64GB, 128GB, 256GB) laid out, illustrating its expandable memory capability. The player's screen shows icons related to storage and battery life.

2. OPERATING THE DEVICE

2.1 Power On/Off

To power on the device, press and hold the **Power** button located on the top right side until the screen illuminates. To power off, press and hold the **Power** button again until the power-off prompt appears, then confirm.

2.2 Navigation and User Interface

The Phinistec Z6 features a 2.4-inch IPS display with touch screen functionality and physical buttons for navigation. Use the touch screen to select icons and options, and the physical buttons for volume control and basic playback functions.

Our Z6 Player



Other MP3



VS

- ✔ Metal body & Glass back
- ✔ Built-in 32GB storage
- ✔ Support 256GB micro SD
- ✔ Loud speaker
- ✔ Up to 90hours playing

- ✘ Plastic or others
- ✘ No internal storage
- ✘ Support 32GB only
- ✘ No speaker
- ✘ 50hours or less

Image: The Phinistec Z6 MP3 Player displaying its main menu interface, which includes icons for Music, Folder, FM Radio, Bluetooth, Recorder, and E-Book. Physical buttons for volume and navigation are visible on the side and bottom.

2.3 Music Playback

From the main menu, select the **Music** icon to access your audio files. You can browse by artist, album, genre, or folder. The player supports various audio formats including APE, FLAC, MP3, OGG, AAC, ACELP, WMA, and WAV. Adjust volume using the **Vol+** and **Vol-** buttons on the side.

Built-in Loud Speaker



Image: The Phinistec Z6 MP3 Player with sound waves emanating from its built-in speaker, indicating active audio playback. The screen shows the music playback interface with album art and track information.

2.4 Bluetooth Connectivity

The Z6 features Bluetooth 5.0 for wireless audio streaming. To connect to Bluetooth headphones, speakers, or car audio:

1. From the main menu, select the **Bluetooth** icon.
2. Turn on Bluetooth.
3. The player will scan for available devices. Select your desired device from the list to pair.
4. Once paired, audio will be routed through the connected Bluetooth device.

Metal Body & Glass Back



Image: The Phinistec Z6 MP3 Player displaying the Bluetooth menu on its screen, with a large Bluetooth symbol next to it, indicating its wireless connectivity feature.

2.5 Other Functions

The Phinistec Z6 offers several other functions:

- **FM Radio:** Access local radio stations. A wired earphone can act as an antenna.
- **Voice Recorder:** Record audio using the built-in microphone.
- **E-Book:** Read text files.
- **Video Playback:** Supports AMV and AVI formats. Videos may need conversion for optimal playback.
- **Alarm Clock:** Set alarms.
- **Photo Viewer:** View image files.

Multi-Function



Image: The Phinistec Z6 MP3 Player surrounded by icons representing its various functions: Bluetooth, Calendar, Recorder, Alarm Clock, Photo, Music, E-Book, and FM Radio. The player's screen shows a menu with Video and Photo options.

3. MAINTENANCE

3.1 Cleaning

To clean the device, use a soft, dry, lint-free cloth. For stubborn smudges on the screen, a slightly damp cloth with water can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the screen and finish.

3.2 Storage

When not in use for extended periods, store the MP3 player in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the device to about 50% before long-term storage to preserve battery health.

3.3 Battery Care

The Phinistec Z6 is equipped with a 1500mAh battery. To maximize battery lifespan, avoid fully discharging the battery frequently. Charge the device regularly and avoid leaving it connected to power for excessively long periods after it is fully charged.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery; System crash.	Charge the device for at least 30 minutes. If unresponsive, press and hold the Power button for 10-15 seconds to force a restart.
Cannot connect to Bluetooth device.	Bluetooth is off; Device not in pairing mode; Interference.	Ensure Bluetooth is enabled on both devices. Put the receiving device into pairing mode. Move closer to the Bluetooth device and away from other wireless interference sources.
No sound from speaker/headphones.	Volume too low; Headphones not properly connected; Corrupted audio file.	Increase volume. Ensure headphones are fully plugged in. Test with a different audio file. If using Bluetooth, ensure it's connected.
Cannot transfer files.	Incorrect USB connection mode; Driver issues; Corrupted storage.	Ensure the device is connected to the computer in data transfer mode. Try a different USB port or cable. Reformat the SD card (backup data first).

5. SPECIFICATIONS

Feature	Detail
Brand	Phinistec
Model Name	Z6
Memory Storage Capacity	96 GB (32GB internal + 64GB SD card)
Expandable Memory	Up to 256GB via MicroSD card
Connectivity Technology	Bluetooth 5.0, 3.5mm Jack, USB-C
Screen Size	2.4 Inches IPS Display
Battery Capacity	1500mAh
Continuous Music Playback	Up to 90 hours
Supported Audio Formats	APE, FLAC, MP3, OGG, AAC, ACELP, WMA, WAV
Supported Video Formats	AMV, AVI
Special Features	Loud Speaker, FM Radio, Voice Recorder, E-Book, Alarm Clock, Photo Viewer, Equalizer
Dimensions (Approx.)	102mm (4.0") x 60mm (2.36") x 14mm (0.55")



Image: The Phinistec Z6 MP3 Player shown with its approximate dimensions: 102mm (4.0 inches) in length, 60mm (2.36 inches) in width, and 14mm (0.55 inches) in thickness, highlighting its compact size.

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Phinistec products are designed for durability and performance. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or contact Phinistec customer support. Keep your purchase receipt as proof of purchase for warranty claims.

6.2 Customer Support

If you encounter any issues or have questions regarding your Phinistec Z6 MP3 Player, please contact our customer support team. We are committed to providing excellent service and assistance.

For firmware updates or technical inquiries, the manufacturer welcomes feedback and ideas for improvement. Please reach out to the Phinistec Team directly.

Contact information for support can typically be found on the official Phinistec website or within the product packaging.



