

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [typecase](#) /

› **typecase Touch Keyboard Case with Trackpad for iPad Air 11-inch (M3 2025 / M2 2024) User Manual**

## typecase B09WVRD5JD

# typecase Touch Keyboard Case User Manual

Model: B09WVRD5JD

## PRODUCT OVERVIEW

The typecase Touch Keyboard Case is designed to enhance the functionality and protection of your iPad Air. It features a full-size keyboard with a multi-gesture trackpad, offering a laptop-like experience. The case boasts a 360° rotatable hinge, allowing for multiple viewing angles and usage modes. An adjustable 11-color RGB LED backlight provides comfortable typing in various lighting conditions. Integrated smart features like auto sleep/wake help conserve battery life, and a dedicated holder keeps your Apple Pencil secure.

### Key Features:

- **Compatibility:** Specifically designed for iPad Air 11-inch (M3 2025 / M2 2024), iPad Air 5th Gen (2022, 10.9"), and iPad Air 4th Gen (2020, 10.9").
- **Integrated Trackpad:** Supports multi-gesture controls for precise navigation.
- **Backlit Keyboard:** 11 adjustable RGB backlight colors with laser-etched keys and a full row of iPadOS shortcuts.
- **Versatile Use Modes:** 360° rotatable hinge for 7 different viewing modes (Laptop, Stand, Tent, Tablet, Corner, Share, Protect).
- **Smart Protection:** Premium hardshell design protects all sides of your iPad, with auto sleep/wake function.
- **Pencil Holder:** Conveniently stores your Apple Pencil.

## PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x typecase Touch Keyboard Case for iPad Air 5th/4th Gen (10.9 inch)
- 1 x USB-C Charging Cable
- 1 x User Manual

## SETUP GUIDE

### 1. Charging the Keyboard Case

Before initial use, fully charge the keyboard case. Connect the provided USB-C charging cable to the charging port on the keyboard and to a USB power adapter (not included).

*Charging indicator: The LED indicator will show charging status. Refer to the keyboard's specific LED behavior for full charge indication.*

## 2. Inserting Your iPad into the Case

Carefully align your iPad with the protective shell of the keyboard case. Gently press the iPad into place, ensuring all corners are securely seated. The case is designed to protect all sides of your iPad.



Image: The typecase keyboard case with an iPad securely inserted, ready for use. Note the integrated trackpad and backlit keys.



## 7-in-1 Design



Image: Visual representation of the 7 versatile modes supported by the 360° rotatable hinge, including Laptop, Stand, and Tablet modes.

### 3. Pairing with Your iPad (Bluetooth)

1. Turn on the keyboard by sliding the power switch to the ON position.
2. Press the **Connect** button (or a similar Bluetooth pairing button, usually indicated by a Bluetooth icon) on the keyboard. The Bluetooth indicator light will start blinking.
3. On your iPad, go to **Settings > Bluetooth**.
4. Ensure Bluetooth is turned **On**.
5. Locate "typecase Keyboard" or a similar name in the "Other Devices" list and tap on it to pair.
6. Once paired, the Bluetooth indicator light on the keyboard will stop blinking and remain solid, or turn off.

*Note: The keyboard will automatically enter sleep mode after a period of inactivity to conserve battery. Press any key to wake it up.*

## OPERATING INSTRUCTIONS

### Keyboard Functions

The keyboard features a standard layout with 78 comfortably spaced keys and a dedicated row of iPadOS shortcut keys.


# SMART PROTECTION



Keys protected in tablet mode



lightweight



thin profile



easy to use

Image: Detailed view of the backlit keyboard, highlighting the iPadOS shortcut keys and the vibrant 11-color RGB backlight.

## iPadOS Shortcut Keys:

Key Icon	Function
Home	Returns to the Home screen.
Brightness Down	Decreases screen brightness.
Brightness Up	Increases screen brightness.
Keyboard Hide/Show	Toggles the on-screen keyboard.
Search	Activates iPad search.
Previous Track	Skips to the previous media track.
Play/Pause	Plays or pauses media.
Next Track	Skips to the next media track.
Mute	Mutes or unmutes audio.

Key Icon	Function
Volume Down	Decreases audio volume.
Volume Up	Increases audio volume.
Lock Screen	Locks the iPad screen.

## Trackpad Usage

The integrated multi-gesture trackpad allows for precise control and navigation of your iPad. Ensure the trackpad is enabled in your iPad's settings if you experience issues.

### Common Trackpad Gestures:

- **Single Finger Tap:** Click/Select.
- **Two Finger Scroll:** Scroll up or down.
- **Pinch to Zoom:** Zoom in or out on content.
- **Three Finger Swipe Up:** Go to Home screen.
- **Three Finger Swipe Left/Right:** Switch between open apps.

**COMPATIBLE**  
for iPad Air 11-inch (M3 2025 /M2 2024) and  
iPad Air 5th /4th Gen 10.9"(2022/2020)



## MODELS

(Please check the back of Tablet)

**iPad Air 11-inch (M3) 2025**  
A3266, A3267, A3270

**iPad Air 11-inch (M2) 2024**  
A2902, A2903, A2904

**Air 5th**  
A2588,A2589, A2591

**Air 4th**  
A2072,A2316, A2324,A2325



iPad Air 11-inch  
(M3 2025 / M2 2024)

for iPad Air 5/4th 10.9  
(2022/2020)

Not for iPad 11" (A16) 2025  
iPad 10th Gen 2022

Not for iPad Air 3 (2019)

Not for iPad Air 1/2

Image: A hand demonstrating the use of the multi-touch trackpad for precise cursor control on the iPad screen.

## Adjusting Backlight

The keyboard features 11 adjustable RGB backlight colors and 3 levels of brightness. Use the dedicated backlight keys on the keyboard to cycle through colors and adjust brightness levels.

Your browser does not support the video tag.

Video: This video demonstrates the 360-degree rotation feature of the typecase Touch Keyboard Case, showcasing its versatility in different viewing modes.

Your browser does not support the video tag.

Video: This video provides a step-by-step guide on how to properly install and remove your iPad from the typecase Touch Keyboard Case, ensuring a secure fit and preventing damage.

## MAINTENANCE AND CARE

---

- **Cleaning:** Use a soft, damp cloth to clean the exterior of the case and keyboard. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the iPad is removed if storing for very long durations.
- **Battery Life:** To maximize battery life, turn off the keyboard when not in use. The auto sleep/wake function helps conserve power.
- **Avoid Liquids:** Do not expose the keyboard case to excessive moisture or liquids.
- **Handle with Care:** While durable, avoid dropping the case or applying excessive force to the hinge or keyboard.

## TROUBLESHOOTING

---

If you encounter any issues with your typecase Touch Keyboard Case, please refer to the following common solutions:

### Keyboard Not Connecting/Typing:

- Ensure the keyboard is turned ON and fully charged.
- Check your iPad's Bluetooth settings to confirm the keyboard is paired and connected. If not, try re-pairing.
- Restart both your iPad and the keyboard.
- Ensure no other Bluetooth devices are interfering with the connection.

### Trackpad Not Responding:

- Verify the keyboard is connected via Bluetooth.
- Check iPad settings: **Settings > Accessibility > Touch > AssistiveTouch**. Ensure "Mouse Keys" is off if it's causing interference.
- Clean the trackpad surface to remove any debris.

### Backlight Not Working:

- Ensure the keyboard is sufficiently charged.
- Press the backlight adjustment keys to cycle through brightness levels and colors.

### iPad Not Entering Sleep/Wake Mode:

- Ensure the iPad is correctly seated in the case.
- Check iPad settings: **Settings > Display & Brightness > Lock/Unlock**. Ensure this feature is

enabled.

*If problems persist, please contact typecase customer support for further assistance.*

## SPECIFICATIONS

Feature	Detail
Model	B09WVRD5JD
Compatibility	iPad Air 11-inch (M3 2025 / M2 2024), iPad Air 5th Gen (2022, 10.9"), iPad Air 4th Gen (2020, 10.9")
Connectivity	Bluetooth
Keyboard Layout	78-key standard with iPadOS shortcuts
Backlight	11-color RGB, 3 brightness levels
Trackpad	Multi-functional, multi-gesture
Hinge Rotation	360° (20,000-cycle stress tested)
Power Source	Battery Powered (1 Lithium Polymer battery included)
Item Weight	1.52 pounds
Product Dimensions (LxWxH)	11.02 x 8.66 x 0.79 inches
Material	Premium hardshell design

## WARRANTY AND SUPPORT

typecase offers a comprehensive warranty and support for your product:

- 1-Year Replacement Service:** Enjoy worry-free after-sales support with a 1-year replacement service for manufacturing defects.
- 30-Day Refund:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days of purchase.
- Customer Support:** For any questions, technical assistance, or warranty claims, please contact typecase customer service. Refer to the contact information provided in the product packaging or on the official typecase website.




Image: Overview of typecase's customer support and warranty policy, including 1-year replacement and 30-day refund.

© 2025 typecase. All rights reserved.  
For more information, visit [typecase Store](#)