

**Manuals+**

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [VASAGLE](#) /

> [VASAGLE UBBC846P31 Small Bathroom Storage Cabinet Instruction Manual](#)

**VASAGLE UBBC846P31**

# VASAGLE UBBC846P31 Small Bathroom Storage Cabinet Instruction Manual

Model: UBBC846P31 | Brand: VASAGLE

## 1. INTRODUCTION

---

Thank you for choosing the VASAGLE UBBC846P31 Small Bathroom Storage Cabinet. This compact and functional cabinet is designed to optimize storage in small bathroom spaces, featuring a toilet paper holder, a drawer, and an adjustable shelf within a lower cabinet. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

# Multiple Storage Sections

Suit your various storage needs



Figure 1: Front view of the assembled VASAGLE UBBC846P31 Small Bathroom Storage Cabinet.

## 2. SAFETY INFORMATION

- **Anti-Tip Kit:** For safety, always attach the product to the wall using the included anti-tip kit. This prevents accidental tipping, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum static load capacity of the top compartment, which is 11 lb (5 kg).



### 3. PACKAGE CONTENTS

---

Before beginning assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer service.

- 1 x Bathroom Storage Cabinet (components for assembly)
- 1 x Accessory Kit (screws, dowels, hinges, drawer slide, handle, anti-tip kit)
- 1 x Instructions Manual (this document)

### 4. SETUP AND ASSEMBLY

---

Assembly of the VASAGLE UBBC846P31 cabinet requires patience and attention to detail. Please follow the included graphical instructions carefully. It is recommended to have a standard screwdriver and potentially a shorter screwdriver for tight spaces.





Figure 3: Exploded view and dimensions of the cabinet components, illustrating the various sections and their measurements.

### Assembly Tips:

- **Organize Parts:** Lay out all components and hardware before starting. Group similar items to avoid confusion.
- **Follow Steps Sequentially:** Adhere strictly to the numbered steps in the provided instruction booklet.
- **Hinge Installation:** It may be easier to attach the door hinges to the cabinet frame after assembling the main cabinet body, rather than attaching them to the door first and then to the cabinet.
- **Do Not Overtighten:** Tighten screws firmly but avoid overtightening to prevent damage to the engineered wood.
- **Anti-Tip Kit:** Once assembled and placed in its final position, securely attach the cabinet to the wall using the anti-tip kit as instructed in the safety section.

## 5. OPERATING INSTRUCTIONS (USAGE)

The VASAGLE UBBC846P31 cabinet offers multiple storage solutions for your bathroom.

### 5.1 Multiple Storage Sections

This cabinet is designed with five distinct storage areas to accommodate various items:

- **Top Compartment:** Ideal for small decorative items, diffusers, or a mobile phone.
- **Drawer:** Suitable for small personal items, hair accessories, or other bathroom essentials.
- **Toilet Paper Holder Section:** Designed to hold one roll of toilet paper for immediate use.
- **Lower Cabinet:** Features an adjustable shelf to store extra toilet rolls, cleaning supplies, or towels.



Figure 4: Overview of the cabinet's multiple storage sections in use.

## 5.2 Removable Toilet Paper Roller

The toilet paper roller is designed for easy use and versatility. To replace a roll, simply pull the roller out from one side. The roller can also be completely removed if you prefer to store tubeless toilet paper or a box of tissues in this section.

# Removable Roller

Allow the holder to fit various types of toilet paper.



Toilet Rolls



Tubeless Toilet Rolls



Tissues

Figure 5: The removable toilet paper roller and alternative storage options for the compartment.

## 5.3 Adjustable Shelf

The shelf within the lower cabinet is adjustable, allowing you to customize the storage space to fit items of varying heights. To adjust, carefully remove the shelf and reposition it into the desired set of pre-drilled holes, ensuring it is level and secure.



## Adjustable Shelf

Allows the bottom cabinet to fit items of varying sizes.



Figure 6: Adjusting the shelf in the lower cabinet to accommodate different item sizes.

### 5.4 Handy Top Compartment

The top compartment features a raised edge on three sides, providing a secure spot for items like your mobile phone, preventing it from falling off or getting wet.

# Handy Compartment

Offers a safe spot for your cellphone.



Figure 7: The top compartment providing a secure space for small items.

## 6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, damp cloth and drying thoroughly.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, solvents, or strong chemical agents, as these can damage

the finish of the engineered wood.

- **Moisture Protection:** While the feet are waterproof, avoid prolonged exposure to excessive moisture. Promptly wipe up any spills.
- **Regular Checks:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Difficulty during assembly (e.g., parts not aligning)	Incorrect orientation of parts; screws not fully tightened; manufacturing variation.	Review the instruction manual carefully, ensuring each part is oriented correctly. Loosen screws slightly, adjust alignment, then retighten. If issues persist, contact customer support.
Drawer or door does not close smoothly or has gaps.	Improper installation of drawer slides or hinges; cabinet not level.	Check that drawer slides and hinges are installed according to instructions and are not bent. Ensure the cabinet is on a level surface. Adjust hinge screws if necessary for door alignment.
Cabinet feels unstable or wobbly.	Screws are loose; cabinet not level; anti-tip kit not installed.	Tighten all assembly screws. Ensure the cabinet is on a flat surface. <b>Crucially, install the anti-tip kit as instructed to secure the cabinet to the wall.</b>
Door magnet is too strong, making it hard to open.	Magnet plate positioned too close to the magnet.	Adjust the distance of the metal plate on the door from the magnet on the cabinet frame. Slightly repositioning the plate can reduce the magnetic force. Ensure the anti-tip kit is installed to prevent the cabinet from moving when opening the door.

## 8. SPECIFICATIONS

<b>Brand</b>	VASAGLE
<b>Model Number</b>	UBBC846P31
<b>Color</b>	White
<b>Material</b>	MDF (Engineered Wood)
<b>Product Dimensions (D x W x H)</b>	7.9" x 7" x 30.2" (20.1 x 17.8 x 76.7 cm)
<b>Item Weight</b>	13.6 lb (6.2 kg)
<b>Max. Static Load Capacity (Top)</b>	11 lb (5 kg)
<b>Number of Drawers</b>	1
<b>Number of Shelves</b>	4 (including fixed bottom and top, plus 1 adjustable)
<b>Assembly Required</b>	Yes
<b>Special Features</b>	Adjustable Shelf, Water-Proof Feet, Anti-Tip Kit Included

## 9. WARRANTY AND SUPPORT

---

For warranty information, missing parts, assembly assistance, or any other product-related inquiries, please contact VASAGLE customer support directly. Refer to the contact information provided with your purchase or visit the official VASAGLE website for assistance.

**Manufacturer:** VASAGLE

**Seller:** SONGMICS HOME CA

*Please retain your proof of purchase for warranty claims.*

