Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JYX JYX-T9

JYX Karaoke Machine User Manual

Model: JYX-T9

Brand: JYX

Product Overview

The JYX Karaoke Machine (Model JYX-T9) is a portable PA system designed for adults, featuring two 8-inch woofers, a 3-inch tweeter, and 500W peak power for saturated and powerful sound quality. It includes two wireless microphones that automatically pair, colorful acoustic LED lights that dance to the music, and flexible trolley bars and wheels for easy transport. Multiple connection methods are supported, including Bluetooth 5.0, AUX, TF card, and USB stick. The built-in 5200mAh rechargeable battery provides up to four hours of non-stop use, with the option to operate while charging for extended periods. The top panel offers comprehensive controls for master volume, microphone volume, echo, recording, and media playback. It also supports TWS (True Wireless Stereo) mode for connecting two units for enhanced bass and optimized sound.



Figure 1: The JYX Karaoke Machine comes with two wireless microphones and a remote control, ready for immediate use.

Package Contents

- Speaker x 1
- Wireless microphone x 2
- Remote Control x 1
- Charging cable x 1
- AUX cable x 1

Setup Guide

Charging the Unit

Before first use, fully charge the karaoke machine using the provided 12V adapter. The 5200mAh rechargeable battery ensures up to four hours of non-stop use. For extended periods, the unit can be used while charging.

Microphone Pairing

The two UHF wireless microphones included with the machine will automatically pair with the speaker when switched on, ready for immediate use.

Connecting Devices

The JYX-T9 supports multiple connection methods:

- **Bluetooth 5.0:** Adopt the latest Bluetooth 5.0 chip for wireless streaming. Enable Bluetooth on your device and select 'JYX-T9' to connect.
- **AUX:** Use the provided AUX cable to connect devices without Bluetooth capability.
- **TF Card & USB Stick:** Insert a TF card or USB stick into the respective slots to play pre-loaded music.
- **Wired Microphones:** The speaker also has two extra microphone jacks (MIC 1, MIC 2) for connecting additional wired microphones.



Figure 2: The top panel provides various input options including TF card, USB, AUX in, and microphone jacks.

Video: This official seller video demonstrates the powerful sound and various features of the JYX T9 Karaoke Speaker, including its connectivity options and portability.

Operating Instructions

Control Panel Functions

The top panel of the speaker features intuitive controls:

- **Master Volume:** Adjusts the overall sound output.
- **MIC VOL +/-:** Controls the volume of the microphones.
- **ECHO +/-:** Adjusts the echo effect for the microphones.
- **REC:** Initiates recording.
- **MODE:** Switches between different input modes (Bluetooth, AUX, TF Card, USB).
- **LED MODE:** Changes the lighting effects of the acoustic lights.

- **PLAY/PAUSE:** Plays or pauses the current track.
- **PREV/NEXT:** Skips to the previous or next track.

Acoustic LED Lights

The two acoustic colorful lights around the speaker units change color and dance to the rhythm of the music, enhancing the party atmosphere. Use the 'LED MODE' button to cycle through different lighting patterns or turn them off.



Figure 3: Explore different vibrant lighting effects to match your mood or event.

Portability and Mobility

Fitted with flexible trolley bars and wheels, the JYX-T9 allows you to easily transport the speaker outdoors or to different rooms. Simply extend the handle and roll the unit to your desired location.



Figure 4: The retractable trolley handle and rolling wheels make the karaoke machine highly portable.

TWS (True Wireless Stereo) Mode

By connecting two JYX-T9 karaoke stereo systems, you can enjoy True Wireless Stereo via Bluetooth. This feature enhances the bass and provides a more balanced sound, optimizing the high and low pitch separation for clear and sonorous audio.

Care and Maintenance

To ensure the longevity and optimal performance of your JYX Karaoke Machine, follow these care and maintenance guidelines:

- **Cleaning:** Wipe the exterior of the speaker with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish.
- **Battery Care:** To prolong battery life, charge the unit regularly, even when not in use. Avoid fully discharging the battery frequently. Store the unit in a cool, dry place away from extreme temperatures.
- **Storage:** When not in use for extended periods, store the karaoke machine in a dry environment. Ensure the

handle is fully retracted and the wheels are clean.

Troubleshooting

If you encounter any issues with your JYX Karaoke Machine, please refer to the following common troubleshooting tips:

- **No Sound:** Ensure the unit is powered on and charged. Check the master volume and microphone volumes. Verify that your connected device (Bluetooth, AUX, TF/USB) is playing audio and its volume is up.
- **Microphone Not Working:** Confirm the wireless microphones are switched on and have fresh batteries. Ensure they are within range of the speaker. If using wired microphones, check their connection to the MIC 1 or MIC 2 jacks.
- **Bluetooth Connection Issues:** Make sure Bluetooth is enabled on your device and the speaker is in Bluetooth mode. Try forgetting the device on your phone and re-pairing. Ensure no other devices are actively connected to the speaker.
- **LED Lights Not Working:** Press the 'LED MODE' button to cycle through lighting effects. Ensure the unit is powered on.

If the problem persists after trying these steps, please contact customer support.

Product Specifications

Feature	Specification
Brand	JYX
Model Number	JYX-T9
Product Dimensions	7.87 x 7.87 x 7.87 inches
Batteries	1 Lithium Ion batteries required (included)
Color	Silver, Black
Special Features	PA System, Deep Bass, Rechargeable, Built-In Handle, Built-In Amplifier, Light Up Speaker, Wireless, Stereo Pairing, TWS
Recommended Uses	Commercial, Party, Events, Outdoor, Home

Warranty and Support

For detailed warranty information and comprehensive support, please refer to the official User Manual PDF provided by JYX. You can download the full manual for complete details on product usage, safety guidelines, and warranty terms.

Download User Manual: User Manual (PDF)

For any further assistance or technical support, please contact JYX customer service through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WYPBM1V

More documents and user manuals: **https://manuals.plus/**