

Anwick B09X1DWDT8

Anwick Metal Bunk Bed Instruction Manual

Model: B09X1DWDT8 | Brand: Anwick

INTRODUCTION

Thank you for choosing the Anwick Metal Bunk Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information

- **Maximum Weight Capacity:** The upper bunk supports up to 250 lbs. The lower bunk supports up to 350 lbs. Do not exceed these limits.
- **Guard Rails:** The upper bunk is equipped with full-length guard rails. Ensure they are always securely in place.
- **Ladder Safety:** Always use the provided ladder for accessing the upper bunk. Ensure the ladder is stable before use.
- **Mattress Thickness:** For the upper bunk, use a mattress no thicker than 6 inches. For the lower bunk, use a mattress no thicker than 8 inches.
- **No Jumping:** Do not allow jumping on either bunk.
- **Assembly:** Assembly requires two adults. Ensure all bolts and fasteners are tightened securely before use. Periodically check and re-tighten all connections.
- **Ventilation:** Ensure adequate ventilation around the bed.



Figure 1: Assembled Anwick Metal Bunk Bed (Black)

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Bed Frame Components (Headboards, Footboards, Side Rails)
- Bed Slats for Upper and Lower Bunks
- Guard Rails for Upper Bunk
- Ladder
- Hardware Pack (Bolts, Nuts, Washers, Allen Wrench)

SETUP AND ASSEMBLY INSTRUCTIONS

Please follow these steps carefully. It is recommended to assemble the bed in the room where it will be used. Two adults are required for safe and efficient assembly.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface (e.g., a carpet or blanket) to prevent scratching. Refer to the parts list (not provided in detail here, but typically included with physical product) to identify each piece.
2. **Assemble Lower Bunk Frame:** Connect the lower bunk headboard and footboard to the lower side rails using the provided bolts and Allen wrench. Do not fully tighten bolts until the entire frame is assembled.
3. **Install Lower Bunk Slats:** Place the metal slats onto the designated supports on the lower bunk frame. Secure them according to the instructions in your hardware pack.
4. **Assemble Upper Bunk Frame:** Connect the upper bunk headboard and footboard to the upper side rails. Again, do not fully tighten bolts yet.
5. **Attach Upper Bunk to Lower Bunk:** Carefully lift the assembled upper bunk frame and align it with the posts of the lower bunk. Secure them together using the appropriate connectors and bolts. This step requires two people.
6. **Install Upper Bunk Slats:** Place the metal slats onto the designated supports on the upper bunk frame and secure them.
7. **Attach Guard Rails:** Secure the full-length guard rails to the upper bunk frame as indicated in the product diagram. Ensure they are firmly attached.
8. **Install Ladder:** Attach the ladder to the designated hooks or mounting points on the side of the bunk bed. Verify it is stable and secure.
9. **Final Tightening:** Once all components are in place, systematically go back and fully tighten all bolts and fasteners. Do not overtighten.



Figure 2: Side view of the bunk bed showing ladder and guard rails.

OPERATING INSTRUCTIONS

The Anwick Metal Bunk Bed is designed for safe and comfortable use when operated correctly.

- **Upper Bunk Access:** Always use the provided ladder to access or exit the upper bunk. Do not climb on the bed frame directly.
- **Weight Distribution:** Distribute weight evenly on both bunks. Avoid concentrating heavy loads in one area.
- **Guard Rail Function:** The guard rails are a critical safety feature for the upper bunk. Ensure they are always in place and undamaged.
- **Mattress Placement:** Ensure mattresses fit snugly within the bed frame to prevent gaps.

MAINTENANCE

Regular maintenance will help prolong the life and safety of your bunk bed.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. A mild soap solution can be used for tougher spots. Avoid abrasive cleaners or harsh chemicals, as they can damage the finish.
- **Fastener Check:** Periodically (e.g., every 3-6 months) inspect all bolts, nuts, and screws. Re-tighten any loose fasteners to ensure structural integrity.
- **Damage Inspection:** Regularly check the bed frame, slats, guard rails, and ladder for any signs of damage, wear, or bending. Discontinue use if significant damage is found and contact support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed squeaks or wobbles	Loose fasteners	Check and re-tighten all bolts and screws.
Ladder feels unstable	Improper attachment or loose connections	Ensure the ladder is correctly hooked or bolted to the frame and all connections are tight.
Missing parts during assembly	Packaging error	Do not proceed with assembly. Contact Anwick customer support immediately.

SPECIFICATIONS



Figure 3: Detailed dimensions of the Anwick Metal Bunk Bed.

- **Model:** B09X1DWDT8
- **Overall Dimensions:** 77.1"L x 55.9"W x 53.7"H
- **Material:** Alloy Steel, Metal
- **Color:** Black
- **Upper Bunk Weight Capacity:** 250 lbs
- **Lower Bunk Weight Capacity:** 350 lbs

- **Recommended Upper Bunk Mattress Thickness:** 6 inches
- **Recommended Lower Bunk Mattress Thickness:** 8 inches
- **Assembly Required:** Yes
- **Included Components:** Guardrails, Slats, Ladder

WARRANTY AND SUPPORT

Anwick products are manufactured to high-quality standards. For specific warranty details, please refer to the documentation included with your purchase or visit the official Anwick brand store.

For customer support, missing parts, or technical assistance, please contact Anwick directly through their official channels or the retailer from whom the product was purchased.

Visit the [Anwick Store](#) for more information.