

[Manuals.plus](#) /

› [Kaiess](#) /

› Kaiess 62-inch Phone Tripod and Selfie Stick (Model TP303) User Manual

Kaiess TP303

Kaiess 62-inch Phone Tripod and Selfie Stick (Model TP303) User Manual

Your guide to setting up and using your Kaiess TP303.

1. INTRODUCTION

This manual provides detailed instructions for the Kaiess 62-inch Phone Tripod and Selfie Stick, Model TP303. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan. This device is designed for capturing photos and videos with smartphones and other compatible devices, functioning as both an extendable selfie stick and a stable tripod.



The Kaless TP303 in its various modes, showcasing its versatility.

2. WHAT'S IN THE BOX

Verify that all components are present upon unpacking:

- Travel Phone Tripod
- Phone Mount
- Wireless Remote
- Compatible for GoPro Quick Release (adapter)

Outstanding Wireless Remote

33FT/10M



Illustration of the items included in the product packaging.

3. PRODUCT FEATURES

- **Durable Construction:** Made with advanced materials for enhanced durability and resistance to rust.
- **Extendable Design:** Extends from 13 inches to 62 inches, offering versatile height options.
- **Stable Tripod Base:** Features a wider, break-proof base for increased stability.
- **Adjustable Phone Holder:** Accommodates phones up to 3.6 inches wide with soft silicone pads for protection.
- **Flexible Shooting Angles:** Tripod head rotates 180°, and the phone holder adjusts 360° for optimal positioning.
- **Wireless Remote Control:** Simple 1-button remote with a working range of up to 40 feet, compatible with Android and Apple phones.
- **Universal Compatibility:** Equipped with a standard 1/4" screw for connecting cameras, action cameras, and webcams.

3.1 Enhanced Stability

UPGRADED

Thicker and Wider



Thicker Tube



Wider & Break-Proof



The upgraded base design ensures greater stability for your device.

3.2 Adjustable Height

Adjust **Height** with Ease



Easily adjust the tripod's height to suit various shooting requirements.

3.3 Flexible Shooting Angles

Support **All** Shooting Angles



Phone holder can
be rotated
360°

Tripod head
can be rotated
180°



Achieve any desired shooting angle with the rotational head and phone holder.

3.4 Secure Phone Holder

1 Handed Clip & Wide Applicability

Include 1/4" Standard Screw



iPhone MAX



S24 Ultra



Ring Light



Camera



The phone holder securely grips your device and is compatible with various accessories.

3.5 Wireless Remote Control

40ft Wireless Remote

App-free



The wireless remote allows for convenient photo and video capture from a distance.

4. SETUP INSTRUCTIONS

4.1 Extending the Tripod/Selfie Stick

1. To extend the tripod legs, gently pull them outwards from the base until they lock into position.
2. To extend the telescopic pole, twist the blue ring lock counter-clockwise to unlock, then pull the sections upwards to the desired height. Twist clockwise to lock.



The blue ring lock secures the telescopic pole at your chosen height.

4.2 Attaching Your Phone

1. Press the two buttons on the back of the phone holder simultaneously to open the clamp.
2. Carefully insert your smartphone into the holder, ensuring it is centered and secure. The soft silicone pads will protect your device.
3. Release the buttons to allow the clamp to firmly hold your phone.

4.3 Pairing the Wireless Remote

1. Ensure the remote control has a working CR2032 battery installed.
2. Turn on the remote control (if it has a power switch).
3. On your smartphone, go to **Settings > Bluetooth**.
4. Enable Bluetooth and search for available devices.
5. Select "AB Shutter3" (or similar name) from the list to pair. The remote's indicator light will confirm successful pairing.



Pairing the wireless remote control with your smartphone via Bluetooth.

5. OPERATING INSTRUCTIONS

5.1 Using as a Tripod

1. Extend the tripod legs fully and ensure they are stable on a flat surface.
2. Adjust the telescopic pole to your desired height and lock it.
3. Position your phone in the holder.
4. Use the 180° rotational tripod head and 360° phone holder to achieve the perfect angle.
5. Use the wireless remote to capture photos or start/stop video recording.

5.2 Using as a Selfie Stick

1. Fold the tripod legs together to form a handle.
2. Extend the telescopic pole to your desired length and lock it.
3. Hold the stick firmly and adjust your phone's angle.
4. Use the wireless remote (which can be clipped onto the stick) to take selfies or group photos.

6. MAINTENANCE

- **Cleaning:** Wipe the tripod and phone holder with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** If the wireless remote is not used for an extended period, consider removing the CR2032 battery to prevent leakage.
- **Water Exposure:** While designed to be break-proof, avoid prolonged exposure to water or wet environments to prevent potential damage to internal components.

7. TROUBLESHOOTING

7.1 Remote Control Not Pairing

- Ensure the remote control has a fresh CR2032 battery and is powered on.
- Make sure Bluetooth is enabled on your smartphone.
- Try unpairing and re-pairing the remote control in your phone's Bluetooth settings.
- Ensure the remote is within the 40-foot operating range of your phone.

7.2 Tripod Instability

- Ensure the tripod legs are fully extended and locked on a flat, stable surface.
- Verify that the telescopic pole is fully locked at the desired height.
- Ensure your phone is securely placed and balanced in the phone holder.
- Avoid placing the tripod on uneven or slippery surfaces.

8. SPECIFICATIONS

Feature	Detail
Model Name	TP303
Maximum Height	62 Inches
Minimum Length	13 Inches
Item Weight	12.8 ounces
Product Dimensions	1.5 x 1.5 x 62 inches
Material	Aluminum, Modified Nylon PA6/6
Weight Limit	340 Grams
Compatible Devices	iPhone, Android
Remote Control Range	Up to 40 feet
Remote Battery Type	CR2032 (included)
Tripod Head Type	Ball Heads

9. WARRANTY AND SUPPORT

Kaless is committed to providing quality products and customer satisfaction.

- **Warranty:** The product includes a 365-day replacement and lifetime service.
- **Customer Support:** 24-hour customer support is available for any inquiries or assistance.
- **Returns:** Standard return policy allows for returns within 30 days for refund or replacement.

For support, please contact Kaless directly through their official channels or the retailer where the product was purchased.



Kaless customer care commitment.

