



Manuals.plus /

› Leemone /

› Leemone IZ462H Filter Replacements Instruction Manual for Shark Vertex Cordless Stick Vacuum Cleaners

## Leemone IZ462H

# Leemone IZ462H Filter Replacements Instruction Manual

For Shark Vertex Cordless Stick Vacuum Cleaners (Models IZ462H, IZ483H, IZ482H, IZ440H)

## INTRODUCTION

This manual provides instructions for the installation, maintenance, and care of Leemone IZ462H filter replacements for compatible Shark Vertex Cordless Stick Vacuum Cleaners. Adhering to these guidelines will help ensure optimal performance and longevity of your vacuum cleaner's filtration system.

## PRODUCT COMPATIBILITY

These replacement parts are compatible with the following Shark Vertex Cordless Stick DuoClean PowerFins Upright Vacuum Cleaner models:

- Shark IZ462H
- Shark IZ483H
- Shark IZ482H
- Shark IZ440H

These parts are designed to replace Shark part numbers #XHF161H and #617FJ140.

# Compatible with Shark

iz440h,iz462h,iz482h,iz483h vertex ultra lightweight  
cordless stick duoclean powerfins vacuum cleaner



Image: A person operating a Shark Vertex cordless stick vacuum cleaner, demonstrating the compatibility of the replacement parts with the vacuum's design.

## PACKAGE CONTENTS

The Leemone IZ462H replacement kit includes the following components:

- 2 x Post-Motor Filters
- 4 x Pre-Motor Foam Filters
- 4 x Felt Filters
- 1 x Brushroll
- 1 x Cleaning Brush



Image: The complete Leemone replacement kit, showcasing two post-motor filters, four pre-motor foam filters, four felt filters, one brushroll, and one cleaning brush.

# PACKAGE INCLUDES

12 Pack:1X Brushroll,2X Post-Motor HEPA Filter,4X Pre-Flet Filter,4X Pre-Foam Filters,1X Cleaning Brush.



Image: A visual representation of the dimensions for the post-motor HEPA filters and pre-motor foam/felt filters, provided for fit verification.

## INSTALLATION INSTRUCTIONS

No extra tools are needed for the replacement process. Follow your Shark vacuum cleaner's user manual for specific instructions on accessing and removing existing filters and brushrolls. Generally, the steps involve:

1. **Power Off and Unplug:** Ensure the vacuum cleaner is turned off and unplugged from any power source before beginning.
2. **Access Filter Compartments:** Locate the pre-motor and post-motor filter compartments on your vacuum. Refer to your vacuum's manual for exact locations.
3. **Remove Old Filters:** Carefully remove the used foam, felt, and post-motor filters. Dispose of them properly.
4. **Insert New Filters:** Place the new Leemone pre-motor foam and felt filters into their designated slots. Ensure they are seated correctly. Install the new post-motor filter.
5. **Replace Brushroll (if applicable):** If replacing the brushroll, follow your vacuum's instructions to remove the old brushroll and insert the new Leemone brushroll. Ensure it clicks into place securely.
6. **Close Compartments:** Securely close all filter and brushroll compartments.

7. **Test:** Power on the vacuum to ensure proper operation.

## OPERATING PRINCIPLES OF FILTERS AND BRUSHROLL

The Leemone replacement parts are designed to maintain the high performance of your Shark vacuum cleaner:

- **Brushroll:** The brushroll efficiently removes hair, pet fur, pet dander, food scraps, and dust from various surfaces, including hard-to-reach areas.
- **Pre-Motor Foam & Felt Filters:** These filters intercept 99% of contaminants and impurities, such as fine dust and allergens, before they can reach and potentially damage the vacuum's motor.
- **Post-Motor Filter:** This filter captures 99.99% of harmful particles, including microscopic allergens, ensuring that clean air is expelled back into your environment.



Image: A diagram illustrating the multi-layer filtration process, showing how the filter captures various particles like pollen, dust, and pet dander, contributing to cleaner air.

# THE BRUSH-ROLL

can efficiently remove hair, pet fur, pet dander, food scraps and dust in the nooks and crannies.



Image: A person using a vacuum cleaner, highlighting the brushroll's action in effectively removing hair, pet fur, and dust from floor surfaces.

## 3-LAYER HIGH-EFFICIENCY FILTER

Deeply filtered, fresh air that can be breathed directly.



Image: A detailed cutaway diagram of the vacuum's filtration system, emphasizing the three distinct layers of filtration that work together to ensure clean air output.

### MAINTENANCE AND CARE

Regular cleaning and timely replacement of filters are crucial for maintaining your vacuum's suction power and air filtration efficiency.

#### Cleaning Filters

The pre-motor foam and felt filters are washable and reusable:

1. **Remove Filters:** Take out the foam and felt filters from the vacuum.
2. **Hand Wash:** Rinse the filters under warm water until the water runs clear. Do not use detergent.
3. **Air Dry:** Squeeze out excess water and allow the filters to air dry completely for at least 24 hours before reinserting them into the vacuum. Ensure they are completely dry to prevent mold or damage to the vacuum.

## WASHABLE AND REUSABLE



Replace it every **1-3 months** according to the use and environment.

Image: A demonstration of hand washing the foam and felt filters under warm running water, illustrating a key maintenance step.

### Replacement Schedule

It is recommended to replace the pre-motor foam and felt filters once every 2-4 weeks, and the post-motor filter every 3-6 months, depending on usage frequency and environmental conditions. Maintaining clean and high-quality filters is essential for prolonging the motor's lifespan and ensuring effective cleaning.

### Brushroll Cleaning

Use the provided cleaning brush to remove tangled hair and debris from the brushroll regularly. If the brushroll is heavily worn or damaged, replace it with a new one from the kit.

## TROUBLESHOOTING

If you experience issues with your vacuum cleaner after replacing the filters, consider the following:

- **Reduced Suction:** Ensure all filters are correctly installed and completely dry. Check for any blockages in the vacuum's hose or nozzle.
- **Unusual Odors:** This often indicates that filters need cleaning or replacement. Ensure filters are

thoroughly dry after washing.

- **Filters Not Fitting:** Double-check that you have the correct replacement parts for your specific Shark vacuum model (IZ462H, IZ483H, IZ482H, IZ440H). Refer to the dimensions provided in the package contents section.
- **Brushroll Not Spinning:** Verify that the brushroll is correctly seated and free from obstructions like tangled hair or debris.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Leemone
Compatible Models	Shark IZ462H, IZ483H, IZ482H, IZ440H Vertex Cordless Stick Vacuum Cleaners
Replaces Part Numbers	XHF161H, 617FJ140
Material Type	Foam, Felt, HEPA-grade filter material
Reusability	Foam and Felt Filters are Reusable (washable)
Number of Pieces	12 (2 Filters, 4 Foam Filters, 4 Felt Filters, 1 Brushroll, 1 Cleaning Brush)

## CUSTOMER SUPPORT

If you encounter any quality issues or require further assistance with your Leemone replacement parts, please contact the Leemone customer service team. We are available to address and resolve any concerns you may have promptly.

For support, please visit the Leemone Store on Amazon or refer to your purchase documentation for direct contact information.