WINGBO SYCF6401

WINGBO 64-Inch DC Ceiling Fan with Lights and Remote Control Instruction Manual

Model: SYCF6401 | Brand: WINGBO

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your WINGBO 64-inch DC Ceiling Fan with Lights and Remote Control. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Important Safety Information

- Always disconnect power at the circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances.
- Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Mount the fan to a ceiling joist or outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less."
- Keep hands, clothing, and other objects clear of fan blades during operation.

Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Housing
- 5 Carved Wood Blades
- LED Light Kit
- Remote Control with Wall Holder
- Downrods (4.5" and 12" lengths)
- Mounting Bracket and Hardware
- Canopy
- Receiver Box

Setup and Installation

Proper installation is crucial for the safe and efficient operation of your ceiling fan. It is recommended to have two people for installation.

1. Mounting Options

The fan supports both standard downrod mounting and angled ceiling installation (up to an 8-degree slope).




Image showing the fan with a downrod mount and an angled mount, indicating suitability for rooms 20'x20' or larger.

2. Assembling the Downrod and Canopy

Select the appropriate downrod length (4.5" or 12") for your ceiling height. Secure the downrod to the motor housing, ensuring all wires are passed through the downrod.

Your browser does not support the video tag.

Video demonstrating the installation process of the WINGBO Ceiling Fan, including assembly of components and mounting.

Your browser does not support the video tag.

Video showing how to replace a ceiling fan, which includes steps relevant to the installation of this WINGBO 64-inch model.

3. Attaching Blades

Attach the five carved wood blades to the motor housing. Ensure all screws are tightened securely.



Close-up view of the fan's solid wood blades, emphasizing their quality and durability.

4. Electrical Connections

Connect the fan's wiring to your household electrical system. Ensure the receiver box is properly integrated into the wiring. Refer to the wiring diagram provided in the physical manual for specific connections. Always turn off power at the circuit breaker before making any electrical connections.



Detailed wiring diagram for the ceiling fan, illustrating connections for power, fan, and light.

Operating Instructions

Your WINGBO ceiling fan is operated using the included remote control.

1. Remote Control Functions

The remote control allows you to adjust fan speed, light settings, and fan direction.



Image of the remote control with labels for fan speed (1-6), light control, and nature mode.

- **Fan Speed:** Buttons 1-6 control the fan speed, from lowest (1) to highest (6).
- **Light Control:** Adjusts the LED light's brightness and color temperature.
- **Nature Mode:** Simulates natural breeze by varying fan speed.
- **Follow/Reverse:** Changes the direction of the fan blades.

2. Reversible Motor (Summer/Winter Modes)

The fan features a reversible DC motor for year-round comfort.



Visual representation of the fan's reversible function, showing downward airflow for summer and upward airflow for winter.

- **Summer Mode (Forward Direction):** Blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
- **Winter Mode (Reverse Direction):** Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling.

3. LED Light Kit

The integrated LED light offers three color temperature options: Warm Light (3000K), Natural Light (4500K), and Day Light (6000K).



Comparison of the three available LED light color temperatures: Warm (3000K), Natural (4500K), and Day (6000K).

4. Timer Function

Set the fan to automatically turn off after 1, 2, 4, or 8 hours using the remote control's timer function.



Illustration of the fan's timer function, allowing users to set automatic shut-off after 1, 2, 4, or 8 hours.

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tightening Screws:** Check all screws on the fan blades and mounting hardware annually to ensure they are secure.
- **Light Kit:** The integrated LED light source is designed for long life and typically does not require replacement.

Troubleshooting

Refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; remote control not paired.	Check circuit breaker. Ensure all wiring connections are secure. Re-pair remote control according to instructions in the physical manual.
Fan is noisy	Loose fan blades; mounting hardware not secure; internal motor issue.	Tighten all blade screws and mounting hardware. Ensure the fan is properly balanced. Refer to the video below for tips on fixing a noisy fan.
Light does not work	Loose wire connection to light kit; LED driver issue.	Check light kit wiring connections. If the issue persists, contact customer support.
Remote control not working	Dead batteries; remote not paired with fan.	Replace remote control batteries. Re-pair remote control with the fan.

Your browser does not support the video tag.

Video guide on how to diagnose and fix common causes of a noisy ceiling fan.

Specifications

Brand	WINGBO
Model Number	SYCF6401
Color	Black and Walnut
Product Dimensions	64"D x 64"W x 21"H
Blade Length	64 Inches
Number of Blades	5
Blade Material	Wood
Power Source	DC
Voltage	110 Volts
Wattage	24 watts (LED Light)
Number of Speeds	6
Light Type	LED (3000K/4500K/6000K)
Controller Type	Remote Control
Mounting Type	Downrod Mount
Indoor/Outdoor Usage	Indoor (Damp Rated)
Certification	ETL Listed

Warranty Information

WINGBO products are manufactured to high-quality standards and are warranted against defects in materials and workmanship. Please refer to the warranty card included with your product for specific terms and conditions, or visit the official WINGBO website for detailed warranty information.

Customer Support

If you have any questions, require assistance with installation, or need troubleshooting support, please contact WINGBO customer service. Contact details can typically be found on the product packaging or the official WINGBO website.
For more information and product updates, visit theWINGBO Store on Amazon.

© 2026 WINGBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question