Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WINGBO SYCF5401

WINGBO 54 Inch DC Ceiling Fan User Manual

Model: SYCF5401 | Brand: WINGBO

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your WINGBO 54 Inch DC Ceiling Fan. Designed with a sleek, minimalistic style and 5 reversible carved wood blades, this fan offers both aesthetic appeal and functional performance. It features a 6-speed noiseless DC motor and an integrated LED light kit, making it suitable for various indoor spaces.



Figure 1: WINGBO 54 Inch DC Ceiling Fan with Remote Control.



Figure 2: The WINGBO 54 Inch DC Ceiling Fan is suitable for various indoor spaces including living rooms, bedrooms, and covered outdoor areas.

Safety Information

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Ensure power is disconnected at the circuit breaker before installation or servicing.
- All electrical wiring must comply with national and local electrical codes. If unsure, consult a qualified electrician.
- Mount the fan to a ceiling joist or support structure capable of supporting the fan's weight (19.2 lbs).
- Do not bend the blade holders during installation or cleaning.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- This fan is suitable for damp locations indoors.

Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- 5 Carved Wood Blades
- Integrated LED Light Kit
- Remote Control with Wall Holder
- 2 Down Rods (4.5 inches and 12 inches)
- Mounting Hardware and Screws
- Instruction Manual

Setup and Installation

Professional installation is recommended for electrical components. Ensure the mounting location is structurally sound.

1. Mounting Options

The fan includes two down rods (4.5" and 12") to accommodate different ceiling heights. It also supports angled mounting for sloped ceilings up to 8 degrees.




Figure 3: Fan Dimensions and Mounting Options (Downrod and Angled).

2. Blade Attachment

Attach the five carved wood blades securely to the motor assembly. These blades are crafted from solid wood for durability and efficient air delivery.



Figure 4: Premium Quality Wood Blades.

3. Electrical Connection

Connect the fan's DC motor to your home's electrical system. The fan operates on 110 Volts (DC) and is ETL Listed for safety compliance.

Operating Instructions

Your WINGBO ceiling fan is controlled by a convenient handheld remote.



Figure 5: Handy Remote Control Layout.

1. Fan Speed Control

The fan features 6 forward and reverse speeds. Use the speed buttons on the remote to adjust airflow to your preference.

2. Dual-Direction (Summer/Winter Mode)

The reversible DC motor allows for year-round comfort. Use the "Follow/Reverse" button on the remote to switch modes:

- **Summer Mode (Forward Direction):** Blades rotate counter-clockwise to force air down, creating a cooling breeze.
- **Winter Mode (Reverse Direction):** Blades rotate clockwise to gently draw warm air up and circulate it throughout the room.



Figure 6: 6-Speeds Reversible Functionality.

3. LED Light Control

The integrated 24W LED light offers three color temperatures: 3000K (Warm Light), 4500K (Natural Light), and 6000K (Day Light). Use the light control buttons on the remote to cycle through these options or turn the light on/off.



Figure 7: LED 3 Color Temperature Options.

4. Timer Function

Set a timer for 1, 2, 4, or 8 hours using the remote control to automatically turn off the fan.



Figure 8: Set a Timer Function.

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Balance:** Check for any wobbling. If present, ensure all blade screws are tightened and blades are balanced.
- **Light Kit:** The LED light source is integrated and generally does not require replacement.

Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Ensure all connections are secure; Replace remote control battery.
Fan wobbles	Loose blades or mounting hardware; Unbalanced blades.	Tighten all screws; Ensure blades are properly installed; Use balancing kit if necessary.
Light does not work	Loose wire connection to light kit; Remote control issue.	Check light kit wiring; Ensure remote battery is good and paired correctly.
Noisy operation	Loose screws; Motor issue (rare for DC motor).	Tighten all mounting and blade screws; If noise persists, contact customer support.

Specifications

Feature	Detail
Brand	WINGBO
Model Number	SYCF5401
Blade Length	54 Inches
Number of Blades	5
Blade Material	Wood (FSC-Certified)
Motor Type	DC Motor (6-Speed, Reversible)
Light Kit	Integrated LED (24W, 3000K/4500K/6000K)
Power Source	DC
Voltage	110 Volts (DC)
Product Dimensions	54"D x 54"W x 21"H
Item Weight	19.2 Pounds
Control Method	Remote Control
Room Type Recommendation	Living rooms, bedrooms, larger rooms (12'x12' to 18'x18')
Usage Environment	Indoor (Damp Rated)
Certifications	ETL Listed, FSC-Certified Wood

Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official WINGBO website. Keep your proof of purchase for any warranty claims.
Manufacturer: WINGBO
Brand Store: Visit the WINGBO Store on Amazon

© 2024 WINGBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09X56TFCS

More documents and user manuals: **https://manuals.plus/**