WINGBO SYCF6401

WINGBO 64 Inch DC Ceiling Fan User Manual

Model: SYCF6401 | Brand: WINGBO

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your WINGBO 64 Inch DC Ceiling Fan with Lights and Remote Control. This modern ceiling fan features 5 reversible carved wood blades, a 6-speed noiseless DC motor, and an integrated LED light kit. Designed for optimal air circulation and energy efficiency, it is suitable for large indoor spaces such as living rooms, bedrooms, and covered outdoor areas.
Please read this manual thoroughly before beginning installation or operation to ensure safe and proper use of the product. Keep this manual for future reference.

Safety Information

- Always disconnect power at the main circuit breaker before installing, cleaning, or servicing the fan.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electrical Code. If you are unfamiliar with proper electrical wiring, seek the services of a qualified electrician.
- Ensure the installation site can support the weight of the fan (approximately 21.1 pounds).
- Do not bend the blade holders during installation, balancing, or cleaning.
- Keep hands, tools, and other objects clear of the fan blades when the fan is operating.
- This fan is designed for indoor use and damp locations. Do not expose to direct water spray.
- The fan must be installed with a minimum of 7 feet (2.1 meters) clearance from the floor to the bottom of the blades.

Package Contents

Carefully unpack all components and ensure all items are present before discarding packaging materials.

- Ceiling Fan Motor Housing
- 5 Carved Wood Blades
- Integrated LED Light Kit

- Remote Control with Wall Holder
- Downrods (4.5" and 12" lengths)
- Mounting Bracket and Hardware
- Instruction Manual



Image: The WINGBO 64-inch DC Ceiling Fan, showing the brass finish motor housing, five black carved wood blades, integrated LED light, and the included remote control.


Setup and Installation

Professional installation by a qualified electrician is recommended for safety and proper functionality.

1. **Prepare the Installation Site:** Ensure the electrical box is securely mounted and capable of supporting the fan's weight. Turn off power at the circuit breaker.
2. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling electrical box. This fan supports both standard downrod and angled ceiling installations (up to 8 degrees slope).
3. **Assemble Downrod and Motor:** Choose the appropriate downrod (4.5" or 12") for your ceiling height. Attach the downrod to the fan motor housing.
4. **Wire the Fan:** Connect the electrical wires from the fan to the household wiring according to the wiring diagram provided in the full instruction manual.
5. **Mount the Fan:** Carefully lift the fan assembly and hang it on the mounting bracket.
6. **Attach Blades:** Securely attach the five carved wood blades to the motor housing.
7. **Install Light Kit:** Connect and install the integrated LED light kit.
8. **Final Checks:** Ensure all connections are secure and all screws are tightened. Restore power at the circuit breaker.

Dimension

4.5" and 12" down rod included



Mounting options





Ideal for room

20′x20′ or Larger

Image: Diagram illustrating the dimensions of the 64-inch ceiling fan, including the 4.5" and 12" downrod options, and showing both downrod and angled mounting configurations.



Image: Icons representing key features: LED light included, downrod installation, slope ceiling compatibility, reversible motor, easy control, and quick install.

Operating Instructions

Your WINGBO ceiling fan is controlled by the included handheld remote. Ensure batteries are correctly installed in the remote control.

Remote Control Functions:

- **Fan Speed Control:** Buttons 1-6 adjust the fan speed from lowest (1) to highest (6).
- **Fan ON/OFF:** Dedicated button to turn the fan on or off.
- **Light ON/OFF:** Dedicated button to turn the LED light on or off.
- **Light Color Temperature Adjustment:** Cycle through 3000K (Warm Light), 4500K (Natural Light), and 6000K (Day Light) settings.
- **Reversible Motor (Summer/Winter Mode):**
  - **Summer Mode (Forward Direction):** Forces air down to create a cooling breeze.
  - **Winter Mode (Reverse Direction):** Draws cool air up, circulating warm air trapped near the ceiling.
- **Timer Function:** Set the fan to automatically turn off after 1, 2, 4, or 8 hours.



Image: The remote control for the WINGBO ceiling fan, highlighting buttons for fan speed, light control, reverse function, and timer settings.



Image: Visual representation of the fan's reversible function, showing airflow for Summer Mode (downward) and Winter Mode (upward).



Image: Examples of the three available LED light color temperatures: Warm Light (3000K), Natural Light (4500K), and Day Light (6000K).



Image: A graphic demonstrating the timer function, allowing the fan to be set to turn off after 1, 2, 4, or 8 hours.

Maintenance

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or blades. Ensure the fan is turned off and power is disconnected before cleaning.
- **Blade Care:** The carved wood blades are durable. Periodically check for dust accumulation and wipe clean. Avoid excessive moisture.
- **Tightness of Screws:** Periodically check all screws on the fan and downrod for tightness. Retighten as necessary to prevent noise or wobbling.



Image: A close-up view of the fan's premium quality solid wood blades, emphasizing their durable and efficient design.

Troubleshooting

Before attempting any repairs, ensure power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start.	No power to the fan; Loose wire connections; Remote control issues.	Check circuit breaker. Ensure all wire connections are secure. Replace remote batteries or re-pair remote if necessary.
Fan wobbles.	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws. Check for bent blades. Ensure mounting bracket is securely fastened to the ceiling.
Light does not work.	Loose wire connection to light kit; Faulty LED module.	Check light kit wiring connections. If LED module is faulty, contact customer support.

Problem	Possible Cause	Solution
Noisy operation.	Loose screws; Motor issues; Blades hitting an obstruction.	Check and tighten all screws. Ensure no obstructions are near the blades. If noise persists, contact customer support.

Specifications

Feature	Detail
Brand	WINGBO
Model Name	DC Ceiling Fan with Lights and Remote Control
Model Number	SYCF6401
Color	Brass and Black
Product Dimensions	64"D x 64"W x 21"H
Blade Length	64 Inches
Number of Blades	5
Blade Material	Wood (FSC-Certified)
Motor Type	DC Motor (6-Speed, Reversible)
Light Type	Integrated LED (24W, 3000K/4500K/6000K)
Control Method	Remote Control
Voltage	110 Volts (DC)
Item Weight	21.1 Pounds
Indoor/Outdoor Usage	Indoor (Damp Rated)
Certification	ETL Listed



Image: A diagram illustrating the powerful 6-speed DC motor, highlighting its energy efficiency, powerful airflow, and reversible summer/winter modes.

Warranty and Support

For warranty information, technical support, or replacement parts, please contact WINGBO customer service directly.
Refer to the contact information provided with your product packaging or visit the official WINGBO website.
Keep your purchase receipt as proof of purchase for any warranty claims.