

[Manuals.plus](#) /

› [Samsung](#) /

› Samsung Galaxy A73 5G User Manual

Samsung SM-A736BLGHMEA

Samsung Galaxy A73 5G User Manual

Model: SM-A736BLGHMEA | Brand: Samsung

1. INTRODUCTION

The Samsung Galaxy A73 5G is a distinctive smartphone designed for optimal performance and user experience. Its sleek design features an ambient edge that seamlessly integrates the camera with the body, providing both aesthetic appeal and full functionality. This device offers extended battery capacity within a thinner, matte frame.

Key Features

- Vibrant FHD+ Super AMOLED display for stunning visuals.
- Advanced multi-lens camera system for next-level photography.
- Powerful octa-core 5nm processor designed for demanding multitasking.
- Long-lasting 5000 mAh (typical) battery for extended streaming, sharing, and gaming.
- USB Type-C connector for modern connectivity.



Figure 1.1: Front and back view of the Samsung Galaxy A73 5G smartphone, showcasing its sleek design and camera module.

2. SETUP GUIDE

2.1 What's in the Box

Upon unboxing your Samsung Galaxy A73 5G, you should find the following items:

- Samsung Galaxy A73 5G Smartphone
- USB Cable (Type-C)
- SIM Tray Ejector Pin

Note: A power adapter and headphones are not included in the box and must be purchased separately.

2.2 Initial Power On

1. Press and hold the Power/Side key (located on the right side of the device) until the Samsung logo appears.
2. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account sign-in.





Figure 2.1: Right side view of the device, highlighting the power and volume buttons.

2.3 SIM Card Installation

1. Locate the SIM card tray on the side of your device.
2. Insert the provided SIM tray ejector pin into the small hole next to the tray. Push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the tray with the gold contacts facing down. Ensure they are correctly seated.
4. Carefully reinsert the tray into the slot until it clicks into place.





Figure 2.2: Side view of the device, indicating the location of the SIM card tray.

3. OPERATING INSTRUCTIONS

3.1 Display and Navigation

The Galaxy A73 5G features a vibrant Super AMOLED display with a 120 Hz refresh rate, providing smooth scrolling and immersive viewing. Navigate the device using touch gestures, including taps, swipes, and pinches. The display resolution is 1080 x 2400 pixels.







Figure 3.1: Front view of the Samsung Galaxy A73 5G, showcasing its Super AMOLED display.

3.2 Camera Usage

The multi-lens camera system on your Galaxy A73 5G allows for versatile photography. It includes Macro, Ultra-Wide, Wide, and Front cameras. To open the camera app, tap the camera icon on your home screen or lock screen. Select different modes (e.g., Photo, Video, Portrait) by swiping across the screen.

3.3 Connectivity

Your device supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access.
- **Bluetooth:** Pair with wireless headphones, speakers, and other Bluetooth-enabled devices.
- **USB:** Connect to a computer for data transfer or charging using the USB Type-C port.
- **NFC:** Use Near Field Communication for quick pairing and mobile payments.
- **GPS:** Utilize the built-in GPS receiver for location services and navigation.

4. MAINTENANCE AND CARE

4.1 Battery Management

The Galaxy A73 5G is equipped with a 5000 mAh (typical) battery. To optimize battery life:

- Adjust screen brightness and screen timeout settings.
- Close unused apps running in the background.
- Enable power-saving modes when battery is low.
- Avoid exposing the device to extreme temperatures.

4.2 General Device Care

To ensure the longevity of your device:

- Keep the device clean using a soft, lint-free cloth.
- Avoid dropping the device or subjecting it to strong impacts.
- Protect the screen with a screen protector and use a protective case.
- Do not expose the device to water or excessive moisture, as it is not explicitly rated for water resistance in the provided specifications.





Figure 4.1: Back view of the Samsung Galaxy A73 5G, showing the camera module and Samsung branding.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Samsung Galaxy A73 5G.

5.1 Common Issues and Solutions

Issue	Possible Solution
Device not powering on or charging	Ensure the USB cable is securely connected to both the device and a working power adapter. Try a different cable or adapter. If the battery is completely drained, it may take a few minutes to show a charging indicator.
SIM card not detected	Remove the SIM tray and reinsert the SIM card, ensuring it is correctly seated. Restart the device. Check if the SIM card is damaged or try it in another compatible device.
Slow performance or freezing	Close unnecessary background applications. Clear cache from apps. Restart the device. Ensure your device software is up to date. Consider performing a factory reset if issues persist (back up data first).
Camera issues (e.g., blurry images)	Ensure the camera lens is clean and free from smudges. Check for sufficient lighting. Restart the camera app or the device.

5.2 Contact Support

If you encounter issues that cannot be resolved using the above solutions, please contact Samsung customer support or visit an authorized service center. You can find contact information on the official Samsung website or through the Samsung Members app on your device.

6. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	Galaxy A73 5G
Item Model Number	SM-A736BLGHMEA
Operating System	Android 12.0
Installed RAM Size	8 GB
Memory Storage Capacity	256 GB
CPU Model	Snapdragon
CPU Speed	2.4 GHz
Screen Size	6.7 inches

Feature	Specification
Resolution	1080 x 2400
Refresh Rate	120 Hz
Display Technology	AMOLED
Other Camera Features	Macro, Ultra-Wide, Wide, and Front Camera
Battery Power Rating	5000 mAh (typical)
Connectivity Technologies	Bluetooth, Wi-Fi, USB, NFC
Wireless Communication Technologies	Cellular
Special Features	Camera, Octa-Core Processor, USB, GPS Receiver
Product Dimensions	16.37 x 7.61 x 0.76 cm
Item Weight	290 grams
Color	Green
Form Factor	Bar
Audio Jack	No
Date First Available	April 15, 2022

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Your Samsung Galaxy A73 5G comes with a standard manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Samsung support website. Extended protection plans may also be available for purchase.

7.2 Customer Support

For further assistance, technical support, or service inquiries, please contact Samsung customer support. You can find contact details, FAQs, and service center locations on the official [Samsung Store page](#) or through the Samsung Members application on your device.