Realspace 78148994

Realspace® Smart Electric 48"W Height-Adjustable Standing Desk User Manual

Model: 78148994

Product Overview

The Realspace Smart Electric Height-Adjustable Standing Desk is designed to enhance work productivity and support personal health and wellness by allowing seamless transitions between sitting and standing positions. This desk integrates advanced technology for personalized movement goals, reminders, and progress tracking through a compatible mobile application. It features built-in power solutions, ample storage, and efficient cable management to maintain an organized workspace.

- **Smart Desk Technology:** Pairs with mobile and tablet devices via a downloadable app for enhanced control and tracking.
- **Electronic Lift Control:** Adjusts surface height from 29-1/2 inches to 49-1/5 inches.
- **Voice Control:** Compatible with Hey Google and Alexa for hands-free height adjustments.
- **Height Memory:** Stores up to 4 customized height levels for quick recall.
- **Wellness Mode:** Allows users to set movement goals, receive reminders, and track progress for a healthier workday.
- **Integrated Power & Charging:** Includes 3 USB ports (2 Type-A, 1 Type-C) for convenient device charging.
- **Cable Management:** Built-in solution to organize cables, power strips, and surge protectors.
- **Storage:** Features two front drawers for office supplies and accessories.
- **Anti-Collision System:** Prevents damage by stopping movement if an obstruction is detected.



Figure 1: The Realspace Smart Electric Height-Adjustable Standing Desk, showcasing its clean design with a natural wood top and white frame.

Setup and Assembly

The Realspace Smart Electric Standing Desk is designed for minimal and straightforward assembly, with the top arriving fully assembled. All necessary assembly tools are included in the package. Due to its weight and size, it is recommended that more than one person handle the product during setup to ensure safety and ease of installation.

- **Unpacking:** Carefully remove all components from the single shipping box. Ensure all parts are present before beginning assembly.
- **Positioning:** Choose a suitable location for your desk, ensuring adequate space for height adjustments and movement.
- **Assembly:** Follow the included assembly guide for specific steps to attach the legs and connect the electronic components.
- **Power Connection:** Once assembled, connect the desk to a standard power outlet.




Figure 2: A detailed front view of the desk, showing the two convenient storage drawers and the discreetly placed control panel for height adjustment.

Operating Instructions

Height Adjustment

The desk's height can be adjusted electronically using the control panel or via voice commands.

- **Manual Adjustment:** Use the up and down arrows on the control panel to precisely adjust the desk height between 29-1/2 inches and 49-1/5 inches.
- **Memory Presets:** The desk allows you to save up to 4 preferred height settings. To save a height, adjust the desk to the desired level, then press and hold one of the numbered memory buttons (1, 2, 3, or 4) until the display confirms the setting is saved. To recall a saved height, simply press the corresponding numbered button.
- **Voice Control:** Integrate your desk with Hey Google or Alexa-enabled devices. Once connected, you can use voice commands to raise or lower the desk. Refer to your smart home device's instructions for connecting new devices.



Figure 3: User interacting with the intuitive control panel to adjust the desk's height.



Figure 4: The desk supports voice control via Amazon Alexa and Hey Google, offering convenient hands-free operation.

Smart Features and Connectivity

The desk's smart technology allows for enhanced functionality through a dedicated mobile application.

- **App Compatibility:** Download the compatible app on your Android or Apple device. The desk supports 2.4GHz Wi-Fi networks for connectivity.
- **Wellness Mode:** Utilize the app to set personal movement goals, receive reminders to switch between sitting and standing, and track your progress over time.
- **USB Charging Ports:** The desk is equipped with 3 USB ports (2 Type-A and 1 Type-C) for convenient charging of your electronic devices. These are located for easy access.



Figure 5: The integrated USB ports provide convenient charging for mobile phones and other devices.

Safety Features

- **Anti-Collision System:** The desk is equipped with an anti-collision system that automatically stops movement if an obstruction is detected during height adjustment, preventing potential damage to the desk or objects.

Maintenance and Care

To ensure the longevity and optimal performance of your Realspace Smart Electric Standing Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Periodically check and organize cables within the cable management compartment to prevent tangling and ensure proper function.
- **Inspection:** Regularly inspect all connections and moving parts for any signs of wear or looseness. Tighten screws if necessary.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 340 pounds to prevent strain on the motor and frame.

Troubleshooting

If you encounter issues with your Realspace Smart Electric Standing Desk, please refer to the following common troubleshooting tips. If the problem persists, contact customer support.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Desk does not move or respond to controls.	Power disconnected, motor error, or control panel issue.	1. Ensure the power cord is securely plugged into both the desk and a working wall outlet. 2. Check for any obstructions under or around the desk that might trigger the anti-collision system. 3. Try resetting the desk by unplugging it for 30 seconds and then plugging it back in.
Desk displays an error code (e.g., E-07).	Specific system malfunction.	1. Consult the full product manual (if available) for specific error code definitions. 2. Attempt a full reset as described above. 3. If the error persists, the control module may need replacement. Contact customer support.
Desk moves unevenly or makes unusual noises.	Uneven load, loose components, or motor issue.	1. Ensure weight is evenly distributed on the desk surface. 2. Check all assembly screws and connections to ensure they are tight. 3. Verify that nothing is obstructing the legs' movement.

Specifications

Brand	Realspace
Model Number	78148994
UPC	735854733193
Product Dimensions (D x W x H)	23.6"D x 53.9"W x 29.5"H
Adjustable Height Range	29.5 inches (Minimum) to 49.42 inches (Maximum)
Color	White/Natural
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood
Finish Type	Protective Coating
Special Feature	Electric, Height-Adjustable, Smart Technology, Voice Control
Included Components	Built-in USB ports (2 Type-A, 1 Type-C), Front drawers, Cable management compartment
Number of Drawers	2
Item Weight	101.6 Pounds

Maximum Weight Recommendation	340 Pounds
Required Assembly	Yes (Minimal)
Manufacturer	OFFICE DEPOT

Warranty and Support

The Realspace Smart Electric Height-Adjustable Standing Desk comes with a**Limited Warranty** covering parts and labor. For specific details regarding the warranty period and coverage, please refer to the warranty documentation included with your purchase or contact Realspace customer service.

Customer Support

For any questions, technical assistance, or to inquire about in-home assembly services, please contact our certified and insured professional assemblers at:

866-388-4350

Additional support and product information may be available on the official Realspace website or through your retailer.

© 2024 Realspace. All rights reserved.