

[manuals.plus](#) /› [Fuzion](#) /› [Fuzion X-3 Pro Stunt Scooter User Manual](#)**Fuzion X-3**

Fuzion X-3 Pro Stunt Scooter User Manual

Model: X-3 | Brand: Fuzion

1. INTRODUCTION

This manual provides essential information for the assembly, safe operation, maintenance, and care of your Fuzion X-3 Pro Stunt Scooter. Designed for entry-level riders, the Fuzion X-3 features a lightweight and durable 4-inch wide, 6061 aluminum box-shaped concave deck, suitable for various tricks. It includes an upgraded neck and fork, solid core 100mm wheels, and a custom nylon/steel brake for quick, quiet stops. Please read this manual thoroughly before use to ensure proper function and safety.

2. SAFETY INFORMATION

- Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads.
- Ensure all bolts and clamps are securely tightened before each ride.
- Ride in safe, open areas away from traffic, pedestrians, and other hazards.
- Do not ride on wet or uneven surfaces.
- The scooter is designed for riders aged 7 years and up, with a maximum weight limit of 220 pounds.
- Adult supervision is recommended for younger riders.

3. SETUP AND ASSEMBLY

The Fuzion X-3 Pro Stunt Scooter is designed for effortless assembly, typically requiring only three bolts to tighten. It comes 95% pre-assembled, allowing you to start riding quickly.

Included Components:

- Fuzion X-3 Pro Scooter (deck with front wheel and fork pre-assembled)
- Handlebar
- Allen Wrench Tool

- User Manual

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all listed components are present.
2. **Attach Handlebar:** Slide the handlebar stem onto the fork tube. Ensure the handlebar is facing forward and aligned with the front wheel.
3. **Secure Clamp:** Use the provided Allen wrench tool to tighten the bolts on the handlebar clamp. Tighten them evenly and securely to prevent any movement during use.
4. **Final Check:** Before riding, double-check all connections and ensure everything is tight and secure.



Figure 1: Fully assembled Fuzion X-3 Pro Stunt Scooter.

4. OPERATING INSTRUCTIONS

Riding:

- Place one foot firmly on the deck of the scooter.
- Use your other foot to push off the ground, gaining momentum.
- Once moving, place both feet on the deck, one behind the other, or side-by-side, depending on your comfort and riding style.
- Steer by leaning and gently turning the handlebars in the desired direction.

Braking:

The Fuzion X-3 is equipped with a high-strength nylon/steel brake for quick and quiet stops.

- To slow down or stop, gently press your foot down on the rear fender brake.
- Apply pressure gradually to avoid sudden stops, which can lead to loss of balance.



Figure 2: Detail of the custom Enigma brake system.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Cleaning:** Wipe down the scooter with a damp cloth after use to remove dirt and debris. Avoid using harsh

chemicals.

- **Check Fasteners:** Periodically inspect all bolts, screws, and clamps for tightness. Tighten any loose fasteners using the provided Allen wrench.
- **Wheel Inspection:** Check the 100mm cast PU wheels for wear and tear. Replace wheels if they show significant damage or flat spots.
- **Bearings:** Listen for any unusual noises from the wheels or headset, which may indicate worn bearings. Consult a professional for bearing replacement if needed.
- **Brake Function:** Ensure the nylon/steel brake is functioning correctly and provides adequate stopping power.



Figure 3: The solid core 100mm wheels are designed for durability.

UPGRADED TOUGH NECK DESIGN

☒ STRONG & LIGHT CONSTRUCTION

FAZE 2.0 FORK

☒ FITS UP TO 110MM WHEELS*

*X-3 COMES WITH 100MM WHEELS



Figure 4: The upgraded neck design and Faze 2.0 fork.

6. TROUBLESHOOTING

- **Loose Handlebars:** If handlebars feel wobbly, re-tighten the clamp bolts evenly with the Allen wrench.
- **Squeaky Wheels:** This may indicate dirt or worn bearings. Clean the wheel area and check bearings. If noise persists, consider professional inspection.
- **Ineffective Brake:** Ensure the brake mechanism is clear of debris and properly aligned. If the brake pad is worn, it may need replacement.
- **Unusual Noises:** Stop riding immediately if you hear any unusual noises. Inspect all parts for damage or looseness.

7. SPECIFICATIONS

Feature	Specification
Brand	Fuzion

Model Name	Fuzion X-3
Age Range (Description)	Youth (7+ Years)
Weight Limit	220 Pounds
Product Dimensions	31.75" L x 4" W x 27.25" H
Item Weight	6.9 Pounds
Frame Material	Aluminum
Wheel Material	Polyurethane
Wheel Size	100 Millimeters
Wheel Type	Solid
Brake Style	Front Braking (Nylon/Steel)
Special Feature	Aircraft-Grade Aluminum, Fuzion Pro Scooters premium parts, 95% Pre-Assembled

8. WARRANTY AND SUPPORT

The Fuzion X-3 Pro Stunt Scooter comes with a **1 Year Limited Warranty** on Manufacturer Defects. Additionally, there is a **Free replacement for easy-wearing parts within 6 months** of purchase.

For warranty claims, technical support, or any questions regarding your scooter, please contact the manufacturer, Nextsport, or visit the official Fuzion Pro Scooters website for assistance.

© 2024 Fuzion. All rights reserved.

Related Documents - X-3

