

[manuals.plus](#) /

› [SENSEA](#) /

› [SENSEA Easy 3L Round Metal Bathroom Bin Instruction Manual](#)

SENSEA 3276000700043

SENSEA Easy 3L Round Metal Bathroom Bin Instruction Manual

Model: 3276000700043

1. INTRODUCTION

Thank you for choosing the SENSEA Easy 3L Round Metal Bathroom Bin. This manual provides essential information for the proper setup, operation, and maintenance of your new bin. Please read these instructions carefully before use and retain them for future reference.

2. PRODUCT OVERVIEW

The SENSEA Easy 3L Round Metal Bathroom Bin is designed for discreet waste disposal in bathroom environments. Its compact size and pedal-operated lid offer convenience and hygiene. The bin features a removable inner bucket for easy cleaning and a soft-close lid mechanism.



Image 2.1: The SENSEA Easy 3L Round Metal Bathroom Bin in its closed position, showcasing its matte white finish and pedal mechanism.



Image 2.2: The bin with its lid open, revealing the internal structure and the soft-close mechanism.

3. SETUP

- 1. Unpacking:** Carefully remove the bin from its packaging. Ensure all components are present: the outer metal bin, the inner plastic bucket, and the lid assembly.
- 2. Inner Bucket Placement:** Insert the black plastic inner bucket into the metal outer bin. Ensure it sits securely at the bottom.
- 3. Liner Installation (Optional):** If using a bin liner, place it inside the inner bucket, folding the edges over the rim of the inner bucket to secure it.
- 4. Positioning:** Place the bin in your desired location in the bathroom. The compact design is suitable for small spaces.



Image 3.1: The outer bin and the removable inner plastic bucket, illustrating how the inner bucket can be taken out for setup or emptying.

4. OPERATING INSTRUCTIONS

- **Opening the Lid:** To open the lid, gently press down on the foot pedal located at the base of the bin. The lid will open smoothly.
- **Closing the Lid:** Release the foot pedal. The lid is equipped with a soft-close mechanism, ensuring it closes quietly and gently without slamming.
- **Emptying the Bin:**
 - a. Open the lid using the foot pedal.
 - b. Grasp the handle of the inner plastic bucket and lift it out of the metal outer bin.
 - c. Dispose of the waste.
 - d. Return the inner bucket to the outer bin, ensuring it is seated correctly.

- **Transporting the Bin:** The bin features a handle at the back for easy relocation. Grasp this handle to move the bin as needed.



Image 4.1: A close-up view of the integrated handle located at the rear of the bin, designed for convenient transport.

5. MAINTENANCE AND CLEANING

- **Exterior Cleaning:** Wipe the exterior of the metal bin with a soft, damp cloth and a mild, non-abrasive cleaner. Dry thoroughly with a soft cloth to prevent water spots. Avoid harsh chemicals or abrasive materials that could damage the finish.
- **Inner Bucket Cleaning:** The inner plastic bucket can be washed with warm soapy water. Rinse thoroughly and allow it to dry completely before placing it back into the outer bin.
- **Pedal Mechanism:** Periodically check the pedal mechanism for any debris that might hinder its smooth operation. Clean as necessary. Do not lubricate the mechanism unless specifically instructed by the manufacturer.

- **Lid Mechanism:** The soft-close mechanism is designed for durability. Avoid forcing the lid open or closed, as this may damage the mechanism.


6. TROUBLESHOOTING

- **Lid not closing softly:**
 - Check for any obstructions around the lid or the hinge mechanism.
 - Ensure the inner bucket is correctly seated and not interfering with the lid's movement.
 - Avoid forcing the lid, as this can damage the soft-close feature.
- **Pedal mechanism feels stiff:**
 - Inspect the pedal and its connection points for any dirt or debris. Clean if necessary.
 - Ensure the bin is placed on a flat, stable surface.
- **Bin appears unstable:**
 - Verify that the bin is on a level surface.
 - Ensure the inner bucket is properly inserted and not causing an imbalance.

7. SPECIFICATIONS

Brand	SENSEA
Model Number	3276000700043
Capacity	3 Litres
Dimensions (L x W x H)	28 x 17 x 23 cm
Material	Metal
Mechanism	Pedal
Color	White (Matte)
Shape	Cylindrical

3L



Ø 16,8 cm



Image 7.1: A diagram illustrating the key dimensions (height, diameter) and capacity of the 3L SENSEA Easy Bathroom Bin.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your SENSEA Easy 3L Round Metal Bathroom Bin, please contact your retailer or the manufacturer, ADEO. Please refer to your purchase documentation for specific warranty details, as availability of spare parts information is not provided.