

manuals.plus /

› [oneisall](#) /

› [oneisall X2 Cat Clipper Instruction Manual](#)

oneisall X2

oneisall X2 Cat Clipper Instruction Manual

Model: X2

1. PRODUCT OVERVIEW

The oneisall X2 Cat Clipper is designed for efficient and quiet pet grooming, especially for cats with matted or thick hair. It features a low-noise motor, ceramic and titanium blades, and a long-lasting battery for cordless operation.



Image: The oneisall X2 Cat Clipper, a cordless grooming tool.

- **Quiet Operation:** Designed with a low-noise motor (less than 50 dB) to minimize pet anxiety during grooming.
- **Powerful Motor:** Two-speed settings (5500 rpm and 6000 rpm) for effective cutting through various hair types.
- **Durable Blades:** Ceramic and titanium blades offer sharpness and longevity, preventing rust and dullness.
- **Long Battery Life:** 3-hour charge provides up to 300 minutes of cordless use, with an LCD display for battery status.
- **Complete Grooming Kit:** Includes 6 guide combs (3mm, 6mm, 9mm, 12mm, 15mm, 18mm), cleaning brush, maintenance oil, and scissors.

2. SAFETY INFORMATION

- Avoid contact with eyes and face.
- Prevent your pet from ingesting or inhaling small parts.
- Clean the device thoroughly after each use.
- This product must be used under adult supervision.
- Always handle blades with care to prevent injury.
- Do not immerse the clipper in water.

3. SETUP AND CHARGING

Before first use, ensure the clipper is fully charged. The LCD display will indicate the charging status.

1. **Charge the Clipper:** Connect the clipper to a power source using the provided USB cable. Charge for 3 hours before the first use. The LCD screen will show battery percentage.
2. **Attach the Blade:** Ensure the ceramic and titanium blade is securely screwed onto the clipper.
3. **Select Guide Comb (Optional):** Choose the desired guide comb (3mm, 6mm, 9mm, 12mm, 15mm, or 18mm) and attach it firmly to the blade for specific hair lengths.

Shave 4 Cats on a Single Charge



2000mAH
Long Battery Life



Image: The clipper displaying battery charge levels on its LCD screen.

Make Your Cat in Varied Looks



Image: The clipper shown with six different guide combs for varying hair lengths.

4. OPERATING INSTRUCTIONS

Follow these steps for effective and safe grooming of your pet.

1. **Prepare Your Pet:** Ensure your pet is calm and comfortable. Brush their fur to remove loose hair and tangles before clipping.

2. **Turn On and Select Speed:** Press the power button to turn on the clipper. Select the desired speed (5500 rpm or 6000 rpm) using the speed adjustment switch.
3. **Begin Clipping:** Guide the clipper smoothly over your pet's fur.
 - Trim along the cat's back hair.
 - Carefully trim the cat's tail hair.
 - Trim the cat's belly hair, being mindful of sensitive areas.
 - Trim the hair around the cat's hindquarters.
 - Trim the hair on the cat's legs and paws.
 - Consider creating a "lion-cut" style if desired, by leaving fur on the head, paws, and tail tip.
4. **Observe Pet's Reaction:** If your pet shows signs of distress, take a break and resume when they are calmer. The low noise design helps reduce anxiety.
5. **Cordless or Corded Use:** The clipper can be used wirelessly after charging or while connected to the power supply.



Image: A cat being groomed with the oneisall X2 clipper, highlighting its quiet operation.



Image: The clipper effectively cutting through matted hair, demonstrating its powerful performance.

The Best Gift for Your Baby Cat



Image: Step-by-step guide on grooming different parts of a cat's body with the clipper.

Your browser does not support the video tag.

Video: Demonstration of the oneisall X2 Cat Clipper in use, showing its effectiveness on matted hair and quiet operation.

5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your clipper.

1. **Clean After Each Use:** Use the provided cleaning brush to remove hair from the blades and inside the clipper head.
2. **Oil the Blades:** Apply a few drops of the maintenance oil to the blades after cleaning to keep them lubricated and sharp.
3. **Store Properly:** Store the clipper in a dry, safe place away from children and pets.
4. **Detachable Blade:** The ceramic blade is detachable for easy cleaning and replacement.

Detachable

Washable Ceramic Blade



Image: The detachable ceramic blade, illustrating ease of cleaning and maintenance.

6. TROUBLESHOOTING

If you encounter issues with your oneisall X2 Cat Clipper, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clipper not turning on	Low battery or not charged	Charge the clipper for 3 hours. Check the LCD display for battery level.
Clipper pulling hair or cutting poorly	Blades are dull, dirty, or not properly oiled	Clean the blades thoroughly and apply maintenance oil. Ensure blades are securely attached. Consider replacing blades if dull.
Excessive noise or vibration	Hair caught in the motor or loose blade	Turn off the clipper and carefully remove any trapped hair. Ensure the blade is securely attached.
Clipper not holding a charge	Battery degradation	Contact customer support for assistance or battery replacement options.

7. SPECIFICATIONS

Feature	Detail
Model Number	X2
Product Dimensions (L x W x H)	19 x 22 x 6.5 cm
Weight	600 Grams
Battery Type	Lithium-ion (1 AA battery included)
Charging Time	3 hours
Operating Time	Up to 300 minutes (5 hours)
Noise Level	Less than 50 dB
Blade Material	Metal and Ceramic (Titanium blades)
Speed Settings	2 speeds (5500 rpm, 6000 rpm)
Special Features	Rechargeable, Cordless, Silent Design, LCD Display
Certifications	FCC, CE, UKCA



Image: Detailed view of the clipper with its dimensions and key specifications.

8. WARRANTY AND SUPPORT

oneisall is committed to providing high-quality products and customer satisfaction.

- **Warranty:** This product comes with a 2-year warranty.
- **Customer Service:** For any questions, concerns, or support needs, please contact our 24-hour customer service.

- **Online Resources:** Visit the official oneisall brand store for additional product information and support: [oneisall Brand Store](#).