

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Keurig](#) /

› [Keurig K-Supreme Single Serve Coffee Maker Instruction Manual](#)

Keurig K-Supreme

Keurig K-Supreme Single Serve Coffee Maker Instruction Manual

Model: K-Supreme

Brand: Keurig

INTRODUCTION

Welcome to the Keurig K-Supreme Single Serve Coffee Maker. This manual provides essential information for setting up, operating, and maintaining your new coffee brewer. The K-Supreme features MultiStream Technology for enhanced flavor extraction, customizable brew options, and a convenient dual-position water reservoir.

PRODUCT FEATURES

- **MultiStream Technology:** Designed to more evenly saturate coffee grounds in every K-Cup pod, extracting full flavor and aroma.
- **Customizable Brewing:** Offers a 'Strong' button for a more intense coffee taste and an 'Over Ice' button for refreshing iced coffee.
- **Multiple Brew Sizes:** Choose from 6, 8, 10, or 12 oz brew sizes to suit your preference.
- **66 oz Dual-Position Water Reservoir:** A large, removable water reservoir that can be positioned on either side of the brewer for optimal counter space and easy refilling.
- **3-Month Brewer Maintenance Kit:** Includes Keurig Descaling Solution, Water Filter Cartridges, and Rinse Pods for comprehensive brewer care.



An image showcasing the Keurig K-Supreme coffee maker with callouts for its key features: MultiStream Technology for enhanced flavor, options for strong or over-ice brewing, four available cup sizes (6, 8, 10, 12 oz), and a large 66 oz dual-position water reservoir.

INITIAL SETUP

Unpacking

Carefully remove all components from the packaging. Remove any protective tapes or films from the brewer and water reservoir.

Water Filter Preparation

For optimal water quality and brewer longevity, prepare and install the water filter:

1. Soak the water filter cartridge in fresh water for 5 minutes.
2. Rinse the cartridge under running water for 60 seconds.
3. Insert the prepared water filter cartridge into the filter holder.
4. Snap the filter holder into the base of the water reservoir.



A close-up image of the Keurig 3-Month Brewer Maintenance Kit, showing the descaling solution bottle, two water filter cartridges, and four rinse pods.

Filling the Water Reservoir

Remove the water reservoir from the brewer. Fill it with fresh, filtered water up to the MAX fill line. Replace the reservoir securely on the brewer.

Initial Rinse Brew

Place a large mug on the drip tray. Do not insert a K-Cup pod. Press the power button, then select the largest brew size (12 oz) to perform a cleansing brew. Discard the hot water. The brewer is now ready for use.

OPERATING INSTRUCTIONS

Step-by-Step Brewing

1. Ensure the water reservoir is filled with fresh water.
2. Lift the brewer handle.
3. Place a K-Cup pod into the K-Cup pod holder.
4. Lower the handle completely to close the lid.
5. Place a mug on the drip tray.
6. Select your desired brew size (6, 8, 10, or 12 oz).
7. For a stronger coffee, press the **STRONG** button before selecting the brew size.
8. For iced coffee, fill a large cup with ice, place it on the drip tray, and press the **OVER ICE** button before selecting the brew size.
9. The brew button will illuminate. Press it to start brewing.
10. The brew will complete when the selected amount of coffee is dispensed.



A Keurig K-Supreme coffee maker in black, actively dispensing coffee into a red mug, with its clear water reservoir visible on the left.

KEURIG K-Supreme™

SINGLE SERVE COFFEE MAKER



MULTISTREAM TECHNOLOGY™

Extracts more flavor and aroma* in every brew

*vs. Keurig® leading K-Classic® brewer with The Original Donut Shop® Coffee K-Cup® pod



CUSTOMIZE YOUR CUP

Brew a stronger cup, or brew hot over ice for refreshing iced coffee



MULTIPLE BREW SIZES

Brew a 6, 8, 10, or 12 oz. cup



66 oz. DUAL-POSITION RESERVOIR

Choose the perfect position for optimal counter space. Removable reservoir makes refilling easy



A detailed view of the Keurig K-Supreme's K-Cup pod holder, showing the MultiStream Technology nozzles designed to evenly saturate coffee grounds for optimal flavor extraction.

MAINTENANCE

Descaling

Descal your brewer every 3 months or when the "DESCALE" indicator light illuminates. Use Keurig Descaling Solution. Follow the instructions provided with the descaling solution for best results.

Water Filter Replacement

Replace the water filter cartridge every 2 months or 60 tank refills. Refer to the water filter instructions for detailed replacement steps. Note: K-Mini brewers do not use water filter handles.

Using Rinse Pods

Use Keurig Rinse Pods weekly or after brewing flavored beverages to reduce flavor carry-over. Insert a rinse pod like a regular K-Cup pod and perform a 10 oz brew. Discard the rinse pod and hot water.



A close-up image of a Keurig Rinse Pod, emphasizing its role in improving beverage taste, safe and effective formula, compatibility with all Keurig coffee makers, and that 4 pods are included in the maintenance kit.

General Cleaning

Regularly wipe down the exterior of the brewer with a damp cloth. The drip tray and water reservoir can be removed and washed with warm, soapy water. Rinse thoroughly.

TROUBLESHOOTING COMMON ISSUES

"ADD WATER" Indicator

If the "ADD WATER" light is on, the water reservoir is low. Refill the reservoir with fresh water. Ensure the reservoir is seated correctly.

"DESCALE" Indicator

The "DESCALE" light indicates it's time to descale your brewer. Follow the descaling instructions in the Maintenance section.

No Power

Ensure the brewer is securely plugged into a grounded outlet. Check if the outlet is functional by plugging in another appliance.

Coffee Not Brewing

Verify the water reservoir is filled and properly seated. Ensure a K-Cup pod is correctly inserted and the handle is fully lowered. Check for any error messages on the control panel.

PRODUCT SPECIFICATIONS

| Property | Value |
|---------------------|---------------------------------------------------------|
| Brand | Keurig |
| Model | K-Supreme |
| Color | Black |
| Special Feature | Removable Tank, Water Filter |
| Coffee Maker Type | Drip Coffee Machine |
| Style | Maker + Coffee Maker, Black |
| Specific Uses | Iced Coffee |
| Recommended Uses | Everyday use, Brewing strong coffee, Making iced coffee |
| Exterior Finish | Matte |
| Included Components | Filter |
| Operation Mode | Fully Automatic |
| Capacity | 12 ounces (brew), 66 ounces (reservoir) |
| First Available | April 6, 2022 |

WARRANTY AND CUSTOMER SUPPORT

For detailed warranty information and customer support, please refer to the official Keurig website or contact Keurig customer service directly. It is recommended to keep your purchase receipt as proof of purchase.

Official Keurig Website: www.keurig.com