

Juboos CANO002

Juboos Kids Analog Quartz Watch (Model CANO002) Instruction Manual

Model: CANO002

INTRODUCTION

Thank you for choosing the Juboos Kids Analog Quartz Watch. This watch is designed for children aged 6-15, featuring a precise Japanese quartz movement, a durable and comfortable strap, and a fun 7-color backlight. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure long-lasting enjoyment.

Key features include:

- **7-Color Backlight:** Easily toggle between seven vibrant LED colors for visibility in low light.
- **Precise Timekeeping:** Equipped with a reliable Japanese quartz movement for accurate time.
- **Easy-to-Read Dial:** Clear analog display designed for children to learn to tell time.
- **Durable & Comfortable:** Features a soft Thermoplastic Polyurethane (TPU) strap and a protective film on the dial and back to prevent scratches.
- **30M Water Resistance:** Suitable for daily activities like hand washing and splashes, but not for swimming or diving.

SETUP

1. Unpacking and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Ensure all protective films are removed from the watch face and back before use.

2. Setting the Time

To set the correct time, follow these steps:

1. **Pull the Crown:** Gently pull the crown (the small knob on the side of the watch) outwards until you hear a soft click.
2. **Turn the Crown:** Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the desired time.
3. **Push the Crown:** Once the time is set, push the crown back into its original position to start the watch movement.



Image Description: This image illustrates the three-step process for setting the time on the watch: pulling out the crown, rotating it to adjust the hands, and pushing it back in. It also reminds users to remove the protective film from the watch's back cover.

OPERATING INSTRUCTIONS

1. Reading the Time

The watch features a clear analog dial with hour, minute, and second hands. The numbers are large and easy to read, aiding children in learning to tell time.

2. Using the 7-Color Backlight

The watch is equipped with a colorful LED backlight for improved visibility in dark environments.

- **Activate Backlight:** Press and hold the "backlight" button (typically located on the side of the watch) for approximately 3 seconds.
- **Change Colors:** Continue to press and hold the backlight button to cycle through the seven available LED colors. Release the button when your desired color is displayed.

Seven backlight colors

Press and hold the "backlight" button for 3s to toggle the LED color



Backlight Button



Normal Display

Backlight Display

Image Description: This image demonstrates the watch's 7-color backlight feature. It shows the watch in its normal state and then with the backlight activated, cycling through various colors. The backlight button is clearly marked.

3. Water Resistance Guidelines

The watch has a water resistance rating of 30 meters (3 ATM), making it suitable for:

- Rainwater exposure
- Hand washing
- Light water splashes during play

Important: Do not press any buttons while the watch is wet or submerged in water. Avoid wearing the watch for prolonged underwater activities such as swimming, diving, or showering, as this can compromise its water resistance and shorten its lifespan.

98FT/30M Waterproof



Rainwater



Hand washing



Water Play

Image Description: This image visually confirms the watch's 30M water resistance, showing the watch with water droplets and a child enjoying water play, indicating suitability for everyday water exposure.

MAINTENANCE

1. Cleaning the Watch

To keep your watch clean, wipe it regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or strap.

2. Battery Replacement

The watch is powered by one Lithium metal battery. When the watch stops or the backlight dims significantly, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

3. Strap Care

The soft TPU strap is designed for comfort and durability. To prolong its life, avoid prolonged exposure to direct sunlight or extreme temperatures. Clean the strap with mild soap and water if necessary, and rinse thoroughly.



Image Description: This image highlights key components of the watch's construction, including the stainless steel back cover, the internal Japanese movement, and the soft TPU strap with its stainless steel buckle, emphasizing quality and comfort.

TROUBLESHOOTING

- **Watch is not keeping accurate time:**

Ensure the crown is fully pushed in. If the issue persists, the battery may be low and require replacement.

- **Backlight is dim or not working:**

This typically indicates a low battery. Replace the battery as described in the Maintenance section.

- **Condensation inside the watch:**

While the watch is 30M water resistant, pressing buttons underwater or prolonged exposure to steam (e.g., hot showers) can cause moisture ingress. If condensation appears, place the watch in a dry, warm place (not hot) to allow the moisture to evaporate. If it persists, seek professional watch repair.

- **Strap discomfort or irritation:**

Ensure the strap is not too tight. Clean the strap regularly to prevent buildup of dirt or sweat. If irritation continues, discontinue use and consult a doctor.

SPECIFICATIONS

Feature	Specification
Model Number	CANO002
Brand	Juboos
Movement Type	Japanese Quartz
Display Type	Analog
Water Resistance Depth	30 Meters (3 ATM)
Battery Type	1 Lithium Metal (included)
Product Dimensions (L x W x H)	22 x 3.51 x 1.5 cm
Item Weight	26 Grams
Band Material Type	Thermoplastic Polyurethane (TPU)
Case Material Type	Polycarbonate
Dial Window Material Type	Crystal
Dial Case Diameter	3.5 cm
Band Width	1.5 cm
Band Length	23 cm
Age Range Description	Child
Special Features	Waterproof, 7-Color Backlight



Image Description: This image provides a visual representation of the watch's dimensions, including the band width, length, dial diameter, and thickness, along with the maximum and minimum wrist circumference it can fit, and the overall product weight.

WARRANTY & SUPPORT

Warranty Information

This Juboos watch comes with a **Limited Warranty**. Please refer to the warranty card included with your purchase for specific terms and conditions. The warranty typically covers manufacturing defects but may not cover damage caused by improper use, accidents, or unauthorized repairs.

Customer Support

For any questions, concerns, or technical assistance regarding your Juboos Kids Analog Quartz Watch, please contact the seller or refer to the customer support information provided at the point of purchase. When contacting support, please have your model number (CANO002) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XB6X28D>

More documents and user manuals: <https://manuals.plus/>