Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AEG SKE814D9ZC (923794016)

AEG Built-in Refrigerator User Manual

Model: SKE814D9ZC (923794016)

1. Introduction

Thank you for choosing an AEG appliance. This manual provides essential information for the safe and efficient use of your new built-in refrigerator. Please read these instructions carefully before installation and use, and keep them for future reference.
The AEG SKE814D9ZC is a 1400 mm built-in refrigerator with a 209 L capacity, designed for seamless integration into your kitchen cabinetry. It features a reversible door and advanced soft-closing technology for convenience and durability.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the appliance is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Only qualified personnel should perform installation and repairs.
- Unplug the appliance before cleaning or maintenance.

3. Product Overview

The AEG SKE814D9ZC refrigerator is designed for optimal food storage, featuring adjustable shelves and specialized drawers.



Figure 3.1: Full interior view of the AEG SKE814D9ZC refrigerator.

The interior includes multiple glass shelves for flexible storage, door bins for bottles and smaller items, and dedicated drawers for fresh produce and sensitive items.



Figure 3.2: Specialized drawers for optimal storage of different food types.



Figure 3.3: LongFresh drawers designed to keep fish and vegetables fresh longer.



Figure 3.4: Adjustable glass shelves for flexible storage configurations.




Figure 3.5: Clear door bins for convenient storage of bottles and smaller items.

4. Installation and Setup

This refrigerator is designed for built-in installation. Proper ventilation is crucial for efficient operation.

4.1 Dimensions and Recess

Ensure the cabinet recess meets the required dimensions for proper fit and ventilation.




Figure 4.1: Installation dimensions for the appliance and cabinet.

The appliance dimensions are approximately 21.65"D x 22.05"W x 55.12"H (55 x 56 x 140 cm). The required recess height is 1400 mm.

4.2 Door Reversibility

The door hinges are reversible, allowing you to change the door opening direction to suit your kitchen layout. Refer to the detailed installation guide provided with the appliance for step-by-step instructions on reversing the door.



Figure 4.2: Detail of the soft-closing door mechanism.

4.3 Electrical Connection

Connect the appliance to a properly grounded electrical outlet. Ensure the voltage and frequency match the specifications on the rating plate.

5. Operating the Appliance

5.1 Temperature Control

The refrigerator features an electronic temperature control panel, typically located at the top interior. Adjust the temperature setting according to your needs. A common setting for optimal food preservation is between 3°C and 5°C (37°F and 41°F).

5.2 Storage Zones

- **Main Compartment:** For general refrigerated items.
- **LongFresh Drawers:** These specialized drawers maintain a lower temperature and optimal humidity, ideal for keeping fresh meat, fish, and certain vegetables fresh for longer periods.
- **Door Bins:** Suitable for bottles, jars, and dairy products.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and efficiency of your refrigerator.

6.1 Interior Cleaning

Clean the interior regularly with a mild detergent and warm water. Avoid abrasive cleaners or solvents. Remove shelves and drawers for thorough cleaning. Ensure all parts are dry before returning them to the refrigerator.

6.2 Automatic Defrost

This appliance features an automatic defrost system, eliminating the need for manual defrosting of the refrigerator compartment. Any frost that forms will melt automatically and evaporate.

6.3 Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Do not spray water directly onto the appliance.

7. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power supply issue; temperature setting too high; door not closed properly; excessive food load.	Check power plug and circuit breaker; lower temperature setting; ensure door seals tightly; reduce food load.
Unusual noises	Appliance not level; items vibrating inside; normal operating sounds (e.g., refrigerant flow).	Adjust leveling feet; rearrange items; normal sounds are expected.
Water on floor/inside	Drain hole blocked; door left open.	Clear drain hole; ensure door is closed properly.

8. Specifications

Feature	Detail
Brand	AEG
Model Info	SKE814D9ZC (923794016)
Product Dimensions	21.65"D x 22.05"W x 55.12"H (55 x 56 x 140 cm)
Capacity	209 Liters
Installation Type	Built-In
Form Factor	Freezer Less
Defrost System	Automatic
Door Hinges	Reversible
Number of Doors	1
Efficiency (10 classes)	A to G

9. Warranty and Support

Your AEG refrigerator comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage period and what is covered.
For technical support, service requests, or to order spare parts, please contact AEG customer service. Have your model number (SKE814D9ZC) and serial number ready when contacting support.
You can find more information and support resources on the official AEG website.

© 2024 AEG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XB9D64G

More documents and user manuals: **https://manuals.plus/**