

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TELESIN](#) /

› [TELESIN POV Magnetic Quick Release Neck Mount Instruction Manual](#)

TELESIN POV Magnetic Quick Release Neck Mount

TELESIN POV Magnetic Quick Release Neck Mount Instruction Manual

1. INTRODUCTION

Thank you for choosing the TELESIN POV Magnetic Quick Release Neck Mount. This innovative accessory allows you to capture immersive first-person perspective videos with your action camera or smartphone. Its ergonomic design and versatile features make it ideal for various activities, from vlogging and travel to sports and daily life recording. Please read this manual carefully before use to ensure proper operation and maximize your experience.

2. PACKAGE CONTENTS

The TELESIN POV Magnetic Quick Release Neck Mount package includes the following items:

- Neck Strap (1)
- Magnetic Quick Release (1)
- Screw (1)
- Standard Two-Claw Part (1)
- Smartphone Clamp (1)
- Central Vertical Shooting Adapter (1)
- Fixing Screw (1)
- Instruction Manual (1)

パッケージ内容




Figure 2.1: All components included in the package. This includes the neck mount, smartphone clamp, various adapters, and screws.



Figure 2.3: Product size data.

Figure 2.2: Detailed view of product parameters and the packing list, including dimensions and accessory names.

3. SETUP AND INSTALLATION

Follow these steps to set up your TELESIN POV Magnetic Quick Release Neck Mount:

1. **Attach the Magnetic Adapter to your Camera:** Unscrew the magnet adapter from the neck mount. Align the two holes on the magnet adapter with the mounting points on your GoPro or action camera, then screw them together securely.
2. **Prepare the Neck Mount:** Press the quick-release button on the neck mount to open it.
3. **Wear the Neck Mount:** Place the neck mount around your neck. Ensure the TELESIN logo faces forward. Gently press the two ends together until they click and lock automatically.
4. **Attach Camera/Smartphone:**
 - **For Action Cameras:** Align the camera (with the attached magnet adapter) to the magnetic interface on the neck mount. It will snap into place securely.
 - **For Smartphones:** Attach the smartphone clamp to the magnetic interface on the neck mount. Then, insert your smartphone into the clamp.
5. **Adjust Angle:** The mount allows for 90-degree rotation and multi-angle shooting. Adjust the camera to your desired POV angle.

進化のデザインで 撮影がもっと快適になる



ワンタッチロックで簡単に取り付けます



強い磁気と回転スナップのデザイン

磁気のマウントアダプターを時計回り90°
回転させて引き出します

Figure 3.1: Illustration of the magnetic quick-release button and the attachment process for an action camera.



Figure 3.2: Close-up view of the attachment button, magnetic connection, and rotational adjustment for precise camera positioning.

Your browser does not support the video tag.

Video 3.1: This video demonstrates the quick and easy installation process of the TELESIN POV Magnetic Quick Release Neck Mount, showing how to attach an action camera and wear the mount.

4. OPERATING INSTRUCTIONS

The TELESIN POV Magnetic Quick Release Neck Mount is designed for intuitive use:

- **Capturing POV Footage:** Once your camera or smartphone is securely attached and positioned, simply start recording on your device to capture hands-free, first-person perspective videos.
- **Horizontal and Vertical Shooting:** The included central vertical shooting adapter allows for both horizontal and vertical video capture, adapting to your content needs.
- **Quick Release:** To remove the mount, press the quick-release button and separate the two ends. To detach the camera, turn it 90 degrees and pull it off the magnetic interface.



Figure 4.1: Examples of horizontal and vertical shooting configurations using the neck mount and its adapters.

日常生活の記録



乗る



生放送Vlog



子供の成長記録



料理時間

Figure 4.2: Various usage scenarios for the neck mount, including cycling, vlogging, recording children's activities, and cooking.

Your browser does not support the video tag.

Video 4.1: This video showcases the TELESIN POV Magnetic Quick Release Neck Mount in action, demonstrating its use during various activities like cycling, running, and surfing, highlighting its stability and versatility.

5. FEATURES

- Magnetic Quick Release:** The new magnetic attachment interface allows for rapid and secure attachment and detachment of your camera or smartphone.
- Ergonomic Design:** Made from high-quality food-grade silicone, the neck strap is soft, breathable, and comfortable for extended wear, preventing neck fatigue.
- Durable and Flexible:** The internal structure features a stainless steel tube and aluminum alloy layer, making it rust-resistant, highly flexible, and bendable at multiple angles without breaking.
- Versatile Mounting:** The flexible collar design allows for creative mounting options beyond just wearing it around your neck, such as hanging it on trees or attaching it to selfie sticks and fishing rods.

- **Lightweight and Portable:** Its ultra-lightweight design and ability to be freely bent make it convenient for storage and transport.



Figure 5.1: Cross-sectional view highlighting the silicone protection layer, stainless steel gooseneck, and aluminum bar for durability and flexibility.

6. COMPATIBILITY

The TELESIN POV Magnetic Quick Release Neck Mount offers wide compatibility with a variety of devices:

- **Action Cameras:** Compatible with GoPro (Max Hero 13, Hero 12, Hero 11, Hero 10, Hero 9, Hero 8, Hero 7, Hero 6, Hero 5 Black, Hero 4, Hero 3 + Fusion Session), DJI (Osmo Action 2 Pocket 2, Osmo Action 3/4/5 PRO Action 6), Insta360 (One R, One X2, X3, X4, X5, Go2), and other wearable cameras from brands like Dragon Touch, APEMAN, AKASO, Crosstour, XiaoYi, Sony, Apexcam, VEMONT, AKAIRIO.
- **Smartphones:** Compatible with various smartphones including iOS (iPhone 13 Plus Max, iPhone 13, iPhone 12, iPhone 11 XR) and Android (Samsung S10/S9 and similar models).



Figure 6.1: Visual representation of the wide range of action cameras and smartphones compatible with the neck mount.

7. MAINTENANCE

To ensure the longevity and optimal performance of your neck mount:

- **Cleaning:** The silicone material is washable with water. Clean regularly to remove sweat or dirt.
- **Storage:** Store the neck mount in a cool, dry place away from direct sunlight when not in use. Its flexible design allows for convenient storage.
- **Avoid Force:** Do not apply excessive force when assembling or disassembling components to prevent damage.

8. TROUBLESHOOTING

If you encounter any issues with your TELESIN POV Magnetic Quick Release Neck Mount, consider the following:

- **Mount Not Locking:** Ensure the two ends of the neck mount are properly aligned and gently pressed until you hear a click. Check for any obstructions.
- **Camera Not Attaching Securely:** Verify that the magnet adapter is correctly screwed into your camera and that the magnetic surfaces on both the adapter and the neck mount are clean and free of debris.
- **Stability Issues:** Ensure all screws are tightened. While the mount is designed for stability, vigorous activities may still cause slight movement. For optimal stability during high-impact activities, consider additional camera stabilization.

If problems persist, please refer to the warranty and support section for contact information.

9. SPECIFICATIONS

Feature	Specification
Product Weight	320 g
Package Dimensions	27 x 19 x 2.5 cm
Special Features	Lightweight, Flexible, Magnetic Quick Release
Color	Refined Gray
Compatible Devices	Action Cameras (GoPro, DJI, Insta360, etc.), Smartphones
Mounting Type	Quick Release Neck Mount

10. WARRANTY AND SUPPORT

Your TELESIN POV Magnetic Quick Release Neck Mount comes with a **12-month manufacturer's warranty**.

If you encounter any issues or have questions regarding your product, please do not hesitate to contact our customer support. We are committed to providing a prompt response within 24 hours to ensure your satisfaction.

For support, please visit the TELESIN official website or contact your retailer.