

[Manuals.plus](#) /

› [CubicFun](#) /

› Cubic Fun Paris Eiffel Tower 3D Puzzle Instruction Manual

CubicFun DS0998h

CubicFun Paris Eiffel Tower 3D Puzzle Instruction Manual

Model: DS0998h

INTRODUCTION

Welcome to the world of CubicFun 3D Puzzles! This manual provides detailed instructions for assembling your CubicFun Paris Eiffel Tower 3D Puzzle (Model DS0998h). Designed for enthusiasts of all ages, this puzzle allows you to recreate an iconic architectural masterpiece with ease, no tools or glue required. Enjoy the process of bringing this famous landmark to life and proudly display your finished model.

PACKAGE CONTENTS

Before you begin, please verify that all components are present in your package. The CubicFun Paris Eiffel Tower 3D Puzzle box should contain the following items:

- Pre-cut EPS foam board puzzle pieces (80 pieces)
- Instruction booklet with assembly diagrams
- National Geographic photography booklet (Paris themed)



Image: The complete CubicFun Paris Eiffel Tower 3D Puzzle retail box, displaying the assembled model and the National Geographic

booklet.




Image: Close-up of the National Geographic Paris photography booklet, which accompanies the puzzle set.

ASSEMBLY INSTRUCTIONS (SETUP)

Follow these steps to assemble your Eiffel Tower 3D Puzzle. No glue or tools are required, as the pieces are designed to interlock securely.

1. **Unpack and Organize:** Carefully remove all puzzle sheets from the box. Identify the different sheets and familiarize yourself with the pieces.
2. **Identify Pieces:** Each puzzle piece is numbered. Refer to the instruction booklet for the correct sequence and placement of pieces. It is recommended to assemble pieces in numerical order.
3. **Punch Out Pieces:** Gently punch out the required pieces from the foam boards. Be careful not to tear or bend the pieces. If a piece is difficult to remove, use a blunt object to push it out from the back.
4. **Assemble Base:** Begin by assembling the base structure of the Eiffel Tower as indicated in the instruction booklet. The base pieces are typically larger and provide a stable foundation.
5. **Connect Sections:** Follow the numerical order to connect subsequent sections of the tower. Pieces are designed to interlock tightly. Ensure each connection is firm and flush.
6. **Top Section:** Continue building upwards, paying close attention to the orientation of each piece to ensure the tower's structure is accurate.
7. **Final Touches:** Once all pieces are assembled, gently press down on all connections to ensure they are secure.



Image: The fully assembled CubicFun Eiffel Tower 3D Puzzle, showcasing its intricate details and structural integrity.

DISPLAY AND USAGE

Your CubicFun Eiffel Tower 3D Puzzle is designed as a display model. Once assembled, it makes an excellent decorative piece for your home, office, or classroom.

- Place the finished model on a flat, stable surface to prevent accidental falls.
- Avoid placing it in high-traffic areas where it might be easily knocked over.
- The model is not intended for rough play.

CARE AND MAINTENANCE

To ensure the longevity and appearance of your CubicFun 3D Puzzle, follow these simple care guidelines:

- **Dusting:** Gently dust the model regularly with a soft, dry cloth or a soft brush to prevent dust buildup in crevices.

- **Avoid Moisture:** Keep the puzzle away from water and high humidity, as moisture can damage the foam material and printed surfaces.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the colors to fade over time. Place the model in a shaded area.
- **Handling:** When moving the model, support it from the base to prevent stress on the assembled sections.

TROUBLESHOOTING

While assembling your puzzle, you might encounter minor issues. Here are some common problems and their solutions:

- **Difficulty Fitting Pieces:**
Ensure you are using the correct pieces by checking their numbers against the instruction booklet. Sometimes, a gentle wiggle or slight pressure is needed to fit pieces snugly. Do not force pieces, as this can cause damage.
- **Missing Pieces:**
Carefully check all packaging materials and the area where you are assembling the puzzle. If a piece is genuinely missing, please contact CubicFun customer support (see "Support" section).
- **Model is Unstable:**
Review the assembly steps, especially the base and lower sections. Ensure all connections are fully interlocked and secure. A loose connection can affect the overall stability.

SPECIFICATIONS

Feature	Detail
Product Name	CubicFun Paris Eiffel Tower 3D Puzzle
Model Number	DS0998h
Number of Pieces	80
Assembled Dimensions (Height)	Approx. 70.9 cm (27.9 inches)
Box Dimensions (L x W x H)	Approx. 29.8 x 21.8 x 6 cm (11.7 x 8.6 x 2.4 inches)
Item Weight	11.4 ounces (approx. 323 grams)
Material	EPS Foam Board
Manufacturer	CubicFun Toys Industrial Co., Ltd
Recommended Age	8+ (Not for children under 3 years due to small parts - Choking Hazard)

Note: The "Product Dimensions" listed in some product data (11.02 x 2.17 x 7.87 inches) may refer to packaging or flat sheet dimensions and do not represent the assembled model's height. The dimensions provided in the table above are based on visual information from the product packaging.



Image: The CubicFun Eiffel Tower 3D Puzzle box and assembled model, with indicated dimensions for the box (29.8 x 21.8 x 6 cm) and the assembled model's height (70.9 cm).

WARRANTY AND SUPPORT

CubicFun is committed to providing high-quality products. While specific warranty details are not provided with this product, if you encounter any issues such as missing pieces or manufacturing defects, please contact CubicFun customer support directly. You can typically find contact information on the product packaging or the official CubicFun website. For further assistance, please refer to the contact details provided by your retailer or visit the official CubicFun website for support resources.

© 2023 CubicFun. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question