

[Manuals.plus](#) /

› [DEXTER](#) /

› DEXTER 141-Piece Tool Kit Instruction Manual

DEXTER 3276000311379

DEXTER 141-Piece Tool Kit Instruction Manual

Model: 3276000311379

1. PRODUCT OVERVIEW

The DEXTER 141-Piece Tool Kit is a comprehensive set designed for various home improvement and DIY tasks. This kit provides a wide selection of essential tools housed in a durable, portable case with wheels for easy transport.



Image 1.1: The DEXTER 141-piece tool kit with its contents displayed in the open case.

2. KIT CONTENTS

This 141-piece tool kit includes a variety of high-quality tools for diverse applications. The tools are organized within a robust, wheeled transport case.

2.1. Tool List

- 1/2" 72T Ratchet Handle
- 5m Measuring Tape
- 18mm Utility Knife
- Blade Box with 5 Blades
- 200mm Water Pump Pliers
- 160mm Universal Pliers
- 160mm Side Cutting Pliers

- 300mm Aluminum Spirit Level
- 310mm Half-Round File
- 25mm Hammer
- 300mm Hacksaw
- 5 Hacksaw Blades (500mm)
- Aluminum Electric Burner
- 5 Precision Screwdrivers
- 30 Bits (25L)
- 10 Bits (50L)
- 60mm Magnetic Bit Holder
- Bit Adapter
- 100-250V Tester
- 9 Hex Keys
- 8 Carpenter Pencils (175mm)
- 150mm Caliper
- 1500mm Stainless Steel Ruler
- 2 Exhibition Screwdrivers (PH1 x 80, SLX 75)
- 4 Clamps
- Various sockets and wrenches



Image 2.1: Detailed view of the bottom compartment of the tool kit, featuring sockets and wrenches.



Image 2.2: Detailed view of the top compartment of the tool kit, featuring pliers, screwdrivers, and other hand tools.

3. SETUP AND ORGANIZATION

3.1. Unpacking the Tool Kit

1. Carefully unlatch the case closures.
2. Open the case to reveal the organized tool compartments.
3. Inspect all tools for any signs of damage during transit.



Image 3.1: The DEXTER tool kit in its closed, compact form.

3.2. Transporting the Case

The tool kit is equipped with integrated wheels and an extendable handle for easy portability.

1. Extend the telescopic handle by pressing the release button and pulling upwards.
2. Tilt the case and roll it using the wheels.
3. Ensure the case is securely latched before transport.



Image 3.2: The tool kit with its handle extended for easy mobility.



Image 3.3: Detail of the robust wheels and hinges for transport.

4. OPERATING INSTRUCTIONS

This section provides general guidelines for using the tools included in your DEXTER kit. Always refer to specific safety instructions for each tool type before use.

4.1. General Safety Precautions

- Always wear appropriate personal protective equipment (PPE) such as safety glasses, gloves, and hearing protection when necessary.
- Ensure your work area is well-lit and clear of obstructions.
- Use the correct tool for the job. Do not force small tools to do the work of larger tools.
- Keep tools clean and in good working condition.
- Store tools securely when not in use to prevent accidents.

4.2. Using Specific Tools (Examples)

For detailed instructions on each tool, consult specialized guides. Below are general usage tips for common tool types in this kit:

- **Pliers:** Use for gripping, bending, or cutting wires. Ensure a firm grip on the workpiece.
- **Screwdrivers:** Select the correct tip size and type (Phillips, flathead) for the screw head to prevent stripping. Apply firm, even pressure.
- **Hammers:** Use for driving nails or light demolition. Always strike squarely.
- **Measuring Tape:** Extend carefully and retract slowly to prevent damage.
- **Utility Knife:** Always cut away from your body. Use a cutting mat or sacrificial surface. Retract the blade when not in use.
- **Ratchet Handle & Sockets:** Select the correct socket size for the fastener. Apply steady force.

5. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your DEXTER tools.

- **Cleaning:** After each use, wipe down tools to remove dirt, grease, and debris. A damp cloth can be used for general cleaning, followed by drying.
- **Lubrication:** Apply a light coat of oil to moving parts of pliers, ratchets, and other mechanical tools to prevent rust and ensure smooth operation.
- **Storage:** Always return tools to their designated slots in the case. This prevents damage, keeps them organized, and makes them easy to find. Store the case in a dry environment to prevent rust.
- **Inspection:** Periodically inspect tools for wear, damage, or dullness. Replace or sharpen as needed.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your tool kit.

Problem	Possible Cause	Solution
Tools are rusting.	Exposure to moisture; lack of lubrication.	Clean and dry tools thoroughly after use. Apply a thin layer of rust-preventative oil. Store in a dry place.
Tools are difficult to remove/insert into slots.	Incorrect tool placement; debris in slots.	Ensure each tool is placed in its correct, matching slot. Clear any debris from the slots.
Case latches are stiff.	Dirt or lack of lubrication.	Clean latches and apply a small amount of lubricant (e.g., silicone spray).
Telescopic handle is stuck.	Debris in mechanism; bent handle.	Check for obstructions. Do not force. If bent, contact support.

7. SPECIFICATIONS

Feature	Detail
Brand	DEXTER

Feature	Detail
Model Number	3276000311379
Manufacturer	ADEO
Product Dimensions (L x W x H)	48 x 40 x 19 cm
Weight	11.68 kg
Number of Pieces	141
Color	Toolbox, 141 pieces
Water Resistance Level	Waterproof
Batteries Required	No
Spare Parts Availability	Information unavailable

8. WARRANTY AND SUPPORT

DEXTER tools are designed for quality and durability.

8.1. Warranty Information

This product typically comes with a **5-year warranty**, ensuring quality and performance. Please refer to your purchase documentation for specific warranty terms and conditions.



Image 8.1: Product packaging highlighting the 5-year warranty.

8.2. Customer Support

For further assistance, technical support, or warranty claims, please contact your retailer or the DEXTER customer service department. Contact information can usually be found on the product packaging or the official DEXTER website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question