

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Wahl](#) /
- › [Wahl Lithium Ion Pro Rechargeable Cordless Hair Clippers User Manual](#)

Wahl 79470

Wahl Lithium Ion Pro Rechargeable Cordless Hair Clippers

Model: 79470

Brand: Wahl

INTRODUCTION

The Wahl Lithium Ion Pro Cordless Rechargeable Hair Clipper is designed for convenient and efficient at-home haircutting. This versatile tool offers the power of a corded clipper with the flexibility of cordless operation, suitable for men, women, and children. Featuring self-sharpening precision ground blades and smart charge technology, this clipper ensures a smooth and reliable grooming experience.

SAFETY INFORMATION

May include: 'Do not use near water', 'Keep out of reach of children', 'Unplug when not in use'. Always ensure the clipper is turned off before cleaning or attaching/detaching guards. Do not immerse the clipper in water. Store in a dry place.

PACKAGE CONTENTS

The Wahl Lithium Ion Pro kit is a complete 22-piece set designed for comprehensive haircutting needs. It includes:

- Cordless Clipper
- 12 Hair Clipper Guards (sizes 1/16", 1/8", 3/16", 1/4", 3/8", 1/2", 5/8", 3/4", 7/8", 1", plus left and right ear tapers)
- Scissors
- Barber's Comb
- Styling Comb
- Detail Cleaning Brush

- Blade Cover
- Blade Oil
- Instruction Book
- Storage Case



Image: Complete 22-piece kit for the Wahl Lithium Ion Pro Hair Clipper, including the clipper, various guards, combs, scissors, and maintenance accessories in a storage case.

SETUP

Initial Charging

Before the first use, fully charge the clipper. The Smart Charge Technology features an LED light indicator:

- **Flashing Red:** Low power
- **Solid Red:** Charging
- **Solid Green:** Fully charged

12 SNAP 'N LOCK CUTTING GUARDS

for goof-proof cutting lengths between 1/16" and 1"




Image: Visual representation of the Smart Charge Technology LED light indicating battery status (low, charging, fully charged).

Blade Adjustment

The adjustable taper lever allows for easy adjustment of blade length, perfect for blending between cutting sizes and fading haircuts.

RECHARGEABLE CLIPPER

The power of a corded clipper with
the convenience of a cordless



**15-MINUTE
QUICK CHARGE
FOR INSTANT
POWER**

The Brand Used
By Professionals



**ADVANCED
TECHNOLOGY**
SUPERIOR POWER
& PERFORMANCE

Image: Diagram illustrating the function of the adjustable taper lever for precise blade length control.

Attaching Guards

Select the desired Snap-N-Lock cutting guard and securely attach it to the clipper. The kit includes 12 guards for lengths from 1/16" to 1".

SMART CHARGE TECHNOLOGY

smart display light indicates battery status...
charging, fully charged, or low power.




Image: Close-up of the Snap-N-Lock cutting guards, highlighting easy-glide teeth and secure attachment clips.

OPERATING INSTRUCTIONS

Cordless Operation

For cordless use, ensure the clipper is fully charged. It provides up to 2 hours of run time on a full charge, allowing for multiple haircuts. The clipper can hold its charge for up to 9 months when not in use.

ADJUSTABLE TAPER LEVER

for blending between cutting sizes and fading haircuts



Image: The Wahl Lithium Ion Pro Clipper being held, demonstrating its cordless design and advanced technology for superior power and performance.

Corded Operation

For continuous power, the clipper can be used while plugged into a power source. Simply connect the charging cable to the clipper and an appropriate outlet.

MAINTENANCE

Cleaning

Regularly clean the clipper blades using the provided detail cleaning brush to remove hair clippings. This ensures optimal performance and longevity.

Blade Care

The clipper features self-sharpening precision ground blades that stay sharper longer. Apply a few drops of the included blade oil to the blades before and after each use to maintain their sharpness and smooth operation.

TROUBLESHOOTING

- **Clipper not turning on:** Ensure the clipper is fully charged or plugged into a working power outlet.
- **Blades pulling hair:** Clean the blades thoroughly and apply blade oil. Ensure the blades are properly aligned.
- **Reduced cutting performance:** Check if the battery is low. Clean and oil the blades. Ensure the correct guard is securely attached.

SPECIFICATIONS

- **Product Dimensions:** 11.02 x 7.44 x 3.31 inches; 2.16 Pounds
- **Item Model Number:** 79470
- **Batteries:** 1 Lithium Ion battery required (included)
- **UPC:** 043917113029
- **Manufacturer:** Wahl Clipper
- **Country of Origin:** China
- **Recommended Uses:** Head
- **Color:** Silver, Black, Navy Blue
- **Hair Type:** All
- **Item Weight:** 980 Grams

WARRANTY AND SUPPORT

Wahl is a trusted brand used by professionals in the salon & barber industry since 1919. For any product issues or support, please refer to the contact information provided on the product packaging and in the included instruction book. Product tutorials may also be available on the official Wahl USA website.