

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Asuwish](#) /

› [Asuwish Wallet Case and Tempered Glass Screen Protector for Xiaomi Redmi 9A / Redmi 9i User Manual](#)

## Asuwish Redmi 9A / Redmi 9i

# Asuwish Wallet Case and Tempered Glass Screen Protector User Manual

For Xiaomi Redmi 9A / Redmi 9i

## 1. INTRODUCTION

---

This manual provides instructions for the proper installation, use, and maintenance of your Asuwish Wallet Case and Tempered Glass Screen Protector. This product is designed specifically for the Xiaomi Redmi 9A and Xiaomi Redmi 9i models. It is not compatible with other devices.

# Compatible with **Redmi 9a / Redmi 9i Only**



Image 1.1: Compatibility chart indicating the case is exclusively for Redmi 9A / Redmi 9i models.

## 2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Asuwish Wallet Case (Rose Gold)
- 1 x Tempered Glass Screen Protector
- 1 x Detachable Wrist Strap



**Image 2.1:** Overview of the complete product package, showing the wallet case, tempered glass screen protector, and detachable wrist strap.

### 3. SETUP AND INSTALLATION

#### 3.1 Installing the Phone into the Wallet Case

1. Open the wallet case.
2. Align your Xiaomi Redmi 9A / Redmi 9i with the inner TPU (thermoplastic polyurethane) shell of the case.
3. Gently press the phone into the shell, ensuring all edges and corners are securely seated.
4. Verify that all ports, buttons, and camera cutouts align correctly with your phone.

#### 3.2 Applying the Tempered Glass Screen Protector

For optimal results, perform this installation in a clean, dust-free environment.

1. **Clean the Screen:** Use the provided cleaning wipes (if included) or a microfiber cloth to thoroughly clean your phone's screen. Ensure there are no dust particles, smudges, or fingerprints.
2. **Remove Protective Film:** Carefully peel off the protective film from the adhesive side of the tempered glass screen protector. Avoid touching the adhesive surface.

3. **Align the Protector:** Align the screen protector with your phone's screen, paying close attention to the edges, camera, and speaker cutouts.
4. **Apply:** Once aligned, gently lower the screen protector onto the screen. It will begin to adhere automatically.
5. **Remove Bubbles:** If any air bubbles appear, gently push them towards the nearest edge using a soft cloth or a credit card wrapped in a cloth.

## 4. OPERATING INSTRUCTIONS

### 4.1 Card Holder Functionality

The wallet case features three dedicated card slots and a larger pocket for cash. These slots are designed to securely hold standard-sized cards such as credit cards, ID cards, or business cards.

- Insert cards into the designated slots.
- Place folded cash into the larger side pocket.



**Image 4.1:** The interior of the wallet case, demonstrating the card slots and cash pocket for convenient storage.

### 4.2 Kickstand Feature

The case can be folded into a kickstand position, allowing for hands-free viewing of media.

1. Open the front flap of the wallet case.

2. Fold the flap backward and position it to create a triangular stand.
3. Adjust the angle for comfortable viewing.



**Image 4.2:** The wallet case configured as a kickstand, providing a stable base for hands-free media consumption.

### 4.3 Detachable Wrist Strap

The included wrist strap can be attached to the case for added security and convenience.

- Locate the small metal loop on the side of the wallet case.
- Attach the clasp of the wrist strap to this loop.
- To detach, simply unclip the clasp.

## FOCUS ON DETAILS

100% Handmade.  
Stylish and Fashionable



Upgraded and detachable hand strap,  
convenient to carry and free your hands



Powerful magnetic closure keep  
your phone secure



Image 4.3: The wallet case featuring the detachable wrist strap and the magnetic closure mechanism.

### 4.4 Magnetic Closure

The case features a magnetic strap closure to keep the front flap securely closed, protecting your screen and contents.

- Simply close the front flap and the magnetic strap will automatically secure it.

## 5. CARE AND MAINTENANCE

To ensure the longevity and appearance of your wallet case and screen protector, follow these care guidelines:

- **Cleaning the Case:** Wipe the exterior of the case with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning the Screen Protector:** Use a microfiber cloth to gently wipe the screen protector. For smudges, a screen cleaner spray designed for electronics can be used.
- **Avoid Overstuffing:** Do not overfill the card slots or cash pocket, as this can stretch the material and compromise the magnetic closure.
- **Protect from Extreme Conditions:** Keep the case away from direct sunlight, high temperatures, and

excessive moisture to prevent material degradation.

## 6. TROUBLESHOOTING

- **Screen Protector Bubbles:** If bubbles appear after installation, try gently lifting the nearest edge of the protector and reapplying, pushing the air out with a soft cloth. Small bubbles may disappear on their own within 24-48 hours.
- **Case Not Closing Properly:** Ensure the card slots and cash pocket are not overfilled. Remove some items if necessary to allow the magnetic closure to function correctly.
- **Phone Not Fitting:** Double-check that your phone model is indeed a Xiaomi Redmi 9A or Redmi 9i. This case is not compatible with other models.

## 7. SPECIFICATIONS

Feature	Detail
Compatible Phone Models	Xiaomi Redmi 9A, Xiaomi Redmi 9i
Material	Leather (Case), Tempered Glass (Screen Protector)
Form Factor	Flip Wallet Case
Special Features	Heavy Duty Protection, Kickstand, Card Holder, Detachable Wrist Strap, Magnetic Closure
Color	Rose Gold
Item Weight	3.84 ounces
Package Dimensions	8.03 x 4.09 x 0.71 inches

## 8. WARRANTY AND SUPPORT

Asuwish is committed to customer satisfaction. If you encounter any issues with your product or are not satisfied with your purchase, please contact our customer service team. We will address specific problems promptly, which may include product replacement, direct refund, or return and refund options.

For support, please refer to the contact information provided with your purchase or visit the official Asuwish support channels.