

[Manuals.plus](#) /

› [Eufy](#) /

› Anker Eufy Security eufyCam 2C 1-Cam Kit User Manual

Eufy T8830

Anker Eufy Security eufyCam 2C 1-Cam Kit User Manual

Model: T8830

INTRODUCTION

Thank you for choosing the Anker Eufy Security eufyCam 2C 1-Cam Kit. This wireless security camera system is designed to provide comprehensive outdoor surveillance with ease of use and advanced features. This manual will guide you through the setup, operation, and maintenance of your eufyCam 2C system.



Image: Overview of the EufyCam 2C system components and typical setup.

PACKAGE CONTENTS

The Anker Eufy Security eufyCam 2C 1-Cam Kit includes the following items:

- eufyCam 2C Camera Unit
- HomeBase 2
- AC Power Adapter (for HomeBase 2)
- Ethernet Cable
- Micro USB Charging Cable (for camera)
- Mounting Bracket
- Mounting Screws and Anchors
- Reset Pin
- Quick Start Guide

SETUP

1. Charging the Camera

Before initial use, fully charge the eufyCam 2C camera using the provided Micro USB cable and a compatible USB power adapter. A full charge can last approximately 180 days, depending on usage.

2. Setting up HomeBase 2

1. Connect HomeBase 2 to power using the AC adapter.
2. Connect HomeBase 2 to your router using the Ethernet cable.
3. Wait for the LED indicator on HomeBase 2 to turn solid blue, indicating it's ready.

3. Installing the Eufy Security App

Download the Eufy Security app from the App Store (iOS) or Google Play (Android). Create an account or log in if you already have one.



Image: The Eufy Security app login screen on a smartphone.

4. Pairing the Camera

1. In the Eufy Security app, tap 'Add Device' and select 'eufyCam 2C'.
2. Follow the on-screen instructions to pair your camera with HomeBase 2.

5. Mounting the Camera

The eufyCam 2C is designed for outdoor use and comes with a wall-mount bracket. Choose a location that provides the

desired viewing angle and strong Wi-Fi signal from HomeBase 2.

1. Secure the mounting bracket to a wall or surface using the provided screws and anchors.
2. Attach the camera to the mounting bracket and adjust the angle as needed.



Image: The eufyCam 2C camera mounted on an outdoor wall.

OPERATING THE EUFYCAM 2C

Live View and Recording

Access the live feed from your camera through the Eufy Security app. The camera records in 1080p Full HD with a 135° wide-angle view, capturing clear details.

細部まで鮮明な映像

135°の広い画角に加え、フルHDの高画質で
映像を録画可能
被写体の表情まで鮮明に確認可能




Image: A demonstration of the eufyCam 2C's 135-degree wide-angle view, clearly showing a car's license plate.

AI Human Detection and Notifications

The camera features AI detection that distinguishes between humans and other moving objects, reducing false alarms. You will receive notifications on your smartphone only when a person is detected.

暗闇でもはっきり見える

暗い場所で動きを検知した場合は
スポットライトを点灯して周囲を
明るく照らし、カラーで録画が可能



Image: The eufyCam 2C's AI detection accurately identifies a person while ignoring a dog, preventing unnecessary alerts.




Image: A smartphone displaying a notification from the Eufy Security app, indicating motion detection.

Spotlight and Color Night Vision

In low-light conditions, the integrated spotlight illuminates the area when motion is detected, enabling full-color recording at night.

追加費用なしで利用可能

ローカルストレージにデータを保存可能

追加費用は不要で

安全に録画データを保存できます



Image: The eufyCam 2C's spotlight activates to illuminate a person in a dark environment, allowing for clear color recording.



Image: The eufyCam 2C with its spotlight active during nighttime surveillance.

Local Storage

All recorded data is stored securely on the HomeBase 2's built-in 16GB local storage, eliminating the need for additional subscription fees.

防水・防塵のワイヤレスカメラ

IP67の防水・防塵規格対応で
電源のない屋外の監視にも最適
カメラは一度の充電で約180日間※
使用することができます



※検出頻度、スポットライトの使用頻度やカメラ操作によって、バッテリーの使用時間が異なります。

Image: A cutaway view of the HomeBase 2, highlighting its internal 16GB local storage for recorded data.



Image: A detailed view of the HomeBase 2's internal components, including the 16GB storage module.

Two-Way Audio

The camera supports two-way audio, allowing you to communicate with visitors or deter intruders. Note that simultaneous two-way conversation is not supported.



Image: A person receiving a package at their front door, with the eufyCam 2C visible above, illustrating its use for communication.

MAINTENANCE

Battery Life and Charging

The eufyCam 2C camera is equipped with a 6700mAh battery, offering approximately 180 days of continuous use on a single charge. Battery life may vary based on detection frequency, spotlight usage, and camera operations. Recharge the camera using the provided Micro USB cable when the battery is low.

Weather Resistance

The eufyCam 2C has an IP67 waterproof and dustproof rating, making it suitable for outdoor surveillance in various weather conditions.

高性能な通知機能

人物が近づいた時にだけ
お使いのスマートフォンに通知する
人物検知設定が可能です



Image: The eufyCam 2C camera installed outdoors, demonstrating its IP67 weather resistance during rainfall.

Regularly check the camera lens for dirt or obstructions and clean it gently with a soft cloth. Ensure the mounting is secure and free from damage.

TROUBLESHOOTING

- **Camera Not Connecting:** Ensure HomeBase 2 is powered on and connected to your router. Check that the camera is within range of HomeBase 2's Wi-Fi signal. The system only supports 2.4GHz Wi-Fi.
- **No Notifications:** Verify that human detection is enabled in the app and that app notifications are allowed on your smartphone. Adjust motion detection zones and sensitivity settings if needed.
- **Poor Video Quality:** Check the camera lens for dirt. Ensure a stable Wi-Fi connection.
- **Short Battery Life:** Battery life is affected by detection frequency and spotlight usage. Reduce these settings if you experience significantly shorter battery life.
- **Two-Way Audio Issues:** Remember that two-way audio is not simultaneous; speak and listen alternately. Ensure your smartphone's microphone and speaker are functioning correctly.
- **Smartphone Requirement:** A smartphone is required to operate this product.




Image: Screenshot of the Eufy Security app showing how to set up custom motion detection zones.

SPECIFICATIONS

Feature	Specification
Model Number	AMZ-T8830
Video Resolution	1080p Full HD
Frame Rate	15 fps
Field of View	135 degrees
Camera Battery Capacity	6700mAh
HomeBase 2 Storage	16GB Local Storage
Wireless Type	Wi-Fi (2.4GHz only)
Weather Resistance	IP67

Feature	Specification
Camera Dimensions (approx.)	57 x 48 x 81 mm (excluding bracket)
Camera Weight (approx.)	196g
HomeBase 2 Dimensions (approx.)	85 x 85 x 131 mm
HomeBase 2 Weight (approx.)	280g

IMPORTANT NOTES

- Continuous recording function is not supported.
- Only 2.4GHz frequency band is supported.
- A smartphone is required to use this product.
- Simultaneous two-way conversation is not possible.
- Battery usage time varies depending on detection frequency, spotlight usage, and camera operations.
- Product installation and removal are not performed by our customer support. Please perform these actions yourself.
- Product packaging may change without prior notice. The product packaging may differ depending on the time of purchase. Please be aware of this in advance.
- Product specifications may change without prior notice. Please be aware of this in advance.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Eufy website or contact Eufy customer service directly. Details can typically be found on the product packaging or the Eufy Security app. You can also visit the [Eufy Store on Amazon](#) for more information and related products.

© 2026 Eufy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XMD2RWY>

More documents and user manuals: <https://manuals.plus/>