Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Olakids 63114

OLAKIDS Inflatable Water Slide Shark Theme Bounce House User Manual

Brand: Olakids | Model: 63114

1. Important Safety Information

Read all instructions before setting up and using the OLAKIDS Inflatable Water Slide. Failure to follow these instructions may result in serious injury or property damage. Keep this manual for future reference.

1.1 General Safety Guidelines

- **Adult Supervision Required:** Always ensure constant and active adult supervision of children using the water slide. Never leave children unattended.
- **Age and Weight Limits:** Suitable for children aged 3 to 10 years. Individual user weight limit is 100 lbs (45 kg). The total maximum weight capacity for all users combined is 265 lbs (120 kg). Do not exceed these limits.
- **Number of Users:** This water park is designed for a maximum of 4 children to play together simultaneously.
- **Clear Area:** Set up the water slide on a level, soft surface (e.g., grass) at least 6 feet (1.8 meters) away from any structures, fences, trees, or other obstacles. Ensure the area is free of sharp objects.
- **No Sharp Objects:** Users must remove shoes, glasses, jewelry, and any sharp objects before entering the water slide.
- **Safe Play:** Prohibit rough play, diving, flipping, or climbing on walls not designated for climbing. Only one child should be on the slide or climbing wall at a time.
- **Material Safety:** This product is made from puncture-resistant 840D and 420D Oxford materials and complies with US CPSIA and ASTM requirements. It is free from BPA, PVC, Phthalates, Lead, Latex, and Formaldehyde.
- **Mesh Walls:** The area between the climbing wall and water slides is enclosed by mesh walls to enhance safety and provide ventilation.
- **Water Depth:** The splash pool contains shallow water. Always supervise children to prevent drowning.
- **Weather Conditions:** Do not use in strong winds, heavy rain, or lightning. Deflate and secure the unit during adverse weather.

2. Package Contents

Please verify that all components are present before assembly:

- 1 x Inflatable Water Slide (Shark Theme Bounce House)
- 1 x Air Blower (680W)
- 1 x Water Hose
- 1 x Carrying Bag
- 12 x Repair Patches
- 6 x Bouncer Stakes

3. Setup Instructions

Follow these steps for quick and easy assembly:

1. **Unroll:** Place the rolled-up inflatable water slide on a clean, level, and soft surface in your desired play area. Ensure the area is free of debris and sharp objects.
2. **Inflate:** Attach the air blower to the inflation tube of the water slide. Ensure the connection is secure. Turn on the 680W air blower. The water slide will inflate within minutes. Keep the blower running continuously during use.
3. **Attach Water Hose:** Connect the provided water hose to a garden hose and secure it to the designated hook and loop fasteners on the water slide. Turn on the water supply to activate the water features.
4. **Secure:** Use the provided bouncer stakes to firmly anchor the water slide to the ground through the multiple straps located around the base. This ensures stability and security during play.



Image: Easy setup in 4 steps: Unroll, Inflate, Attach, Secure.



Image: The fully inflated OLAKIDS Shark Theme Water Slide with children enjoying the various features.

4. Operating Instructions

Once set up, the OLAKIDS Inflatable Water Slide offers multiple play areas:

- **Water Slide:** Children can slide down the smooth, wet slide into the splash pool. Ensure the slide surface is adequately wet for safe sliding.
- **Climbing Wall:** The integrated climbing wall allows children to ascend to the top of the slide. Always ensure children use the handholds and footrests provided.
- **Splash Pool:** The spacious splash pool at the bottom provides a safe landing area and a place for water play.
- **Water Gun:** A water gun is included for interactive water play.



Image: Close-up views of children engaging with the slide, climbing wall, splash pool, and water cannon.

4.1 Wet and Dry Use

This inflatable unit can be used as a water park with the hose connected for summer outdoor fun, or as a dry bounce house for indoor or all-season play.




Image: The water slide can be used wet for outdoor summer play or dry for indoor use.

5. Maintenance

5.1 Cleaning

To clean the inflatable water slide, wipe surfaces with a damp cloth and mild soap. Rinse thoroughly with clean water. Do not use harsh chemicals or abrasive cleaners.

5.2 Drying

Before storage, ensure the entire unit is completely dry to prevent mold and mildew. If used with water, allow it to air dry thoroughly in a shaded area. You may need to run the blower for a period to dry internal surfaces.

5.3 Repairs

Small punctures can be repaired using the included repair patches. Clean the damaged area, apply adhesive (not included) to the patch, and firmly press it over the puncture. Allow sufficient time for the adhesive to cure.

5.4 Storage

Once clean and dry, deflate the water slide completely. Fold it neatly and place it in the provided carrying bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

- **Unit Not Inflating:** Check that the blower is securely attached, plugged in, and turned on. Ensure all air outlets and zippers are closed.
- **Slow Inflation/Loss of Air:** Inspect for any punctures or tears. Use repair patches for small damages. Ensure the blower is operating correctly and continuously.
- **Water Features Not Working:** Check that the water hose is properly connected to both the water supply and the inflatable unit. Ensure the water supply is turned on and there are no kinks in the hose.
- **Unit Not Stable:** Ensure the unit is placed on a level surface and all bouncer stakes are firmly inserted into the ground.

7. Specifications

Product Dimensions	153.5"L x 120"W x 94.5"H (390cm L x 305cm W x 240cm H)
Item Weight	31.5 pounds (14.3 kg)
Age Range (Recommended)	36 months - 10 years
Individual Weight Limit	100 lbs (45 kg)
Maximum Total Weight Capacity	265 lbs (120 kg)
Maximum Users	4 children
Material	840D and 420D Oxford Cloth
Blower Power	680W



Image: Detailed product dimensions of the OLAKIDS Inflatable Water Slide.

8. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact Olakids customer service. You can find contact details on the official Olakids website or through your original point of purchase.
Visit the Olakids Store for more information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XMH93FV

More documents and user manuals: **https://manuals.plus/**