Libovgogo DF-580B

Libovgogo DF-580B Portable Emergency Radio User Manual

Model: DF-580B | Brand: Libovgogo

Introduction

Thank you for choosing the Libovgogo DF-580B Portable Emergency Radio. This device is designed to provide reliable communication, power, and illumination in various situations, especially during emergencies or outdoor activities. It features AM/FM radio, multiple charging methods (hand crank, solar, USB-C), a 5000mAh power bank, a powerful flashlight, a reading lamp, and an SOS alarm.

Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.



Figure 1: Libovgogo DF-580B Emergency Radio. This image highlights the device's robust design and splash resistance, with water droplets visible around the radio.

Product Overview and Components

Familiarize yourself with the various parts of your Libovgogo DF-580B radio.



Figure 2: Product Features Diagram. This diagram illustrates the key components of the radio, including the antenna, solar panel, hand crank, compass, carabiner, flashlight button, flashlight, mode display, battery indicator, speaker, AM/FM switch, volume/next station controls, power button, and automatic scan button, along with its dimensions (16.5 cm length, 4.5 cm width, 7.5 cm height).

Key Components:

- **Antenna:** Extendable for improved radio reception.
- **Solar Panel:** For trickle charging the internal battery using sunlight.
- **Hand Crank:** Manual power generation for charging.
- **Flashlight:** Integrated LED flashlight for illumination.
- **Reading Lamp:** Built-in LEDs for soft area lighting.
- **Speaker:** For audio output from the radio.
- **Control Buttons:** Power, volume, tuning, mode selection.
- **USB-C Port:** For charging the radio and outputting power to external devices.
- **Compass:** Integrated for navigation assistance.
- **Carabiner:** For easy attachment and portability.

Setup and Initial Use

Charging the Radio:

Before first use, it is recommended to fully charge the radio's internal 5000mAh lithium-polymer battery.

1. **USB-C Charging:** Connect the supplied USB-C cable to the radio's USB-C input port and the other end to a standard USB power adapter (not included) or a computer USB port. The battery indicator on the display will show charging progress.
2. **Hand Crank Charging:** Extend the hand crank handle and rotate it clockwise or counter-clockwise at a steady pace (approximately 130-150 RPM). One minute of cranking can provide several minutes of radio use or emergency light.
3. **Solar Charging:** Place the radio with the solar panel facing direct sunlight. The solar panel provides a trickle charge and is ideal for maintaining battery life or for emergency charging when other power sources are unavailable. It is not intended as the primary charging method for a full charge.



Figure 3: Multiple Charging Options. This image displays the hand crank for manual power generation, the USB-C port for cable charging, the solar panel for solar charging, and an illustration of the 5000mAh high-capacity battery with charging and playtime indicators.

Operating Instructions

Radio Operation (AM/FM):

1. **Power On/Off:** Press the power button () to turn the radio on or off.
2. **Select Band:** Use the AM/FM switch to select your desired radio band.
3. **Automatic Scan:** Press the automatic scan button (often labeled with a magnifying glass or scan icon) to automatically find and save available AM/FM stations. The radio will scan frequencies from AM: 520-1710 kHz and FM: 76.0-108.0 MHz.
4. **Manual Tuning/Volume:** Use the volume/next station controls to adjust the volume or manually fine-tune stations if

needed. The large LED screen facilitates reading the station scale.

5. **Antenna:** Extend the telescopic antenna fully for optimal FM reception. For AM reception, the internal antenna is usually sufficient, but rotating the radio may improve signal.

Power Bank Function:

The Libovgogo DF-580B can act as a power bank to charge your mobile devices.

- Connect your phone or tablet to the radio's USB-C output port using your device's charging cable.
- The radio's 5000mAh internal battery will begin charging your connected device. This feature is crucial for keeping your essential electronics powered during outages or in remote areas.

Light Functions:



Figure 4: Multiple Light Modes. This image illustrates the reading lamp for soft illumination, the powerful LED flashlight with a long beam, and the SOS red light for emergency signaling.

- **Flashlight:** Press the flashlight button to activate the 3W LED flashlight. It provides a strong beam with a range of approximately 35 meters, useful for navigating in the dark.

- **Reading Lamp:** Activate the reading lamp (often located on the underside or side of the solar panel) to illuminate your immediate area. It features 4 integrated LEDs, perfect for reading or working in low-light conditions.

SOS Alarm:

In an emergency, the SOS alarm can be activated to attract attention.

- Press and hold the SOS button (usually for 3 seconds) to activate the loud siren and flashing red light.
- The siren has a volume of 110 dB and an effective range of 200 meters, designed to alert potential rescuers to your location.



Figure 5: Emergency Features. This image demonstrates the SOS alarm in action, the integrated compass, the shockproof construction of the radio, and its IP5 water resistance, highlighting its utility in emergency situations.

Integrated Compass:

The radio includes a built-in compass for basic navigation assistance, particularly useful during outdoor adventures or in unfamiliar terrain.

Maintenance and Care

- **Cleaning:** Wipe the radio with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The radio features IPX5 splash protection, meaning it can withstand splashes of water from any direction. Do not submerge the radio in water. Ensure all port covers are securely closed to maintain water resistance.
- **Storage:** Store the radio in a cool, dry place when not in use. If storing for extended periods, charge the battery every 3-6 months to maintain its health.
- **Impact Resistance:** The robust construction is designed to be shock-resistant, but avoid dropping the device from significant heights.



Figure 6: IPX5 Water Resistance. This image depicts the radio being used outdoors in rainy conditions, demonstrating its IPX5 splash-proof capability, making it suitable for various weather conditions.

Troubleshooting

Problem	Possible Cause	Solution
Radio does not turn on.	Battery is depleted.	Charge the radio using USB-C, hand crank, or solar panel.
Poor radio reception.	Antenna not extended; weak signal area; interference.	Extend the telescopic antenna fully. Try rotating the radio for better signal. Move to an open area away from obstructions.
External device not charging.	Radio battery is low; incorrect cable; device not compatible.	Ensure the radio has sufficient charge. Use the correct USB-C cable for your device. Verify device compatibility.
Flashlight/Reading lamp not working.	Battery is depleted; light function not activated correctly.	Charge the radio. Ensure you are pressing the correct button for the desired light function.

Specifications

Feature	Detail
Model Number	DF-580B
Dimensions (H x W x D)	16.5 x 4.5 x 7.5 cm (6.5 x 1.8 x 3.0 inches)
Weight	438 g (0.97 lbs)
Radio Bands	AM: 520-1710 kHz, FM: 76.0-108.0 MHz
Battery Type	5000mAh Lithium-Polymer (rechargeable)
Charging Methods	USB-C, Hand Crank, Solar Panel
Power Output	USB-C (for charging external devices)
Flashlight Power	3W LED (approx. 35m range)
Reading Lamp	4 integrated LEDs
SOS Alarm Volume	110 dB (approx. 200m range)
Water Resistance	IPX5 (splash-proof)
Special Features	Integrated Compass, Automatic Scan, Shock-resistant design

Warranty and Support

Libovgogo is committed to providing reliable products and excellent customer service. If you have any questions before purchase or during use of your DF-580B Emergency Radio, please do not hesitate to contact us. Refer to the product

packaging or the official Libovgogo website for specific warranty details and contact information.

Your satisfaction is our priority, and we are here to assist you with any concerns or technical support needs.

© 2024 Libovgogo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question