

- Manuals.plus /
- > XIMAX /
 - > XIMAX Shower Wall Coat Hook Model 53117 Instruction Manual

XIMAX 53117

XIMAX Shower Wall Coat Hook Instruction Manual

Model: 53117

1. INTRODUCTION

Thank you for choosing the XIMAX Shower Wall Coat Hook. This manual provides essential information for the proper installation, use, and maintenance of your new product. Please read these instructions carefully before use and retain them for future reference.

2. PRODUCT OVERVIEW

The XIMAX Shower Wall Coat Hook is designed for convenient hanging of towels and bathrobes on shower walls without frames. Its chrome finish and durable plastic construction ensure both functionality and aesthetic appeal in your bathroom environment.



Figure 1: XIMAX Shower Wall Coat Hook. This image displays the chrome-finished hook, designed with a curved top section to fit over a frameless shower wall and a lower hook for hanging items.

3. PACKAGE CONTENTS

The package includes the following items:

- 1 x XIMAX Shower Wall Coat Hook (Chrome)

4. SPECIFICATIONS

Feature	Detail
Model Number	53117
Brand	XIMAX
Material	Plastic
Color	Chrome
Finish Type	Chrome
Mounting Type	Wall Mount (Over Shower Wall)
Dimensions (L x W x H)	1.57 x 3.15 x 6.1 inches (40 x 80 x 155 mm)
Item Weight	1.97 ounces (0.06 Kilograms)
Special Feature	Durable
Recommended Use	Shower walls (frameless)

5. SETUP AND INSTALLATION

The XIMAX Shower Wall Coat Hook is designed for easy, tool-free installation on frameless shower walls.

1. **Identify Placement:** Choose a suitable location on your frameless shower wall where you wish to hang towels or bathrobes. Ensure the top edge of the shower wall is clear and accessible.
2. **Position the Hook:** Take the XIMAX Shower Wall Coat Hook. The top, curved section of the hook is designed to fit over the top edge of a frameless glass shower wall.
3. **Install:** Gently place the curved top section of the hook over the top edge of the shower wall. The hook should rest securely on both sides of the glass. No tools or adhesives are required.
4. **Verify Stability:** Ensure the hook is stable and does not wobble. It should hang securely without risk of falling when items are placed on it.

Note: This hook is specifically designed for frameless shower walls. Do not attempt to install it on framed shower doors or walls, as it may not fit securely or could cause damage.

6. OPERATING INSTRUCTIONS

Using your XIMAX Shower Wall Coat Hook is straightforward:

- Simply hang your towel, bathrobe, or other lightweight items onto the hook.
- Ensure the weight of the items does not exceed the hook's capacity to maintain stability.

7. MAINTENANCE

To keep your XIMAX Shower Wall Coat Hook in optimal condition:

- **Cleaning:** Wipe the hook regularly with a soft, damp cloth. For stubborn marks, a mild soap solution can be used.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or strong chemical detergents, as these can damage the chrome finish.
- **Drying:** Dry the hook thoroughly after cleaning to prevent water spots.

8. TROUBLESHOOTING

This product is simple in design, and issues are rare. However, if you encounter any problems:

- **Hook is not stable:** Ensure the hook is correctly seated over a frameless shower wall. Verify that the shower wall thickness is compatible with the hook's design.
- **Damage to finish:** Avoid dropping the hook or exposing it to sharp objects. Follow maintenance instructions to prevent damage from harsh cleaners.

9. WARRANTY AND SUPPORT

Specific warranty information for the XIMAX Shower Wall Coat Hook is typically provided at the point of purchase or on the product packaging. Please refer to your purchase documentation for details regarding warranty coverage and duration.

For further assistance or support, please contact your retailer or the XIMAX customer service department through the contact information provided with your purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XMZF6Q1>

More documents and user manuals: <https://manuals.plus/>