Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beper P206VEN350

Beper P206VEN350 Bladeless Fan with Purification Function

USER INSTRUCTION MANUAL

Important Safety Instructions

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage indicated on the rating label matches your mains supply voltage.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Unplug the appliance from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Do not operate the fan with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance out of reach of children and pets.
- Do not insert fingers or any objects into the fan grille or openings.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not use the fan in areas with high humidity, such as bathrooms, or near water.
- Ensure proper ventilation around the fan; do not block air inlets or outlets.
- This appliance is for household use only. Do not use it outdoors or for commercial purposes.

Product Overview

The Beper P206VEN350 is a versatile bladeless fan designed to provide both cooling and air purification. It features an intuitive LED display, touch controls, and a convenient remote control for ease of use.

Figure 1: Beper P206VEN350 Bladeless Fan and Remote Control. This image shows the sleek, white tower fan design with its integrated LED display and the accompanying remote control, highlighting its modern aesthetic and user interface.

Key Features:

- **Bladeless Design:** Provides a smooth, consistent airflow and is safer for households with children or pets.
- **Air Purification Function:** Equipped with an active carbon filter to help eliminate odors and airborne organic compounds.

- **Multiple Speed Settings:** Three distinct fan speeds (Low, Medium, High) for customized comfort.
- **Three Ventilation Modes:** Normal, Natural, and Night modes to suit different preferences and times of day.
- **Oscillation Function:** Wide 70-degree oscillation for broad air distribution across a room.
- **Timer Function:** Programmable timer for automatic shut-off, up to 15 hours.
- **LED Display & Touch Panel:** Clear display and responsive touch controls for easy operation.
- **Remote Control:** Full-function remote control for convenient operation from a distance.

Figure 2: Overview of Beper P206VEN350 Fan Features. This image illustrates the key specifications and functions of the fan, including its 50W power, remote control capability, 3 speeds, 3 fan modes, 15-hour timer, active carbon filter, and energy-saving function, presented with clear icons.

Setup

1. **Unpacking:** Carefully remove the fan and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the fan on a firm, level, and stable surface. Ensure there is adequate space around the fan for proper airflow, at least 20 cm from walls or other objects. Do not place it near curtains or other materials that could obstruct the air intake.
3. **Filter Installation (if not pre-installed):** The Beper P206VEN350 comes with an active carbon filter. Locate the filter compartment, usually at the rear or base of the unit. Insert the filter according to the markings, ensuring it is securely in place.

Figure 3: Rear View of Beper P206VEN350 Highlighting Purification. This image shows the back of the fan, emphasizing its purification function with an active carbon filter, indicated by air bubbles flowing into the unit, suggesting air intake and filtration.

4. **Power Connection:** Plug the power cord into a standard electrical outlet. Ensure the outlet voltage matches the fan's requirements (110 Volts).

Operating Instructions

Control Panel and Remote Control:

The fan can be operated using the touch control panel located on the unit or the included remote control. The functions are identical for both.

Figure 4: User Operating Beper P206VEN350 with Remote Control. This image depicts a person comfortably using the remote control to adjust the fan settings from a distance, illustrating the convenience of the remote operation.

Functions:

- **Power On/Off:** Press the **POWER** button to turn the fan on or off. The LED display will illuminate when the fan is on.
- **Speed Adjustment:** Press the **SPEED** button repeatedly to cycle through the three fan speeds: Low (1), Medium (2), and High (3). The current speed will be shown on the LED display.
- **Mode Selection:** Press the **MODE** button to select one of the three ventilation modes:
  - **Normal Mode:** Provides a constant, steady airflow at the selected speed.
  - **Natural Mode:** Simulates natural breeze by varying the fan speed intermittently.
  - **Night Mode:** Operates at a lower, quieter speed, ideal for sleeping, and may gradually decrease speed over time.
- **Oscillation Function:** Press the **SWING** button to activate or deactivate the oscillation function. When activated, the fan will rotate horizontally up to 70 degrees to distribute air across a wider area.

Figure 5: Beper P206VEN350 Optimal Oscillation for Large Environments. This image visually represents the fan's 70-degree oscillation capability, showing the wide area of air distribution, making it suitable for larger rooms.

- **Timer Function:** Press the **TIMER** button to set the automatic shut-off time. Each press will increase the timer by 1 hour, up to a maximum of 15 hours. The set time will be displayed on the LED screen. The fan will automatically turn off once the set time has elapsed.
- **Purification Function:** The active carbon filter continuously works to purify the air by capturing dust particles and organic compounds. This function operates automatically when the fan is running.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Beper P206VEN350 fan.

Cleaning the Fan:

- Always unplug the fan from the power outlet before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- For hard-to-reach areas, such as air intake vents, use a soft brush or a vacuum cleaner with a brush attachment to remove dust.
- Ensure no water or liquids enter the internal components of the fan.
- Allow the fan to dry completely before plugging it back in.

Active Carbon Filter Maintenance:

The active carbon filter should be checked and cleaned periodically, depending on usage and air quality. Refer to the filter compartment for specific instructions on removal and reinstallation.

- **Cleaning:** Gently vacuum the filter to remove accumulated dust and debris. Do not wash the active carbon filter with water, as this can damage its purification properties.
- **Replacement:** The active carbon filter has a limited lifespan. If you notice a decrease in purification effectiveness or persistent odors, it may be time to replace the filter. Contact Beper customer support or an authorized dealer for replacement filters.

Storage:

When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

Troubleshooting

If you encounter any issues with your Beper P206VEN350 fan, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power button not pressed.	Check if the power cord is securely plugged into a working outlet. Press the POWER button on the unit or remote control.
Weak or no airflow.	Air inlets/outlets blocked. Filter is dirty. Fan speed set too low.	Ensure nothing is obstructing the air vents. Clean or replace the active carbon filter. Increase the fan speed setting.
Fan makes unusual noise.	Fan not on a level surface. Obstruction inside the unit.	Place the fan on a flat, stable surface. Unplug the fan and carefully check for any foreign objects. Do not attempt to disassemble the unit.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Remove any objects blocking the line of sight between the remote and the fan's sensor.

Specifications

Brand	Beper
Model Number	P206VEN350
Colour	White
Product Dimensions (L x W x H)	24 x 24 x 97 cm
Item Weight	4.03 kg
Power / Wattage	50 watts
Voltage	110 Volts
Special Features	High Velocity, Bladeless, Oscillating, Purification function, Active carbon filter, LED display, Touch panel, Remote control

Number of Speeds	3
Ventilation Modes	3 (Normal, Natural, Night)
Timer	Up to 15 hours

Warranty and Support

This Beper P206VEN350 fan is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for detailed terms and conditions, including the warranty period and coverage.

For technical support, replacement parts, or warranty claims, please contact Beper customer service. Contact information can typically be found on the product packaging, the official Beper website, or your purchase receipt.

When contacting support, please have your product model number (P206VEN350) and purchase date ready.

© 2024 Beper. All rights reserved.

Model: P206VEN350

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XN3Z69T

More documents and user manuals: **https://manuals.plus/**