

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [WATOOR](#) /

> [WATOOR JC-36 Wine Cooler and Beverage Refrigerator User Manual](#)

WATOOR JC-36

WATOOR JC-36 Wine Cooler and Beverage Refrigerator User Manual

Model: JC-36

1. INTRODUCTION

Thank you for choosing the WATOOR JC-36 Wine Cooler and Beverage Refrigerator. This appliance is designed to store your beverages at optimal temperatures, ranging from 40°F to 61°F. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read it thoroughly before use and retain it for future reference.





Image 1.1: Front view of the WATOOR JC-36 Wine Cooler and Beverage Refrigerator, showcasing its glass door and interior shelving with wine bottles.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces, especially when the appliance is operating.
- Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Before cleaning or performing any maintenance, ensure the unit is unplugged from the power outlet.
- Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- This appliance is for freestanding use only. Do not use for built-in applications.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged:

- WATOOR JC-36 Wine Cooler and Beverage Refrigerator Unit
- Removable Wire Shelves (Quantity: 1 or more, as needed for configuration)

4. SETUP AND INSTALLATION

4.1 Location

Place the appliance on a flat, solid surface strong enough to support it when fully loaded. Ensure adequate ventilation around the unit. This appliance is designed for freestanding installation only and should not be built into cabinetry.




Image 4.1: The WATOOR JC-36 Beverage Refrigerator positioned as a freestanding unit under a kitchen counter, demonstrating suitable placement.

4.2 Leveling

Adjust the leveling legs at the bottom of the unit to ensure it is perfectly level. Proper leveling is crucial for efficient operation and to prevent vibrations.

4.3 Power Connection

Plug the appliance into a dedicated, grounded electrical outlet. Allow the unit to stand upright for at least 2-4 hours before

plugging it in to allow the refrigerant to settle.

5. OPERATING INSTRUCTIONS

5.1 Control Panel

The control panel is located on the top front of the unit. It features buttons for temperature adjustment, interior light control, and a control panel lock function.



Image 5.1: A close-up view of the digital control panel, showing the temperature display, light control, and temperature adjustment buttons.

5.2 Temperature Adjustment

- The temperature range is 40°F to 61°F (4°C to 16°C).
- To adjust the temperature, first unlock the control panel by pressing and holding the lock button for 3 seconds.
- Use the ▲ (Up) and ▼ (Down) buttons to set your desired temperature. The digital display will show the current internal temperature.

5.3 Interior Light

Press the light bulb icon button on the control panel to turn the interior blue LED light on or off. This light aids visibility inside the cooler.




Image 5.2: The interior of the cooler illuminated by soft blue LED lighting, enhancing visibility of stored items.

6. LOADING AND STORAGE

The WATOOR JC-36 offers a 2.7 cubic feet capacity, capable of holding up to 85 standard 12-oz cans or 24 standard 750ml wine bottles.

Large Capacity

For large quantities of cans and bottles

300ml



x85
TINS

750ml



x24
BOTTLES



Image 6.1: The interior of the cooler with its door open, illustrating the spacious design and removable wire shelves for flexible storage of various beverage types.

6.1 Wire Shelves

The unit includes removable wire shelves that can be adjusted to accommodate different sizes of bottles and cans. Ensure items are placed evenly to prevent shelves from sagging.



Image 6.2: Detail of the sturdy, removable wire shelves designed for flexible storage configurations.

7. MAINTENANCE AND CLEANING

7.1 Cleaning the Interior

Unplug the appliance before cleaning. Use a soft cloth with a mild, non-abrasive cleaner to wipe down the interior surfaces. Remove shelves and clean them separately. Ensure all parts are dry before reinserting and plugging the unit back in.

7.2 Cleaning the Exterior

Wipe the exterior with a soft, damp cloth. For the glass door, use a glass cleaner. Avoid harsh chemicals or abrasive materials that could damage the finish.

7.3 Door Seal

Regularly check the door seal for any signs of damage or wear. A tight door seal is essential for maintaining the internal temperature and energy efficiency.



Image 7.1: Detail of the door hinge and seal, highlighting the importance of a secure closure for insulation.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; circuit breaker tripped; temperature set too high.	Ensure plug is secure; reset circuit breaker; lower temperature setting.
Temperature is not cold enough	Door opened too frequently; door not closed properly; poor ventilation; excessive items stored.	Minimize door openings; check door seal; ensure adequate space around unit; do not overfill.
Excessive noise	Appliance not level; loose parts; normal compressor operation.	Adjust leveling legs; check for loose items; slight humming is normal.
Condensation on glass door	High humidity; door not sealed properly.	This can be normal in humid environments; ensure door is fully closed and seal is intact.

9. SPECIFICATIONS

Detailed technical specifications for the WATOOR JC-36 Wine Cooler and Beverage Refrigerator:



Image 9.1: Dimensional diagram of the WATOOR JC-36, indicating height, width, and depth in both millimeters and inches.

Feature	Detail
Brand	WATOOR
Model Number	JC-36
Capacity	2.7 Cubic Feet (approx. 85 cans or 24 wine bottles)
Temperature Range	40°F - 61°F (4°C - 16°C)
Product Dimensions (D x W x H)	18.1 x 16.9 x 29.1 inches (460 x 430 x 740 mm)
Item Weight	32 Pounds
Installation Type	Freestanding
Door Material Type	Glass (Double Pane)
Shelf Type	Removable Wire Shelves
Defrost System	Automatic
Voltage	115 Volts
Certification	ETL

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact WATOOR customer service. Keep your purchase receipt as proof of purchase for any warranty claims.