

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Playseat](#) /

› [Playseat Trophy Sim Racing Cockpit Instruction Manual](#)

Playseat RAP.00304

Playseat Trophy Sim Racing Cockpit Instruction Manual

Model: RAP.00304

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your Playseat Trophy Sim Racing Cockpit. Please read this manual thoroughly before use to ensure proper setup and safe operation. Retain this manual for future reference.

The Playseat Trophy is a high-performance racing simulator cockpit designed for optimal comfort, stability, and compatibility with various steering wheel and pedal configurations, including Direct Drive systems.

2. SAFETY INFORMATION

- Ensure all bolts and connections are securely tightened before each use.
- Do not exceed the maximum recommended driver weight of 122 kg (269 lb).
- Keep hands and fingers clear of moving parts during adjustment.
- Place the cockpit on a stable, level surface to prevent tipping.
- Keep children and pets away from the cockpit during use and adjustment.
- Avoid placing liquids directly on or near electronic components.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Playseat Trophy Frame (various sections)
- ActiFit Seat Material

- Wheel Mount Plate
- Pedal Mount Plate
- Assembly Hardware (bolts, nuts, washers, Allen keys)
- Instruction Manual (this document)



Image: All components of the Playseat Trophy Sim Racing Cockpit laid out for assembly.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Playseat Trophy cockpit. It is recommended to have a clear, spacious area for assembly.

4.1. Frame Assembly

1. Unpack all components and verify against the package contents list.
2. Attach the two side base plates to the bottom of the seat using the provided bolts and Allen key. Ensure they are securely fastened.
3. Connect the two small beams between the base plates. Position the holes in the beams perpendicular to the ground.
4. Mount the widest sliding pipe to the two beams using the large socket cap bolts. Ensure the threading hole faces upward and towards the front of the chair.

DYNAMIC COMFORT & SUPPORT

Discover the perfect blend of comfort and performance with the Playseat® trophy. Our design features a frameless yet exceptionally stable seating structure that conforms to your body. The backrest reclines separately, and the firmness can be easily customized to your liking, giving you adjustable lumbar support and control.



Image: Illustration of frame assembly, connecting side plates and beams.

4.2. Pedal and Wheel Mount Installation

1. Attach the pedal base plate to the pedal mount part using the small socket cap bolts.
2. Screw the hex nuts onto the levelers and bolt these into the bottom of the pedal mounting base.
3. Slide the wheel mounting plate into the center beam and secure it with a tightening handle.
4. Attach your steering wheel and pedals to their respective mounts using the manufacturer's instructions.

UNLIMITED POSITION CUSTOMISATION

Designed to accommodate drivers of all ages and sizes, the Playseat® Trophy allows you to easily tailor your setup to perfection with full adjustability, enabling you to position the wheel and pedals exactly where you desire. Adjust the tilt forward and backward, and effortlessly shift them up or down to achieve your desired configuration.



Image: Detailed view of pedal and wheel mount installation.

4.3. Seat Cushion and Adjustments

1. Unwrap the ActiFit seat cushion and secure it onto the frame.
2. Adjust the seat back angle by setting the two drop bolts in place.
3. Use the tightening handles to adjust the position of the wheel and pedal mounts for optimal ergonomics.
4. Level the pedal base area using the adjustable levelers.

OPEN COCKPIT DESIGN

The Playseat® trophy is crafted to embrace racers of all ages and sizes, ensuring that everyone feels secure and race ready.

With the open cockpit design, it enables free body movement, enhancing wheel and pedal performance to the fullest extent.



Image: Demonstrating the adjustability of the Playseat Trophy cockpit.

5. OPERATING INSTRUCTIONS

The Playseat Trophy is designed for intuitive use. Once assembled and adjusted to your preference, connect your steering wheel and pedals to your PC or console according to their respective manufacturer's instructions.

- **Entering the Cockpit:** The open cockpit design allows for easy entry and exit.
- **Adjustments:** Fine-tune the wheel and pedal positions using the quick-release mechanisms and tightening handles. The seat back angle can also be adjusted for optimal comfort.
- **Stability:** Ensure all locking mechanisms are engaged before beginning your racing session to maintain stability.

Your browser does not support the video tag.

Video: Official Playseat video demonstrating the racing simulator in use.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Playseat Trophy cockpit.

- **Cleaning:** Wipe down the frame with a damp cloth. The ActiFit fabric can be spot cleaned with a mild detergent and water. Avoid harsh chemicals.
- **Fasteners:** Periodically check all bolts, nuts, and tightening handles to ensure they are secure. Tighten if necessary.
- **Storage:** The lightweight design allows for easy storage. If not in use for extended periods, consider storing it in a dry, cool place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cockpit feels unstable/wobbly	Loose fasteners; uneven surface.	Check and tighten all bolts and handles. Ensure the cockpit is on a flat surface. Adjust levelers if present.
Difficulty adjusting wheel/pedal position	Tightening handles not fully loosened.	Ensure all relevant tightening handles are fully loosened before attempting adjustment.
Steering wheel/pedals not recognized by PC/console	Incorrect connection; driver issues.	Verify all cables are securely connected. Refer to your steering wheel/pedal manufacturer's manual for driver installation and troubleshooting.

8. SPECIFICATIONS

- **Model:** Playseat Trophy
- **Color:** Black
- **Material:** ActiFit Fabric, Carbon Steel Frame
- **Direct Drive Support:** Yes
- **Dimensions (L x W x H):** 138 x 58 x 101 cm (55.12 x 22.83 x 39.37 inches)
- **Weight:** 16 kg (33.07 lbs)
- **Optimal Driver Height:** 120 - 220 cm
- **Optimal Driver Weight:** 20 - 122 kg (44 - 269 lb)
- **Compatibility:** All major steering wheel and pedal configurations on PC and console.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Playseat website or contact their customer service

directly. Keep your proof of purchase for any warranty claims.

Official Playseat Store: [Visit Playseat Store](#)

© 2023 Playseat. All rights reserved.