

IRONZON F190B

IRONZON Fingerprint Smart Door Lock Instruction Manual

Model: F190B | Brand: IRONZON

1. PRODUCT OVERVIEW

The IRONZON Fingerprint Smart Door Lock offers a secure and convenient 4-in-1 keyless entry solution for residential homes, hotels, offices, apartments, and bedrooms. This advanced door lock integrates multiple unlocking methods including fingerprint recognition, password entry, mobile application control, and traditional backup keys. Designed for ease of use and robust security, the lock features a high fingerprint recognition rate, allowing access in approximately 1 second. It supports up to 50 unique fingerprints and offers flexible password management, including temporary password generation for guests or service providers. The smart app functionality provides remote control and monitoring capabilities, enhancing overall security and convenience.



Image: The IRONZON Fingerprint Smart Door Lock, showcasing its sleek black design with integrated keypad and fingerprint sensor, alongside a mobile phone displaying the companion app interface.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning installation.

- 1 x IRONZON Fingerprint Smart Door Lock (Front and Rear Handles)
- 2 x Backup Keys
- 1 x Latch/Deadbolt Mechanism
- 1 x Installation Hardware Kit (Screws, Spindle, etc.)
- 1 x User Manual (This document)

3. INSTALLATION GUIDE

The IRONZON Fingerprint Smart Door Lock is designed for easy installation, typically within 10 minutes, requiring no additional drilling for standard US doors. It is compatible with door thicknesses from 1-3/8" to 2-1/8" (35 mm - 55 mm) and backsets of 2-3/8" (60mm) and 2-1/8" (70 mm). The lock is suitable for both left-handed and right-handed doors.

3.1 Preparation

1. Ensure your door meets the specified dimensions.
2. Gather necessary tools: Phillips head screwdriver.
3. Remove any existing door hardware.

3.2 Installation Steps

1. Install the latch/deadbolt mechanism into the door edge. Ensure the latch bolt is facing the correct direction for your door swing.
2. Insert the spindle through the latch mechanism.
3. Attach the exterior handle assembly, ensuring the spindle aligns correctly.
4. Connect the interior handle assembly, carefully routing any wires to avoid pinching.
5. Secure both handle assemblies with the provided screws.
6. Install 4 AAA batteries into the battery compartment of the interior handle.
7. Test the lock's basic functionality before closing the door.

Easy Installation Within 10 Minutes



Image: Diagram illustrating the simple installation process of the IRONZON Smart Door Lock, highlighting that no additional drilling is required and installation can be completed with a screwdriver.

4. SETUP AND PROGRAMMING

After installation, configure your lock for secure access using the mobile app, fingerprints, and passcodes.

4.1 Mobile App Setup

The lock supports both iOS and Android devices for smart control. Download the dedicated app (refer to the packaging or quick start guide for app name/QR code) to unlock, manage users, and set temporary passwords.

1. Download and install the smart lock application from your device's app store.
2. Create an account and log in.
3. Follow the in-app instructions to add your IRONZON Smart Door Lock. This typically involves pairing via Bluetooth or Wi-Fi.
4. Once paired, you can use the app to unlock the door, add/delete users, and manage settings.

APP Unlock

Share Your Smart Life with Your Family and Friends



Image: A smartphone screen displaying the IRONZON smart lock app interface, showing a locked padlock icon, indicating the ability to unlock the door via the application.

4.2 Fingerprint Enrollment

The lock can store up to 50 unique fingerprints. Ensure your finger is clean and dry during enrollment for optimal recognition.

1. Access the fingerprint management section within the mobile app or follow the lock's direct programming instructions (usually involving pressing a button on the interior handle).
2. Place your finger on the fingerprint sensor multiple times as prompted, adjusting the angle slightly each time to capture a comprehensive scan.
3. A confirmation sound or light will indicate successful enrollment.

Fingerprint Unlock



360° fingerprint
recognition support



Fast read speed
0.1s unlocking



Fingerprint
Unlock



Image: A close-up of the IRONZON Smart Door Lock's handle, highlighting the fingerprint sensor with a blue glowing ring, indicating its 360-degree recognition support and fast 0.1-second unlocking speed.

4.3 Passcode Setup

You can set permanent or temporary passcodes for access. The lock supports an anti-peeping feature, allowing you to enter random numbers before or after your actual code to prevent others from guessing it.

1. Navigate to the password management section in the mobile app or use the lock's keypad programming mode.
2. Enter your desired passcode, ensuring it meets any length requirements (e.g., minimum 6 digits).
3. Confirm the passcode.
4. For temporary passcodes, specify the duration or number of uses as prompted by the app.

Password Unlock

Relaxing Travel Experience



Image: A hand entering a password on the keypad of the IRONZON Smart Door Lock, with an overlay demonstrating the anti-peeping password feature where random numbers can be entered before or after the real password.

5. OPERATION

Operating your IRONZON Smart Door Lock is straightforward with its multiple access methods.

5.1 Unlocking with Fingerprint

- Place your enrolled finger firmly on the fingerprint sensor.
- The lock will verify your fingerprint (indicated by a light or sound).
- Once verified, the lock will unlock, allowing you to turn the handle and open the door.

5.2 Unlocking with Passcode

- Touch the keypad to activate it.
- Enter your registered passcode (optionally, include random digits before or after for anti-peeping).

- Press the '#' key or wait for automatic confirmation.
- The lock will unlock upon successful code entry.

5.3 Unlocking with Mobile App

- Open the IRONZON smart lock application on your smartphone.
- Ensure your phone is within Bluetooth range of the lock or connected via Wi-Fi (if applicable).
- Tap the unlock icon within the app.
- The lock will receive the command and unlock.

5.4 Unlocking with Backup Key

- Insert one of the provided backup keys into the keyhole located on the exterior handle.
- Turn the key to unlock the mechanism.
- This method is useful for emergencies or when batteries are depleted.

Key Unlock

Multiple unlocking methods to protect your family



Image: The IRONZON Smart Door Lock with a physical key inserted into its keyhole, demonstrating the traditional backup unlocking

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your IRONZON Smart Door Lock.

- **Battery Replacement:** The lock requires 4 AAA batteries. It features a low battery reminder function. When the battery alert is active, replace all four batteries promptly to avoid loss of functionality.
- **Emergency Charging:** In case of complete battery depletion, the lock is equipped with a Type-C interface for emergency charging. Connect a portable power bank via a Type-C cable to temporarily power the lock and gain access.
- **Cleaning:** Wipe the lock's surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish or electronic components.
- **Fingerprint Sensor:** Keep the fingerprint sensor clean and free of dirt or moisture for accurate readings.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your IRONZON Smart Door Lock.

Problem	Possible Cause	Solution
Lock does not respond or power on.	Dead batteries; incorrect battery installation.	Replace all 4 AAA batteries. Ensure batteries are inserted with correct polarity. Use emergency Type-C power if needed.
Fingerprint not recognized.	Finger is wet, dirty, or improperly placed; fingerprint not enrolled.	Ensure finger is clean and dry. Place finger firmly and completely on the sensor. Try different angles. Re-enroll fingerprint if issue persists.
Passcode not working.	Incorrect passcode entered; passcode expired (for temporary codes).	Verify the passcode. Ensure you are pressing '#' after the code. Check if it's a temporary code that has expired. Reset passcode via app if necessary.
App cannot connect to the lock.	Bluetooth/Wi-Fi off; lock not paired; app issues.	Ensure Bluetooth is enabled on your phone. Re-pair the lock with the app. Restart the app or your phone. Check app permissions.
Lock beeps continuously.	Low battery; internal error.	Replace batteries immediately. If beeping continues after battery replacement, contact customer service.

If you encounter issues not listed here or require further assistance, please refer to the customer service information in Section 9.

8. SPECIFICATIONS

Feature	Detail
Model Number	F190B
Brand	IRONZON

Feature	Detail
Lock Type	Keypad, Fingerprint
Material	Zinc
Color	APP Black
Dimensions (L x W x H)	6.3 x 2.3 x 2.3 inches
Item Weight	1 pound
Power Source	4 x AAA Batteries (Included)
Emergency Power	Type-C Interface
Connectivity	Wi-Fi (for app control)
Controller Type	Android, iOS
Door Thickness Compatibility	1-3/8" to 2-1/8" (35 mm - 55 mm)
Backset Compatibility	2-3/8" (60mm) and 2-1/8" (70 mm)
Fingerprint Capacity	Up to 50 groups
First Available Date	April 12, 2022

9. WARRANTY AND CUSTOMER SUPPORT

IRONZON is committed to providing high-quality products and customer satisfaction.

9.1 Return Policy

This product is subject to a 30-day return policy for refund or replacement, as per standard retail terms.

9.2 Customer Service

For any product information, questions, or technical support, please contact IRONZON customer service. We aim to respond to inquiries within 24 hours.

Manufacturer: IRONZON

For support, please visit the official IRONZON store page or contact through the platform where the product was purchased. [Visit IRONZON Store on Amazon](#)

Related Documents

IRONZON FINGERPRINT KNOB (280X)



[IRONZON Fingerprint Knob \(280X\) User Manual and Installation Guide](#)

This document provides comprehensive instructions for installing and operating the IRONZON Fingerprint Knob (280X), covering the packing list, installation dimensions, step-by-step installation procedures, operation of the Tuya Smart App for managing the lock, adding fingerprints and members, connecting to a Bluetooth gateway for remote control, adjusting volume settings, and useful tips for usage.