

Goreit Goreit-AU-G9322

Goreit XHP70.2 LED Flashlight User Manual

Model: Goreit-AU-G9322

1. PRODUCT OVERVIEW

The Goreit XHP70.2 LED Flashlight is a high-performance, rechargeable tactical torch designed for various outdoor and emergency applications. Featuring a powerful XHP70.2 LED chip, it delivers up to 15000 lumens of super bright light. Its robust aerospace-grade aluminum alloy construction ensures durability and IP67 waterproof rating. The flashlight offers multiple light modes, a zoomable beam, and a convenient USB input/output for charging and power bank functionality.



Image: The Goreit XHP70.2 LED Flashlight, showcasing its design, included USB charging cables, and an inset image demonstrating its powerful beam illuminating a distant area.

2. SAFETY INFORMATION

- **Caution:** To prevent accidental activation and battery drain, press and hold the power switch for **3 seconds** to turn the flashlight ON or OFF.
- Do not shine the light directly into eyes. The high intensity beam can cause temporary vision impairment.
- Keep out of reach of children.
- Do not disassemble the flashlight head or internal components, as this may damage the device and void the warranty.
- Use only the specified battery type and charging methods.
- Avoid exposing the flashlight to extreme temperatures or corrosive liquids.

3. PACKAGE CONTENTS

Upon opening your Goreit Flashlight package, please verify that all the following items are included:

- 1 x Goreit Rechargeable Flashlight
- 1 x Lithium-Ion Battery (pre-installed or separate)
- 1 x USB Charging Cable (Type-C)
- 1 x Lanyard
- 1 x Operating Instructions Manual (this document)



Image: A visual representation of the items included in the Goreit flashlight package, such as the flashlight unit, battery, USB cable, and lanyard.

4. SETUP

4.1 Battery Installation

If the battery is not pre-installed, unscrew the tail cap of the flashlight. Insert the provided Lithium-Ion battery with the positive (+) end facing towards the head of the flashlight. Screw the tail cap back on securely.

4.2 Initial Charging

Before first use, it is recommended to fully charge the flashlight. Connect the supplied USB charging cable to the flashlight's USB port and to a compatible USB power source (e.g., wall adapter, computer, power bank). The indicator light on the switch will turn red during charging and green when fully charged.

USB Input & Output



Image: A diagram illustrating the USB input and output capabilities of the flashlight, showing how it can be recharged via various USB ports and used to charge other devices.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

To turn the flashlight **ON**, press and hold the power switch for approximately **3 seconds**. To turn the flashlight **OFF**, press and hold the power switch for approximately **3 seconds** again.

5.2 Light Modes

Once the flashlight is on, short press the power switch to cycle through the 5 available light modes:

1. **High:** Maximum brightness for powerful illumination.

2. **Medium:** Balanced brightness for general use.
3. **Low:** Reduced brightness for extended battery life or close-range tasks.
4. **Strobe:** Rapid flashing light for signaling or disorientation.
5. **SOS:** International Morse code signal for emergencies.




Image: A visual guide to the flashlight's five light modes (High, Medium, Low, Strobe, SOS) and the instruction to press and hold the switch for 3 seconds to activate the device.

5.3 Zoom Function (Adjustable Focus)

The flashlight features an adjustable focus mechanism. Gently push or pull the head of the flashlight to switch between a focused spotlight beam and a wide floodlight beam.

- **Spotlight:** Pull the head outwards for a narrow, long-distance beam. Ideal for pinpointing objects far away.
- **Floodlight:** Push the head inwards for a wide, diffused beam. Suitable for illuminating a large area up close.



Image: A visual comparison demonstrating the flashlight's ability to switch between a focused spotlight for long-range illumination and a wide floodlight for broader area coverage.

6. CHARGING AND POWER BANK FUNCTION

6.1 Charging the Flashlight

The flashlight is equipped with a built-in USB charging port. To charge, connect the USB-C end of the provided cable to the flashlight's charging port and the USB-A end to a power adapter, computer, or car charger. The indicator light on the switch will glow **red** during charging and turn **green** when the battery is fully charged. Charging time is reduced, and the working time is extended up to 10 hours on low mode.




Image: A detailed diagram highlighting the upgraded XHP70.2 LED chip, which is central to the flashlight's powerful illumination and efficient energy use.

6.2 Power Bank Function (USB Output)

The flashlight can also function as a power bank to charge other electronic devices. Connect your device's charging cable to the flashlight's USB output port. This feature is useful for charging mobile phones or other small digital products in emergency situations.



Image: An icon illustrating the anti-slip texture design of the flashlight, enhancing grip and handling security.

7. MAINTENANCE

- **Cleaning:** Wipe the flashlight body with a clean, soft cloth. For stubborn dirt, a slightly damp cloth can be used. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the battery when the indicator light turns red. If storing for a long period, charge the battery every 3-6 months to maintain its health.
- **Lubrication:** Periodically apply a thin layer of silicone grease to the O-rings and threads to maintain waterproof integrity and smooth operation.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is low or depleted. Battery inserted incorrectly. Power switch not pressed for 3 seconds.	Charge the battery fully. Check battery polarity (+/-). Press and hold the switch for 3 seconds.
Light output is dim.	Battery is low. Lens is dirty.	Recharge the battery. Clean the lens with a soft cloth.
Flashlight not charging.	Charging cable or adapter faulty. Charging port dirty. Battery not making contact.	Try a different cable/adapter. Clean the charging port. Ensure battery is properly seated.
Beam is inconsistent or flickers.	Loose connections. Low battery.	Tighten all parts (head, body, tail cap). Charge the battery.

9. SPECIFICATIONS

Feature	Detail
Brand	Goreit
Model Number	Goreit-AU-G9322
Light Source	XHP70.2 LED Chip
Luminous Flux	15000 Lumens
Light Modes	High, Medium, Low, Strobe, SOS
Power Source	Battery Powered (1 Lithium Ion battery included)
Voltage	3.7 Volts
Charging	USB Rechargeable (USB Input & Output)
Material	Aerospace Grade Aluminum Alloy
Color	Black
Waterproof Rating	IP67 (Submersible up to 1 meter for 30 minutes)
Special Features	Zoomable Adjustable Focus, Weather & Shock Resistant, Safety Hammer Design
Product Dimensions	3 x 18.01 x 4.29 cm
Item Weight	330 g

10. WARRANTY AND SUPPORT

Goreit is committed to providing high-quality lighting products. For any questions, concerns, or assistance with your Goreit flashlight, please do not hesitate to contact our customer service team. We offer **7x24-hour customer service** to ensure your satisfaction.

Please refer to your purchase documentation for specific warranty terms and conditions. Keep your proof of purchase for any warranty claims.

© 2024 Goreit. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XQPM4M7>

More documents and user manuals: <https://manuals.plus/>