

[Manuals.plus](#) /

› [DOMETIC](#) /

› DOMETIC 386520126 Original Remote Control User Manual

DOMETIC 386520126

DOMETIC 386520126 Original Remote Control User Manual

For DOMETIC Air Conditioners

1. INTRODUCTION

This manual provides comprehensive instructions for the proper use and maintenance of your DOMETIC 386520126 Original Remote Control. This remote is designed for seamless operation with compatible DOMETIC air conditioning units, offering convenient control over various functions. Please read this manual thoroughly before operating the device.

2. PRODUCT OVERVIEW

The DOMETIC 386520126 is an ergonomic infrared remote control specifically designed for DOMETIC air conditioners. It features a clear display and intuitive button layout for easy operation.



Image 1: The DOMETIC 386520126 Original Remote Control, featuring a black body, a display screen, and various control buttons for air conditioner functions.

Key Features:

- **Ergonomic Design:** Comfortable to hold and operate.
- **Infrared Technology:** Reliable communication with your air conditioner.
- **Clear Display:** Shows current settings and modes.
- **Dedicated Function Buttons:** Easy access to all air conditioner features.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Always use new batteries of the same type. Do not mix old and new batteries or different types of batteries. Remove batteries if the remote will not be used for an extended period.

3.2 Initial Use

Once batteries are installed, the remote control is ready for use. Point the remote directly at the infrared receiver on your DOMETIC air conditioner unit. No complex pairing is typically required for original infrared remote controls.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your remote control:

- **Power Button** (): Turns the air conditioner unit ON or OFF.
- **Mode Button (MODE)**: Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **Temperature Adjustment Buttons (+ / -)**: Increases or decreases the desired temperature setting.
- **Fan Speed Button** (): Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Sleep Mode Button** (): Activates or deactivates sleep mode for quieter operation and energy saving.
- **Timer Button** (): Sets a timer for the unit to turn ON or OFF automatically.
- **Light Button** (): Controls the display light on the air conditioner unit, if applicable.
- **Set Button (SET)**: Confirms settings for functions like Timer.
- **C/F Button (°C/°F)**: Toggles the temperature display between Celsius and Fahrenheit.
- **Air Flow Direction Button** (): Adjusts the direction of the air flow (swing function).

5. MAINTENANCE

5.1 Cleaning the Remote Control

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote's display becomes dim or the air conditioner unit no longer responds reliably to commands. Refer to section 3.1 for battery installation instructions.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are correctly inserted and have sufficient charge. Replace if necessary.
 - Ensure there are no obstacles between the remote control and the air conditioner's infrared receiver.
 - Make sure you are within the effective operating range (up to 10 meters).
- **Display is dim or blank:**
 - This usually indicates low battery power. Replace the batteries.

- **Incorrect temperature reading:**
 - Press the °C/°F button to switch between Celsius and Fahrenheit if the unit is displaying the wrong scale.

7. SPECIFICATIONS

Feature	Specification
Brand	DOMETIC
Model Number	386520126
Color	Black
Connectivity Technology	Infrared
Special Feature	Ergonomic
Compatible Devices	Air Conditioner
Number of Buttons	12
Controller Type	Button Control
Maximum Range	10 Meters
Battery Type	AAA

8. WARRANTY AND SUPPORT

Warranty information for the DOMETIC 386520126 Original Remote Control is typically provided with the compatible air conditioning unit. For specific warranty details or technical support, please refer to the documentation included with your air conditioner or visit the official [DOMETIC website](#).

© 2023 DOMETIC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XR5R9GF>

More documents and user manuals: <https://manuals.plus/>