

[Manuals.plus](#) /

› [GEAMENT](#) /

› GEAMENT LED Light Kit for Lego Hogsmeade Village Visit 76388 Instruction Manual

GEAMENT 76388C

GEAMENT LED Light Kit for Lego Hogsmeade Village Visit 76388 - Instruction Manual

PRODUCT OVERVIEW

This GEAMENT LED Light Kit is specifically designed to enhance your Lego Hogsmeade Village Visit (model 76388) by adding illumination. Please note that this product includes only the lighting components; the Lego model set itself is not included.



Important notice: This product is a lighting kit only, the Lego model set is not included.

PACKAGE CONTENTS

Before you begin, please verify that all components listed below are present in your package:

- LED lighting components (various lights and wires)
- User manual (simple guide)
- Battery box (for power, batteries not included)
- USB power cable

Important: this item only includes lighting kit,

NOT MODEL SET

Wichtig: Dieser Artikel enthält nur Beleuchtungsset,

Nicht Modell-Set

Belangrijk: dit item omvat alleen verlichting kit,

Niet Bouwsteenmodel

¡Nota importante: este producto sólo contiene kits de iluminación,

Juego Modelo No Incluido

Important: cet article ne contient que des kits d'éclairage,

Pas de Jouets en Blocs

Importante: questo articolo include solo kit di illuminazione,

Non Modello Set



Components included in the GEAMENT LED Light Kit: LED lights, battery box, and USB cable.

SETUP AND INSTALLATION GUIDE

Important Pre-Installation Notes

Before beginning installation, ensure your Lego Hogsmeade Village Visit (model 76388) is fully assembled. The lighting kit is designed to be integrated into a completed model.

A simple user manual is included in the package. For detailed, step-by-step PDF installation instructions, please follow the prompts provided in the included manual to download them.

Installation Steps Overview

The installation process involves carefully integrating the LED lights and wiring into your Lego model. Patience and attention to detail are crucial to avoid damaging the components or the model. Follow the detailed PDF instructions for precise placement and connection of each light.

Your browser does not support the video tag.

Official GEAMENT video demonstrating the light kit installation and final illuminated effect for the Lego Hogsmeade Village Visit 76388.

Lighting effect display

Product does not contain model set



The completed Lego Hog's Head Inn model illuminated by the GEAMENT LED light kit, showcasing the interior lighting.

Lighting effect display
Product does not contain model set



Close-up view of the illuminated interior of one of the Hogsmeade Village buildings.

Lighting effect display
Product does not contain model set



Detailed view of illuminated windows within the Lego Hogmeade Village model.

Lighting effect display
Product does not contain model set



Interior shot of a building in the Lego Hogsmeade Village, showing subtle lighting effects on details.

Lighting effect display

Product does not contain model set



Upper floor interior of a Hogsmeade Village building, highlighting the integrated lighting.

OPERATING INSTRUCTIONS

Powering the Light Kit

The light kit can be powered by a battery box (requires 3x AA batteries, not included) or via a compatible USB power source. Connect the USB cable from the light kit to the battery box or a USB power adapter (e.g., phone charger, power bank).

Switching On/Off

The light kit features a remote control for switching the lights on and off. Refer to the detailed PDF instructions for specific remote control functions, including brightness adjustment or lighting modes if available.

MAINTENANCE

Cleaning

To clean the LED lights and wires, gently wipe with a dry, soft cloth. Avoid using liquids, solvents, or

abrasive cleaners, as these can damage the components.

Storage

When not in use for extended periods, disconnect the power source (remove batteries or unplug USB) and store the light kit in a dry, cool place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Lights Not Turning On

- Ensure batteries are correctly inserted into the battery box and are not depleted. Replace with fresh batteries if necessary.
- Verify all connections are secure between the light kit, battery box, and USB cable.
- If using a USB power adapter, ensure it is functioning correctly and providing adequate power (5 Volts). Try a different USB port or adapter.

Flickering Lights

- Check for loose connections along the wiring.
- Replace batteries if they are low, as insufficient power can cause flickering.
- Ensure the power source is stable and not experiencing interruptions.

Damaged Wires/LEDs

Handle wires and LEDs with care during installation and operation. If components appear damaged, avoid attempting repairs yourself. Contact customer support for assistance.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	GEAMENT
Model Name	GEAMENT 76388 (Item model number: 76388C)
Light Source Type	LED
Power Source	Battery Powered (USB compatible)
Voltage	5 Volts
Control Method	Remote
Indoor/Outdoor Usage	Indoor
Material	Plastic
Item Weight	3.88 ounces (110 Grams)
Product Dimensions	5.91 x 3.94 x 1.18 inches

WARRANTY AND SUPPORT

Warranty Information

This product comes with a standard manufacturer's warranty. Please refer to the packaging or the detailed PDF instructions for specific warranty terms and conditions, including duration and coverage.

Customer Support

For any questions, technical assistance, or support regarding your GEAMENT LED Light Kit, please contact GEAMENT customer service through the retailer where the product was purchased or visit the official GEAMENT store page on Amazon for contact information.