

[Manuals.plus](#) /

› [LEGO](#) /

› LEGO Disney Princess Cinderella and Prince Charming's Castle 43206 Instruction Manual

LEGO 43206

LEGO Disney Princess Cinderella and Prince Charming's Castle

MODEL: 43206

Brand: LEGO

1. INTRODUCTION

This instruction manual provides detailed guidance for assembling and enjoying your LEGO Disney Princess Cinderella and Prince Charming's Castle (Model 43206). Designed for builders aged 5 and up, this set contains 365 pieces, offering an engaging and creative building experience.

The set allows for the construction of a multi-level castle featuring various interactive elements and includes beloved characters from the Cinderella story. Please read all instructions carefully before beginning assembly.

2. COMPONENTS OVERVIEW

The LEGO Disney Princess Cinderella and Prince Charming's Castle set includes:

- **3 Mini-doll Figures:** Cinderella, Prince Charming, and Lady Tremaine.
- **2 Animal Figures:** Gus Gus (mouse) and Lucifer (cat).
- **365 Building Elements:** Various LEGO bricks and specialized pieces to construct the castle and accessories.

Key features of the assembled castle include a 3-level structure with a ballroom, a spinning dance floor, a dress studio, a closet with a working cat door, a bedroom, and a kitchen area. Additional accessories are provided to enhance play scenarios.



Figure 2.1: Fully assembled LEGO Cinderella and Prince Charming's Castle with included figures.



Figure 2.2: Close-up of the Cinderella, Prince Charming, Lady Tremaine, Gus Gus, and Lucifer figures.

3. ASSEMBLY INSTRUCTIONS (SETUP)

Follow the step-by-step visual instructions provided in the included building guide. Sort pieces by color and size to facilitate the building process. Ensure all connections are firm to maintain the structural integrity of the castle.

For an enhanced building experience, digital instructions are available through the official LEGO Builder App. This app provides 3D models, zoom, and rotate functions to assist with complex steps.



Figure 3.1: Utilizing digital building instructions for assembly.

Your browser does not support the video tag.

Video 3.1: An overview of the LEGO Builder App, demonstrating its features for digital building instructions.

4. INTERACTIVE FEATURES (OPERATING)

The Cinderella and Prince Charming's Castle is designed with several interactive features to enhance play:

- **Ballroom with Spinning Dance Floor:** Place Cinderella and Prince Charming on the dance floor and rotate them for a magical dance scene.
- **Dress Studio:** Utilize the mannequin and accessories to imagine new outfits for Cinderella.
- **Closet with Cat Door:** Lucifer the cat can enter and exit through his dedicated door.
- **Kitchen and Bedroom:** Furnished areas for role-playing daily castle life.



Figure 4.1: Detailed view of the castle's interior, showcasing various rooms and interactive elements.

Your browser does not support the video tag.

Video 4.1: A brief overview of the LEGO Disney Cinderella and Prince Charming's Castle set, highlighting its key features.

5. MAINTENANCE

To ensure the longevity of your LEGO set, follow these maintenance guidelines:

- **Cleaning:** Use a soft cloth dampened with mild soap and water to gently clean the bricks. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the assembled castle or individual bricks in a cool, dry place away from direct sunlight to prevent discoloration and warping.
- **Handling:** Handle the set with care to prevent pieces from detaching or breaking.

6. TROUBLESHOOTING

If you encounter any issues during assembly or play, consider the following:

- **Missing Pieces:** In the rare event of a missing piece, please contact LEGO Customer Service directly through their official website.
- **Loose Connections:** If parts feel loose, carefully re-examine the building steps in the instruction manual or the digital app to ensure all bricks are correctly aligned and pressed firmly together.
- **Difficulty with Assembly:** Refer to the digital instructions in the LEGO Builder App for 3D views and step-by-step guidance, which can often clarify complex steps.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	14.88 x 13.94 x 2.78 inches
Item Weight	2 pounds
Model Number	6379128
Recommended Age	5 years and up
Number of Pieces	365
Manufacturer	LEGO
Release Date	August 1, 2022

8. SAFETY INFORMATION

This product contains small parts which may pose a choking hazard for children under 3 years of age. Adult supervision is recommended during assembly and play, especially with younger children. Ensure all parts are securely connected to prevent accidental detachment.

9. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For any questions regarding product quality, missing parts, or general support, please visit the official LEGO Customer Service website. Information on warranty policies and contact details can be found there.

Official LEGO Website: www.lego.com/service

© 2025 LEGO Group. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XT71WY1>

More documents and user manuals: <https://manuals.plus/>