Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TCL 6165S1

TCL 30 SE Smartphone User Manual

Model: 6165S1 | Brand: TCL

Introduction

The TCL 30 SE is an unlocked Android smartphone designed to provide a comprehensive mobile experience. It features a 50MP AI triple camera for capturing high-quality photos, a large 128GB internal storage, and a 5000mAh battery for extended use. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.
This device is compatible with T-Mobile and AT&T LTE networks. It is not compatible with Verizon, Spectrum, Xfinity, or similar carriers. For detailed carrier compatibility, please refer to the provided compatibility chart or contact customer support.

Package Contents

Upon opening your TCL 30 SE package, you should find the following items:

- 1 x TCL 30 SE Mobile phone
- 1 x TCL 30 SE Mobile Phone Case
- 1 x Screen Protector
- 1 x Type-C Cable
- 1 x Charger (5V 2A)
- 1 x Sim Card Pin
- 1 x Quick Guide

Note: Headphones, SIM Card, and SD Card are not included.

Setup Guide

1. Inserting the SIM Card

The TCL 30 SE is a single SIM mobile phone. Use the provided SIM card pin to open the SIM tray. Insert your compatible Nano-SIM card into the tray, ensuring it is correctly oriented. Gently push the tray back into the phone until it clicks into place.

2. Initial Power On and Network Connection

Press and hold the power button until the TCL logo appears. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account. Ensure your SIM card is active with a compatible carrier (T-Mobile or AT&T LTE networks) for cellular service.

3. Security Setup

For enhanced security, you can set up Face Key recognition or the fingerprint sensor. Navigate to **Settings > Security** to configure these options. These features provide effortless access to your device.

4. Screen Sensitivity Adjustment

If you find the screen sensitivity to be unresponsive, you can adjust it. Go to **Settings > System > Languages & input > Advanced > Pointer speed**. Drag the slider to the right to increase sensitivity or to the left to decrease it.



Image: Front and back view of the TCL 30 SE smartphone, showcasing its design and camera module.




Image: A visual chart indicating compatible and incompatible major carriers for the TCL 30 SE smartphone.

Operating Your Device

Display and Visuals

The TCL 30 SE features a 6.52-inch HD+ display powered by NXTVISION technology. AI optimization enhances color and clarity for a more immersive viewing experience. Eye-comfort modes are available to reduce blue light exposure and minimize eye strain, making the device comfortable to use in various lighting conditions.



Image: A hand holding the TCL 30 SE, showcasing its 6.52-inch HD+ display with AI-enhanced picture quality powered by NXTVISION.

Camera Features

Capture moments with the 50MP AI-powered rear triple camera system. This system allows for clear photos even in dimly lit environments and supports gesture shooting for hands-free photography. The front camera is 8MP.



Image: Close-up view of the TCL 30 SE's rear triple camera system, highlighting its 50MP main camera, 2MP macro camera, and 2MP depth camera, along with the 8MP front camera.

Storage and Battery

The device comes with 128GB of internal storage, expandable up to 512GB with a microSD card (sold separately). The massive 5000mAh battery provides up to two days of usage, and intelligent charging mode helps prolong its lifespan.



Image: A graphic illustrating the TCL 30 SE's 5000mAh battery capacity and estimated usage times for video playback, music playback, 4G web surfing, and standby time.



Image: A visual representation of the TCL 30 SE's 4GB RAM and 128GB internal storage, with an icon of a 512GB microSD card indicating expandable storage.

Standard Operations

The TCL 30 SE runs on Android 12.0, offering a familiar and intuitive user interface. Standard applications for messaging, contacts, and calls are integrated with Google apps. The phone supports web browsing, video streaming, and various other applications available through the Google Play Store.

Do Not Disturb Feature

To manage notifications, utilize the Do Not Disturb feature. Access it via**Settings > Sound & Vibration**. You can customize it to silence calls and messages during specific times or from certain contacts.

Battery Percentage Display

To display the battery percentage next to the battery icon, go to**Settings > Display > Status Bar & Notch > Battery Percentage** and select your preferred display option.

Maintenance

General Care

To ensure the longevity of your TCL 30 SE, keep it clean and free from dust and debris. Use a soft, lint-free cloth for cleaning. Avoid exposing the device to extreme temperatures, direct sunlight for prolonged periods, or liquids. Always use the provided phone case and screen protector for added physical protection.

Battery Longevity

The intelligent charging mode helps to prolong the battery's lifespan. It is recommended to use the original charger and Type-C cable provided with your device for optimal charging performance.

Troubleshooting

Screen Unresponsive or Insensitive

If the screen feels unresponsive or insensitive, adjust the pointer speed. Go to **Settings > System > Languages & input > Advanced > Pointer speed**. Move the slider to the right to increase sensitivity.

App Notifications Not Appearing

If you are not receiving notifications from certain applications, check the Smart Manager app. Open **Smart Manager > Auto-Start** and ensure that "Automatically Manage" is turned off for the affected applications. This allows the apps to run in the background and deliver notifications.

Network Connectivity Issues

Ensure your SIM card is from a compatible carrier (T-Mobile or AT&T LTE networks). If you experience persistent network issues, try restarting your device or contacting your carrier's customer support for assistance.

Technical Specifications

Brand	TCL
Model Name	TCL 30 SE
Item Model Number	6165S1
Operating System	Android 12.0
Memory Storage Capacity	128 GB (expandable up to 512GB with microSD)
RAM	4 GB
Screen Size	6.52 Inches
Resolution	720 x 1600
Battery Capacity	5000 mAh

Rear Camera	50MP Main + 2MP Macro + 2MP Depth
Front Camera	8MP
CPU Model	MediaTek Helio G25 (Octa-Core 2 GHz)
Wireless Communication Technologies	Bluetooth, Cellular, NFC, Wi-Fi
Audio Jack	3.5 mm
Color	Space Gray
Item Weight	13.1 ounces
Package Dimensions	6.77 x 3.7 x 2.48 inches

Warranty and Support

Warranty Information

The TCL 30 SE comes with a one-year US warranty. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions regarding carrier compatibility, technical issues, or general support, please contact TCL customer support. You may also find helpful instructional videos and additional information on official TCL support channels online.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XV7MXJX

More documents and user manuals: **https://manuals.plus/**