

[Manuals.plus](#) /

› [Robo Alive](#) /

› Robo Alive Robotic Snake Model 7150 Instruction Manual

Robo Alive 7150

Robo Alive Robotic Snake Model 7150 Instruction Manual

Your guide to setting up and enjoying your Robo Alive Robotic Snake.

1. INTRODUCTION

The Robo Alive Robotic Snake is an interactive electronic pet designed to mimic the realistic movements of a snake. It slides silently and features lifelike tongue movements and glowing eyes, providing an engaging play experience. This manual provides essential information for the safe and proper use of your robotic snake.

2. SAFETY INFORMATION

WARNING:

- Not suitable for children under 36 months due to small parts.
- Always use under the direct supervision of an adult.
- Ensure battery compartment is securely closed to prevent ingestion of batteries.

3. WHAT'S IN THE BOX

Upon opening your Robo Alive Robotic Snake package, you should find the following items:

- 1 x Robo Alive Robotic Snake (color may vary)
- 1 x Instruction Manual



Image: The product packaging for the Robo Alive Robotic Snake, displaying both green and red snake models.

4. SETUP

4.1. Battery Installation

The Robo Alive Robotic Snake requires 2 AAA batteries for operation. Batteries are not included and must be purchased separately.

1. Locate the battery compartment on the underside of the snake.
2. Using a small screwdriver, carefully open the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

4.2. Initial Activation

Once batteries are installed, locate the ON/OFF switch, usually found near the battery compartment. Slide the switch to the "ON" position to activate the snake.

5. OPERATING INSTRUCTIONS

Your Robo Alive Robotic Snake is designed for realistic movement and interaction.

- **Realistic Movement:** Once activated, the snake will begin to slither and move across smooth surfaces, mimicking the motion of a real snake.
- **Lifelike Features:** Observe the snake's eyeballs moving and its tongue flicking in and out, adding to its realistic appearance.
- **Light-Up Head:** The snake's head is designed to light up during operation, enhancing its visual appeal.



Image: A green Robo Alive Robotic Snake demonstrating its realistic movement and light-up head feature.

**I MOVE
LIKE A REAL
SNAKE!**



I LIGHT UP

Image: A child interacting with the green Robo Alive Robotic Snake, showing its movement on a flat surface.

6. MAINTENANCE

- **Cleaning:** Wipe the snake with a dry, soft cloth to remove dust and dirt. Do not immerse in water or use harsh cleaning agents.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly.
- **Storage:** Store the snake in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Snake does not move or light up.	Batteries are dead or incorrectly installed. ON/OFF switch is in the "OFF" position.	Replace with new AAA batteries, ensuring correct polarity. Slide the ON/OFF switch to "ON".
Movement is sluggish or erratic.	Batteries are low. Surface is not smooth enough.	Replace batteries. Ensure the snake is operating on a smooth, flat surface.

8. SPECIFICATIONS

- **Model Number:** 7150
- **Product Dimensions:** 15.75 x 1.97 x 1.57 inches
- **Item Weight:** 8.8 ounces
- **Recommended Age:** 3 years and up
- **Batteries Required:** 2 x AAA (not included)
- **Manufacturer:** ZURU



Image: A red variant of the Robo Alive Robotic Snake, showcasing its segmented body design.

9. WARRANTY AND SUPPORT

Specific warranty information for the Robo Alive Robotic Snake Model 7150 is not provided in this manual. For warranty details, product support, or to contact the manufacturer, please refer to the official ZURU website or the retailer where the product was purchased.

You can also visit the [Robo Alive Store on Amazon](#) for more information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question