



[Manuals.plus](#) /

› [Samsonite](#) /

› Samsonite S'Cure Spinner Suitcase User Manual

Samsonite 49539/9784

Samsonite S'Cure Spinner Suitcase User Manual

Model: 49539/9784

INTRODUCTION

Welcome to the user manual for your Samsonite S'Cure Spinner suitcase. This robust and lightweight luggage is designed for secure and comfortable travel. Featuring a durable polypropylene shell, a three-point locking system, smooth-rolling double wheels, and a dual tube wheel handle, the S'Cure provides reliability and ease of use for all your journeys. Please read this manual carefully to ensure proper setup, operation, and maintenance of your suitcase.



Image: A full view of the Samsonite S'Cure Spinner suitcase in aqua blue, showcasing its hard shell, telescopic handle extended, and four spinner wheels. A side-mounted combination lock is visible on the left.

SETUP

Setting the Combination Lock

Your Samsonite S'Cure suitcase is equipped with an integrated three-digit combination lock for enhanced security. The lock is preset to 0-0-0 at the factory.

1. Open the suitcase by sliding the main lock button to the side.

2. Locate the small reset button or lever next to the number dials. This is usually a small, recessed button that requires a pen or pointed object to press.
3. With the suitcase open, press and hold the reset button/lever.
4. While holding the reset button/lever, set your desired three-digit combination by rotating the dials. Choose a memorable combination.
5. Release the reset button/lever. Your new combination is now set.
6. Test your new combination by scrambling the dials and then entering your new code to ensure the lock opens.

***Important:** Remember your combination. Samsonite cannot open your lock or provide your combination if you forget it.*

OPERATING INSTRUCTIONS

Using the Three-Point Locking System

The S'Cure suitcase features a secure three-point locking system for robust closure and protection against moisture penetration.

- **To Open:** Ensure the combination lock is set to the correct code. Slide the main lock button to release the central latch. Simultaneously, the two side latches will also release.
- **To Close:** Align the two halves of the suitcase. Close the two side latches first by pressing them firmly until they click into place. Then, close the central latch and scramble the combination dials to secure it.

Extending and Retracting the Handle

The dual tube wheel handle is designed for comfortable maneuvering.

- **To Extend:** Press the button located on the top of the handle grip and pull the handle upwards until it locks into your desired height.
- **To Retract:** Press the button on the handle grip again and push the handle downwards until it fully retracts into the suitcase body.

Maneuvering with Spinner Wheels

Your S'Cure suitcase is equipped with smooth-rolling double wheels, allowing for 360-degree rotation and effortless movement.

- For upright rolling, push the suitcase alongside you.
- For two-wheel pulling, tilt the suitcase and pull it behind you.

Interior Features

The interior of your S'Cure suitcase is designed for organized packing.

- **Lowered Cross Ribbons:** Use these elastic straps to secure your packed items and prevent shifting during transit.
- **Zipped Divider Pad:** This panel helps separate the two compartments of the suitcase and can be used to store smaller items or documents.
- **Large Side Pocket:** Provides additional storage for accessories or items you need to access quickly.

MAINTENANCE

Cleaning the Exterior

To clean the polypropylene shell, use a soft cloth dampened with mild soap and water. Wipe gently and then dry thoroughly with a clean, dry cloth. Avoid abrasive cleaners or solvents, as they can damage the surface.

Cleaning the Interior

The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow it to air dry completely before closing the suitcase or storing items.

Wheel and Handle Care

Periodically check the wheels for any debris (hair, lint) that might hinder smooth rolling. Clean them as needed. The telescopic handle mechanism generally requires no special maintenance, but ensure it extends and retracts smoothly. Do not force the handle if it feels stuck.

Storage

Store your suitcase in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is clean and dry before storing to prevent mold or mildew.

TROUBLESHOOTING

Combination Lock Issues

- **Lock not opening:** Double-check that you have entered the correct three-digit combination. Ensure each number is precisely aligned in the center of the display window. If you forgot your combination, there is no master key or reset code from Samsonite. You may need to try common combinations or seek professional assistance.
- **Difficulty setting new combination:** Ensure the suitcase is open and the reset button/lever is fully pressed while setting the new code. Release the button only after the new combination is set.

Wheel Issues

- **Wheels not rolling smoothly:** Check for any debris (e.g., hair, string) wrapped around the wheel axles. Carefully remove any obstructions. If the wheels are damaged, contact Samsonite customer support for repair options.

Handle Issues

- **Handle sticking or not extending/retracting:** Ensure the release button is fully depressed. Avoid overloading the suitcase, which can put stress on the handle mechanism. Do not force the handle.

SPECIFICATIONS

| Feature | Detail |
|--------------------|------------------------|
| Product Dimensions | 49 x 29.01 x 69.01 cm |
| Item Model Number | 49539/9784 |
| ASIN | B09XVQKTHQ |
| Closure Type | 3-point locking system |
| Material | Polypropylene |
| Department | Unisex |

| Feature | Detail |
|----------------------|----------------------------|
| Manufacturer | JiDuoJiao (as per listing) |
| Date First Available | 17 May 2019 |

WARRANTY AND SUPPORT

Samsonite products are known for their quality and durability. For information regarding the warranty coverage for your S'Cure Spinner suitcase, please refer to the warranty card included with your purchase or visit the official Samsonite website. Warranty terms and conditions may vary by region.

For further assistance, product inquiries, or to locate an authorized service center, please visit the official Samsonite customer support page or contact their service hotline. Always provide your model number (49539/9784) and proof of purchase when seeking support.

Note: This manual provides general guidance. Specific warranty details and support contact information are best obtained directly from Samsonite's official channels.