Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Salter 3003SS

Salter 3003 SSSVDR08EU16 Kitchen Weighing Scale

Digital Glass Food Scales Instruction Manual

Introduction

This manual provides detailed instructions for the proper setup, operation, and maintenance of your Salter 3003 SSSVDR08EU16 Digital Glass Kitchen Scale. Designed for precision, this scale features an Aquatronic function for liquids, an Add & Weigh function for multiple ingredients, and easy-to-read measurements in both metric and imperial units. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your device.

Product Overview

The Salter 3003 SSSVDR08EU16 kitchen scale is a versatile tool for accurate measurement in your kitchen. It features a sleek glass platform and an intuitive digital display.

- **Digital Display:** Large, easy-to-read LCD for clear measurement readings.
- **Glass Platform:** Hygienic and easy to clean, providing a stable weighing surface.
- **Unit Conversion:** Switch between kilograms (kg) and pounds (lb) for solid ingredients, and milliliters (ml) and fluid ounces (fl.oz) for liquids.
- **Tare Function (Zero):** Allows you to reset the scale to zero after placing a container or an ingredient, enabling measurement of multiple items in the same bowl.
- **Aquatronic Function:** Specifically designed for accurate measurement of liquids.
- **Add & Weigh Function:** Facilitates measuring multiple ingredients consecutively without emptying the bowl.



Figure 1: Top-down view of the Salter 3003 SSSVDR08EU16 Digital Kitchen Scale, showcasing its transparent glass platform and silver base with control buttons and LCD display.



Figure 2: Close-up of the scale's hygienic glass platform and large, easy-to-read digital display, highlighting its clean design.



Figure 3: Demonstration of the Add & Weigh function, showing multiple ingredients being measured in the same bowl on the scale.



Figure 4: The Aquatronic function in use, accurately measuring liquids in milliliters or fluid ounces.




Figure 5: Visual representation of the scale's compact dimensions, measuring approximately 20cm by 21cm.

Setup

1. Battery Installation

Your Salter kitchen scale requires two CR2032 batteries. A battery is typically included with the product. To install or replace batteries:

1. Turn the scale upside down.
2. Locate the battery compartment cover on the underside of the scale.
3. Open the compartment cover.
4. Insert two CR2032 batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
5. Close the battery compartment cover securely.



Figure 6: Underside of the Salter kitchen scale, showing the battery compartment and the unit conversion switch.

2. Initial Use and Unit Selection

Before first use, ensure the scale is placed on a flat, stable surface. The scale allows you to select your preferred unit of measurement.

- **For Solid Measurements (Weight):** Use the 'KG/LB' button to toggle between kilograms (kg) and pounds (lb).
- **For Liquid Measurements (Volume):** Use the 'ML/FL.OZ' button to toggle between milliliters (ml) and fluid ounces (fl.oz).
- **Physical Switch for Weight Units:** On the underside of the scale, there is a small switch that allows you to select between pounds (lb) and kilograms (kg) as the default weight unit. Ensure this switch is set to your desired unit.

Operating Instructions

1. Basic Weighing

1. Place the scale on a firm, flat surface.
2. Press the 'ON/ZERO' button to turn on the scale. The display will show '0'.

3. Place the item to be weighed directly onto the glass platform.
4. Read the measurement displayed on the LCD screen.

2. Tare Function (Zero) / Add & Weigh

The Tare function allows you to measure multiple ingredients in the same container or to exclude the weight of a container.

1. Place your first ingredient or an empty container on the scale.
2. Press the 'ON/ZERO' button. The display will reset to '0', effectively subtracting the weight of the container or first ingredient.
3. Add the next ingredient to the container. The display will show the weight of only the newly added ingredient.
4. Repeat this process for all subsequent ingredients.

3. Measuring Liquids (Aquatronic Function)

The Aquatronic function allows for precise measurement of liquids.

1. Turn on the scale and place an empty container on the platform.
2. Press the 'ON/ZERO' button to tare the container's weight.
3. Press the 'ML/FL.OZ' button to select your desired liquid unit (milliliters or fluid ounces).
4. Pour the liquid into the container. The display will show the volume of the liquid.

4. Turning Off the Scale

To conserve battery life, the scale will automatically turn off after a period of inactivity. You can also manually turn it off:

- Press the 'OFF' button to manually turn off the scale.

Maintenance and Care

- **Cleaning:** Wipe the scale with a damp cloth and mild detergent. Do not immerse the scale in water or use abrasive cleaning agents.
- **Storage:** Store the scale in a dry place at room temperature. Avoid extreme temperatures or high humidity.
- **Handling:** Handle the scale with care. Do not drop it or subject it to strong impacts, as this may damage the internal sensors.
- **Battery Replacement:** Replace batteries when the display shows a low battery indicator (e.g., "LO").

Troubleshooting

Problem	Possible Cause	Solution
Display shows "LO"	Low battery.	Replace the two CR2032 batteries.
Display shows "Err" or "O-Ld"	Overload. The weight exceeds the maximum capacity.	Remove the item immediately to prevent damage. Ensure the weight is within the 5kg/11lb limit.
Inaccurate readings	Scale not on a flat, stable surface; external vibrations; scale needs re-calibration (rare).	Ensure the scale is on a firm, level surface. Avoid vibrations. Turn the scale off and on again to reset.
Scale does not turn on	No batteries or incorrect battery installation.	Check if batteries are installed correctly and have sufficient charge. Replace if necessary.

Specifications

Feature	Detail
Model Number	3003SS
Capacity	5 kg / 11 lb
Graduation	2g / 1/8 oz
Units of Measurement	kg, lb, ml, fl.oz
Display Type	Digital LCD
Platform Material	Glass
Power Source	2 x CR2032 Batteries (included)
Product Dimensions	3.1 x 0.93 x 3.26 inches (approx. 20 x 21 cm)
Product Weight	1.95 Pounds
Manufacturer	Ultimate Products Ltd

Warranty and Support

Salter products are manufactured to high standards and are rigorously tested. For specific warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Salter website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Salter. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XVRQY75

More documents and user manuals: **https://manuals.plus/**