

Arlo VMS4352P

Arlo Pro 4 XL Spotlight 3 Camera Security Bundle (VMS4352P) User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. INTRODUCTION

This manual provides detailed instructions for the Arlo Pro 4 XL Spotlight 3 Camera Security Bundle, model VMS4352P. This system offers advanced security features including 2K video resolution with HDR, a 160-degree diagonal viewing angle, color night vision, and motion detection. The cameras are 100% wire-free and designed for outdoor use, offering up to one year of battery life on a single charge. The bundle includes a SmartHub for optional local storage.

2. PACKAGE CONTENTS

Verify that all components are present in your package:

- Three (3) Arlo Pro 4 XL Cameras with XL Batteries and Housing
- Three (3) Security Mounts
- One (1) Arlo SmartHub
- Charging Cable and Power Adapter
- Mounting Screw Kits



Image 2.1: Arlo Pro 4 XL Security Bundle showing three cameras, the SmartHub, and mounting hardware.

3. SETUP

3.1. Charge Cameras

Before initial use, fully charge all Arlo Pro 4 XL cameras. Connect the charging cable to the camera and a

power adapter. The LED indicator on the camera will show charging status.

3.2. Connect the SmartHub

1. Connect the SmartHub to your router using an Ethernet cable.
2. Connect the SmartHub to power using the provided power adapter.
3. Wait for the SmartHub's LED indicator to turn solid green, indicating it is ready.

3.3. Install the Arlo App

Download the Arlo Secure App from your device's app store (iOS or Android). Create an Arlo account or log in if you already have one. Follow the in-app instructions to add your SmartHub and cameras to your account.

4. INSTALLATION

4.1. Choose Mounting Locations

Select locations that provide optimal viewing angles and motion detection coverage. Consider areas with high traffic or vulnerable entry points. Ensure the cameras are within Wi-Fi range of the SmartHub.

4.2. Mount the Cameras

1. Use the provided security mounts and screw kits to securely attach the mounts to a wall or other stable surface.
2. Attach the Arlo Pro 4 XL camera to the mount. Adjust the camera angle to cover the desired area.



Image 4.1: Arlo Pro 4 XL camera mounted on an exterior wall.



Image 4.2: Arlo Pro 4 XL camera mounted under an overhang.

5. OPERATING INSTRUCTIONS

5.1. Live View

Open the Arlo Secure App and select a camera to view its live feed. This allows real-time monitoring of your property.

5.2. Motion Detection and Alerts

The Arlo Pro 4 XL cameras are equipped with advanced motion detection. When motion is detected, the camera will record and send an alert to your smartphone. You can customize motion sensitivity and activity zones within the Arlo app.

5.3. Color Night Vision

The integrated spotlight enables color night vision, providing clear, full-color video recordings even in low-light conditions. This feature can be configured in the app.

5.4. Two-Way Audio

Utilize the built-in speaker and microphone for two-way communication through the Arlo app. This allows you to speak to visitors or deter intruders.

5.5. Local Storage

The included SmartHub supports optional local storage via a USB flash drive (sold separately). Insert a compatible USB drive into the SmartHub to enable local recording of video events.

6. MAINTENANCE

6.1. Battery Care

The cameras feature XL batteries designed for extended life. Monitor battery levels through the Arlo app and recharge as needed. Use only Arlo-approved charging accessories.

6.2. Cleaning

Periodically clean the camera lens and housing with a soft, damp cloth to ensure optimal video clarity and prevent obstruction of sensors.

7. TROUBLESHOOTING

- **Camera Not Connecting:** Ensure the camera is within range of the SmartHub and fully charged. Restart both the camera and SmartHub.
- **Poor Video Quality:** Check for obstructions on the camera lens. Ensure a strong Wi-Fi signal.
- **Motion Detection Issues:** Adjust motion sensitivity settings in the Arlo app. Verify activity zones are correctly configured.
- **Battery Draining Quickly:** High activity areas or frequent live viewing can reduce battery life. Consider adjusting settings or charging more often.

For further assistance, refer to the Arlo support website or contact customer service.

8. SPECIFICATIONS

Feature	Specification
Model Number	VMS4352P
Video Resolution	2K HDR
Viewing Angle	160° Diagonal
Night Vision	Color Night Vision
Power Source	Battery Powered
Connectivity	Wi-Fi
Indoor/Outdoor Use	Outdoor
Alert Type	Motion Only
Dimensions (Package)	6.59 x 11.67 x 6.52 inches
Weight (Package)	4.93 pounds
International Protection Rating	IP54

9. WARRANTY AND SUPPORT

This product is offered as a renewed item. For specific warranty details and support, please refer to the Amazon Renewed Guarantee which typically covers replacement or refund if not satisfied with the purchase. For technical support related to the Arlo system, visit the official Arlo support website or contact Arlo customer service directly. Keep your purchase receipt for warranty claims.

Amazon Renewed Guarantee: Renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee if not satisfied with the purchase.

[pdf] Quick Start Guide Instructions Guide Declaration of Conformity Label



Arlo Pro 4 XL Spotlight Camera Quick Start Guide VMS4352P camera Technologies arlo en us imagesSet up your Title Author Subject Created Date 5 14 2021 3 31 47 PM DQSG US images documents arlopro4 |||

Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Apple is a trademark of Apple Inc., registered in the US and other countries. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. Any o...

lang:en score:20 filesize: 651.68 K page_count: 2 document date: 2021-05-14