

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Mr. Heater](#) /

> [Mr. Heater 1500W Portable Ceramic Electric Buddy Heater Instruction Manual](#)

Mr. Heater MHBE150FAT

Mr. Heater 1500W Portable Ceramic Electric Buddy Heater

Model: MHBE150FAT

Brand: Mr. Heater

IMPORTANT SAFETY INFORMATION

Read and understand all instructions before using this heater. Failure to follow these instructions may result in fire, electric shock, serious injury, or death.

- **Indoor Use Only:** This heater is designed for indoor use in residential and office environments. Do not use outdoors or in wet locations.
- **Electrical Safety:** Plug the heater directly into a 120V, 60Hz wall outlet. Do not use with extension cords, power strips, or surge protectors. Ensure the outlet is not overloaded.
- **Overheat Protection:** The heater is equipped with an automatic overheat protection system. If the heater overheats, it will automatically shut off. Unplug the heater, allow it to cool for 30 minutes, and then plug it back in.
- **Tip-Over Safety Switch:** A safety switch automatically turns off the heater if it is tipped over. Ensure the heater is placed on a firm, level surface.
- **Clearance:** Maintain a minimum distance of 3 feet (0.9 meters) from any combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains.
- **Do Not Cover:** Never cover the heater or block the air intake/outlet vents. This can cause overheating and fire.
- **Supervision:** Close supervision is necessary when any heater is used by or near children or individuals with reduced physical, sensory, or mental capabilities.
- **Unplug When Not In Use:** Always unplug the heater when not in use or when cleaning.

PRODUCT OVERVIEW

The Mr. Heater 1500W Portable Ceramic Electric Buddy Heater provides supplemental heat for your home or office. It features a ceramic heating element, adjustable thermostat, and multiple safety features for reliable operation. Its compact design and integrated handle make it easy to move and store.



Image: The Mr. Heater Portable Ceramic Electric Buddy Heater positioned on a table in a living room, demonstrating its compact size and indoor use.

Key Features

- Heats up to 170 sq. ft.
- 120V, 1500W power output.
- Features a tip-over safety switch and overheat protection.
- Fold-down handle for portability.
- Adjustable thermostat for personalized comfort.
- Efficient ceramic heating element.
- Two heat settings: Low (1000W) / High (1500W).
- Fan-only setting for air circulation.
- Power indicator light.
- Ideal for small and medium rooms.

HEATER FEATURES











-  Tip-Over Safety Shut-Off
-  Overheat protection with automatic shutdown
-  Thermostatically controlled with low and high heat settings (1000W Low /1500W High)
-  Ceramic heating element
-  Cord wrap for easy storage
-  Fan only option
-  Fan-forced for wide heat distribution
-  Fold down handle
-  6 foot (1,8 m) power cord
-  1 One year limited warranty



Image: A visual summary of the heater's features, including safety mechanisms, heating capabilities, and design elements like the fold-down handle and cord wrap.

PORTABLE ELECTRIC HEATER

Fold down handle

Fan only option available

Thermostatically controlled with low and high heat settings (1000W Low/1500W High)

Cord wrap for easy storage

Fan-forced for wide heat distribution

6 foot (1,8 m) power cord

Tip-Over safety shut-off (on the bottom of unit)



Image: An annotated diagram highlighting various components and features of the portable electric heater, such as the fold-down handle, heat settings, and cord wrap.

SETUP

- Unpack:** Carefully remove the heater from its packaging. Retain packaging for future storage or transport.
- Placement:** Place the heater on a firm, level, non-combustible surface. Ensure there is at least 3 feet (0.9 meters) of clear space around the heater from walls, furniture, and other objects. Do not place on soft surfaces like rugs or carpets that could block the air intake.

3. **Power Connection:** Unwind the power cord from the cord wrap. Plug the heater directly into a standard 120V, 60Hz electrical outlet. Ensure the outlet is in good condition and not shared with other high-wattage appliances.



Image: A detailed view of the cord wrap mechanism located on the back of the heater, designed for organized storage of the power cord.

OPERATION

The heater features two control knobs on the top panel: a Power/Fan Mode selector and a Thermostat control.



Image: A close-up of the heater's top control panel, showing the two rotary knobs for power/fan selection and temperature adjustment.

1. **Power On:** Plug the heater into a suitable electrical outlet. The power indicator light will illuminate.
2. **Select Mode:** Turn the left knob (Power/Fan Mode) to select your desired setting:
 - **Fan Only:** Activates the fan without heat.
 - **Low Heat:** Provides 1000W of heating power.
 - **High Heat:** Provides 1500W of heating power.
3. **Set Temperature:** Turn the right knob (Thermostat) to your desired temperature setting. The heater will cycle on and off to maintain the set temperature. For continuous heat, turn the thermostat knob to its maximum setting.
4. **Power Indicator Light:** The red light on top of the heater indicates that the unit is receiving power.



Image: A close-up view of the red power indicator light, which illuminates when the heater is connected to a power source.

MAINTENANCE

Regular cleaning and proper storage will help maintain the heater's performance and extend its lifespan.

1. Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the heater in water or allow water to drip into the interior.
- Periodically vacuum the air intake and outlet grilles to remove dust and lint.

2. Storage:

- When not in use, store the heater in a cool, dry location.
- Wrap the power cord neatly around the integrated cord wrap for tidy storage.
- The fold-down handle can be used for convenient carrying and storage.

TROUBLESHOOTING

If your heater is not operating correctly, consult the following common issues and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit. Tip-over switch activated. Thermostat set too low.	Ensure the heater is securely plugged into a working 120V outlet. Place the heater on a firm, level surface. Turn the thermostat knob to a higher setting.
Heater stops working unexpectedly.	Overheat protection activated. Tip-over switch activated.	Unplug the heater, allow it to cool for 30 minutes, then plug back in. Ensure vents are not blocked. Place the heater on a firm, level surface.

Problem	Possible Cause	Solution
Reduced heat output.	Thermostat set too low. Air intake/outlet blocked.	Increase the thermostat setting. Ensure vents are clear of dust and obstructions.

SPECIFICATIONS

Feature	Detail
Brand	Mr. Heater
Model Number	MHBE150FAT
Power Output	1500 Watts (High), 1000 Watts (Low)
Voltage	120 Volts
Amperage	12.5 Amps
Heating Coverage	Up to 170 sq. ft.
Heating Element	Ceramic
Dimensions (D x W x H)	8.27" x 12.2" x 12.6"
Item Weight	4.4 pounds
Special Features	Portable, Tip-Over Safety Switch, Overheat Protection, Adjustable Thermostat, Fold-Down Handle, Fan-Only Setting
Cord Length	6 feet (1.8 meters)
UPC	089301994935

WARRANTY AND SUPPORT

This Mr. Heater product is covered by a **1-year limited warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal use.

For warranty claims, technical support, or replacement parts, please contact Mr. Heater customer service. Keep your purchase receipt as proof of purchase.

Contact Information:

Please refer to the official Mr. Heater website or product packaging for the most current customer service contact details.

